

Pioneer of IP Innovation



Software Installation Guide & Quick User Guide PLANET UNI - NMS Universal Network Management Software





Installing VM VirtualBox

Download to install Oracle VM VirtualBox from Internet.

<u>Download Link</u> (http://www.oracle.com/technetwork/serverstorage/virtualbox/downloads/index.html)

ORACLE	Menu	Q		よ Sign In 🗸	Country/Region ~	💋 Call
Oracle Technology Network	/ Server and Storage Syster	ns / Oracle VM VirtualBox /	Downloads			
All-Flash Storage Corente Cloud Services Exchange Developer Studio Engineered Systems Ksplice NAS Storage Netra Systems Networking and Data Center Fabric Products OpenStack Oracle Linux Oracle Optimized Solutions Oracle VM Oracle VM	Overview Download Oracle VM Virtt The latest release is On this page you can Oracle VI Oracle VI Source CI Oracle VI Oracle VI	IS Documentation Comm IalBox version 5.2.20. download: V VirtualBox Base Packages - 5 V VirtualBox Extension Pack ode for Oracle VM VirtualBox Ba V VirtualBox Pre-built Appliance Ingrant Boxes for Oracle VM Virtu	aunity Support .2.20 ase Packages s JalBox - GitHub Nev	Learn More		
Oracle x86 Servers Private Cloud Appliance SAN Storage Secure Global Desktop Server Management Trols	Oracle VM Virtual Freely available for Win	Box Base Packages - 5.2. dows, Mac OS X, Linux and Solaris	20 s x86 platforms under	GPLv2:		
Software in Silicon	Platform	:	32-bit 6	64-bit		
Software in Silicon Cloud	Windows			Mindows Installer		
Solaris 10				. windows mistalier		
Solaris 11	Mac OS X (64-bit)		-	🗄 dmg Image		
Solaris Cluster	Solaria 10 E/08 and Is	tor or Solaria 11 (64 bit)				
SPARC Servers	Solaris To 5/06 allu la	nor or Solans TT (04-bit)		 Solaris Package 		
StorageTek Tape Storage Sun Blade 6000 Modular	Linux Platforms					



Installing UNI-MNS

Select items from the menus to download UNI-NMS

(UNI-NMS_v1.0b19705.ova.zip).

Download Link

🛃 View Downloads - Internet Explorer			-		×
View and track your downloads		Search downloads			٩
Name	Location	Actions			
UNI-NMS_v1.0ova 909 MB ftp.planet.com.tw	Do you want to open save this file?	or Open	Save	•	×
UNI-NMS_v1.0ova 909 MB 10.1.0.80	Downloads		Open	•	
FW_WDAP-W7zip 2.74 MB ftp.planet.com.tw	Downloads		Open	•	
Options		Clear li	st	Close	



Importing UNI-NMS Software

- Double-click "UNI-NMS_v1.0b190705.ova" to import (or import it through the VM VirtualBox Manager).
- Uncheck the following items if existed.
 - USB Controller
 - 🗸 DVD
 - Sound Card
- Select
 - Reinitialize the MAC ...

			?	×
Ę	Import Virtual Appliance			
	Appliance to import			
				_
	C:\Users\reyow\Desktop\UNI-NM;	W/ WIUNI-NMS_v1.06190705.ova		
	Appliance settings			
	Virtual System 1			^
	😽 Name	UNI-NMS		
	Product	UNI-NMS		
	Product-URL	http://www.planet.com.tw		
	🗩 Vendor	PLANET Technology Corporation		
	Vendor-URL	https://www.planet.com.tw		
	Version	v1.0b190705		
	Description	PLANET Union Network Management System (UNI-NMS)		~
	You can modify the base folder w modified.	ich will host all the virtual machines. Home folders can also be individually (per vir	tual machii	1e)
	C:\Users\reyow\WirtualBox V	ds .		\sim
	MAC Address Policy: Generate n	w MAC addresses for all network adapters		-
	Additional Options: 🔲 Import 1	ard drives as VDI		_
	2.	2		
		Guided Mode Restore Defaults Import	Cau	ncel



How to Set Up the Software

- Right-click "UNI-NMS".
- Select "Create Shortcut on Desktop".

🦸 Oracle VM VirtualBox Mar	nager					
<u>F</u> ile <u>M</u> achine <u>H</u> elp						
Tools	Click		New New	Settings	Discard	Start
The		_	💻 Gr	eneral		
Powered Off	\odot	<u>S</u> ettings			Ctrl+S	NMS
	G.	Cl <u>o</u> ne			Ctrl+0	ntu (32-bit) sers\revow
	R	Move				
	R	Export to OCI.				
	*	<u>R</u> emove				
	0	Gro <u>u</u> p				⁷ M Paravir
	۵	S <u>t</u> art			•	- 1
		<u>P</u> ause				
	\bigcirc	<u>R</u> eset				мв
	\bigtriangledown	<u>C</u> lose			►	BoxVGA
	Ф	Discard Saved	State			abled
	5	Show <u>L</u> og			Ctrl+L	- 1
	G	Re <u>f</u> resh				- 1
2	E.	Show in Explo	rer			S-disk001.
2.	5	Create Shortcu	ut on Des	sktop		1
	31	<u>S</u> ort	_	_	_	-
			•			
			🧭 ប	5B		
			USB Co	ontroller: Filters:	OHCI	.)
			Course.	ared for		9
			<u> </u>	area 10	10612	



Setting Up VM Network Adapter

• Unselect Enable Hardware Virtualization.

휳 Oracle VM VirtualBox N	Manager				- 🗆 ×
<u>File Machine Help</u>	2.Click Setti	ngs	•		
Tools	4	New Settings Discard St	taurt		
VNI-NMS Powered Off	UNI-NMS - Setting	s		? >	
elect VM	📃 General	System	4. Choose Acceleration	1	
	System	<u>M</u> otherboard <u>P</u> rocessor	r Acce <u>l</u> eration		UNI-NMS
3. Choose Syste	m Display	Paravirtualization Interface:	Default 🔻		
	Storage	Hardware Virtualization:	Enable VT-x/AMD-V 5. Unselect Enable Ha	ardware Virtualization	
	🕩 Audio				
	Network				
	Serial Ports				
	DSB				
	Shared Folders				
	User Interface				
		Neved toldars		OK Cancel	
		- 219160 1010612			



Setting Up VM Network Adapter

 Please ensure your Network Adapter 1 is connected to the local network (Managed devices included).





Running UNI-NMS Application

• Select the VM.

Press "Start" to run the UNI-NMS.



*Press the setting button to define the General Name of VM.





Running UNI-NMS Application

 When the "UNI-NMS login" appears, please enter user login account "adminuser", and password "adminuser".

VNI-NMS_Agent [Running] - Oracle VM VirtualBox	—	×
File Machine View Input Devices Help		
Ubuntu 16.04.1 LTS UNI-NMS tty1		
UNI-NMS login: adminuser Password: Veet login: Two Det 20,10:38:00 CST 2018 on ttu1		
Welcome to Ubuntu 16.04.1 LTS (GNU/Linux 4.4.0-79-generic i686)		
<pre>* Documentation: https://help.ubuntu.com * Management: https://landscape.canonical.com * Support: https://ubuntu.com/advantage</pre>		
1) View IP Status 3) Restart Network 5) Logout 7) Shutdown 2) Ping 4) Reset Database 6) Reboot Please enter your choice: 3 Restart network will take a few seconds Network restart finished. Please enter your choice:		

 When the "preferred command" appears, please enter "No.3" to restart network command. (It will not be necessary if you cannot be connected to UNI-NMS Web UI.)



Logging in UNI-NMS

- Open Chrome to log in the UNI-NMS.
- Please use Chrome to get fully supported. (UI Resolution <u>1280 x 768</u>)





Logging in UNI-NMS

- Username: admin
- Password: admin

https://192.168.1.100	.8888 ×
	D https://192.168.1.100:8888
	Sign in https://192.168.1.100:8888 Username admin Password Sign in Cancel



Logging in UNI-NMS and Discovery

On the dashboard, press the "Domain" icon (No. 1), and then press Discovery (No. 2) and Search (No. 3) to find the managed APs and continue other settings.

		PLA Networking & C Universal	nemateritien NMS 2	14 Device(s) (Client(s) Grou	p (s)				3. 2 2 2 3
				Discov	rery Topolog	y View				Search Apply Filter by Model, MAC, IP
		Devi	ce List 🛛 🔊	Num.	MAC Addres	s Device Ty	pe Model No.	()	Version	Device IP Device Description
Dashbo	ard V	Venner Search:	Device Description							
UNI-NMS	× +									
	Not secure htt	ps:/								
me ystem Information				Event	Syslog 🔇	2019-07-05	>>			Search Q K « 1 /3 »
System Version	v1.0b181018			ID	Туре	Time	Source	Status	Device Type	Information
Management Port	8888			1	System	10:29:55	192.168.1.100	Login Failed	N/A	192.168.1.10
36.3%	6.9%			2	System	10:29:55	192.168.1.100	Login Failed	N/A	192.168.1.10
CPU Utilization	Disk Utilization			3	System	08:55:13	192.168.1.100	Connect	Wireless	WDAP-802AC 192.168.1.160 a8:f7:e0:00:01:0c
etwork Summary				4	System	08:55:13	192.168.1.100	Connect	Wireless	WBS-202N 192.168.1.161 a8:f7:e0:00:04:03
((<mark>†</mark>))	4	Mar		5	System	08:55:13	192 168 1 100	Connect	Wireless	WAP-552N 192 168 1 163 a8:f7:e0:3c:38:51
	0	AP 0.0000								
•	0	2.4GHz Clients					_			
	0	5GHz Clients			Th	nere is no client.				
					Online					
	0	SSID Profiles 2.4GHz Profiles			Disabled					



UNI-NMS – Adding Devices to List

Select devices (No. 1) by checking the boxes, and then press the "Apply" icon (No. 2) to add devices to management list.

	UNI-NM	5		×	+							- 0	×
←	→ C	1 (A	Not se	cure	https://192	.168.1.10) :8888					오 ☆	:
		ANET king & Communication ersal NMS		Devic	Ce(s) Client(s	O Group(s)	5)			0	❷ ♥	≜ \$ • ∦ • ⊖• (ტ -
					Discovery		Topology	View	Sea	rch Apply	Filter by Model, N	MAC, IP Q 10 (10256)	٢
	Devic	e List	\rightarrow	Num.	MAC Addre	ess De	evice Type	Model N	ło.	Version	Device IP	Device Description	
	\$	Search:	_	1	a8:f7:e0:16:	05:00 V	/ireless	WNAP-C3	220A	v1.3465cb17092	26 <u>192.168.0.4</u>	WNAP-C3220A	
_		ouron.		2	a8:f7:e0:4b:	34:26 V	/ireless	WS-2864	PVR	v1.440181029	192.168.1.200	PLANET WS-2864PVR AP Managed Switch	
	IP	Device Descripti	on	3	00:30:4f:00:	00:06	Switch	GS-5220-8	P2T2X	v2.440180914	192.168.1.201	PLANET GS-5220-8P2T2X L3 Managed Switch	•
				4	08:00:27:c4:	cc:2e	N/A	UNI-N	٨S	v1.0b181031	<u>192.168.1.100</u>	PLANET Controller	
				Even	t Syslog	2019-07-	05 >>>				Search	Q K « 1 3 »)	1
				ID	Туре	Time	S	ource	Status	Device Type	I	Information	^
				1	System	10:29:55	192.1	68.1.100	Login Failed	N/A	192	2.168.1.10	
				2	System	10:29:55	192.1	68.1.100	Login Failed	N/A	193	2.168.1.10	
				3	System	08:55:13	192.1	68.1. 1 00	Connect	Wireless	WDAP-802AC 192.1	168.1.160 a8:f7:e0:00:01:0c	

. .

Connect

Connect

Wireless

Wireless

WBS-202N 192.168.1.161 a8:f7:e0:00:04:03

WAP-552N 192 168 1 163 a8 f7 e0 3c 38 51

192.168.1.100

192 168 1 100

System

System

08:55:13

08:55:13



UNI-NMS – Device List and Topology View

Press "Topology View" to see the domain network topology after one minute.

%If you do not see the topology, please check devices to enable SNMP and LLDP function.





UNI-NMS – Device List and Topology View

- Press the "Double Arrow" icon (No. 1) to see the full managed devices information.
- Press the "Identification" icon (No. 2) to modify the device description, type, and web protocol information.

🔍 UNI-NMS X +							- a ×					
	(192.168.1.100:8888 4 0 0 Device(s) Client(s) Group(s)	🌏 U	NI-NMS		+		o ⊹ ≑ :			-		×
	Discovery Topo	← -	→ C ①	A Not secure	https://192.*	168.1.100:8888			e	\ ☆		6
Cervice Lia Cervice Lia Cervice Description 192.168.0.4 WINAP-G3220A PLANET (G-5/220.6829712X	- 1		PLANE Networking & Communi Universal NMS	Devic	e(s) Client(s)	O Group(s)			2 9 🚊 🌣 🖌	• ť	} •	ሆ -
192.168.1.201 L3 Managed Switch 192.168.1.200 PLANET WS-2864PVR AP Managed Switch 192.168.1.100 PLANET Controller												
		•					Device List					
		- Or		Disable					ilter by Context	0 (102	256)	۲
			Status AP Grou	MAC Address	Device Type	Model No.	Version	IP Address	Device Description 2.		Action	<u>~</u>
			•	a8:17:e0:16:05:00	vvireiess	WNAP-C3220A	V1.3465CD170926	192.168.0.4	WNAP-C3220A	20	C	
			N/A	00:30:4f:00:00:06	Switch	GS-5220-8P2T2X	v2.440180914	192.168.1.201	Managed Switch	666	Ĉ	茴
			N/A	a8:f7:e0:4b:34:26	Wireless	WS-2864PVR	v1.440181029	192.168.1.200	PLANET WS-2864PVR AP Managed Switch	10	ð	盦
			N/A	08:00:27:c4:cc:2e	N/A	UNI-NMS	v1.0b181031	192.168.1.100	PLANET Controller	66	d	盦
	-											
	_											
	_											
									Total: 4,	Offline:	1, On	line: 3



UNI-NMS – System Event

- Press the "Event" icon (No. 1) to see the full system event by day.
- Press the "<<"& ">>" icon (No. 2) to select daily report.



Total: 14, Offline: 1, Online: 13



UNI-NMS – System Event

• Use "search" to choose the information you want by entering the key word.





UNI-NMS – Syslog Server

- Press the "Syslog" icon (No. 1) to see the full syslog by day (Open the devices remote syslog function.).
- Press the "<<" & ">>" icon (No. 2) to select daily report.
- Press the "Drop-down " menu (No. 3) to select severity and device ID.





UNI-NMS – System Event

• Use Search to choose the information you want by entering the key word.

Event	Syslog 🔇	2019-07-	05 »> Severity: INFO	Device: Any	K≪ <mark>4</mark> .1 /10 ≫ >I	
					2864 Q]
ID	Severity	Time	Source	Information		
1	Informational	09:17:38	192.168.1.190	1970-01-01 Thu 00:25:01+00:00 [WS-2864PVR] LINK-UPD0 1/4, changed state to down.	OWN: Interface GigabitEthernet	
2	Informational	09:04:48	192.168.1.190	1970-01-01 Thu 00:12:11+00:00 [WS-2864PVR] LINK-UPD0 1/4, changed state to up.	OWN: Interface GigabitEthernet	
3	Informational	08:54:29	192.168.1.190	1970-01-01 Thu 00:01:51+00:00 [WS-2864PVR] LINK-UPD(1/10, changed state to up.	OWN: Interface GigabitEthernet	
4	Informational	08:54:29	192 168 1 190	1970-01-01 Thu 00:01:51+00:00 [WS-2864PVR] LINK-UPD	OWN: Interface GigabitEthernet 🚽	,



Software AP Controller

• Press the "AP control" icon (No. 1) to use AP control function.

***How to operate. Refer to SAPC user's manual :** "Configuration Guide"

	_	_			-			1		_	_	_	_	_
	Server	ANET king & Communication	1	4 1	0			[] ♀	@	Φ -		•	-	() .
	Univ	ersal NMS	Dev	ice(s) Client(s)	Group(s)									
Ж	Preferenc	e 🖉 Pro	ofiles 🗸 😧 Con	itrol 🗸 🍳	Map It 🕺	Statistics								
Hon	ne > Contro	ol > Managem	nent			1	- 💼 App	ly Filter by Contex	t	(ર િ	8 (825	6)	۲
	Online 🔴	Offline 🔘 Dis	able											
	Status	AP Group	MAC Address	Device Type	Model No.	Version	IP Address	Device Description			Ac	tion		
	•		8c:88:2b:00:00:46	Wireless	WNAP-W2201A	v1.3465cb170926	192.168.1.153	WNAP-W2201A	10	ð		÷,	Q	畲
	•		88:dc:96:5b:7c:2e	Wireless	WAP-500N	1.0.0.11	192.168.1.150	WAP-500N	99	C	Ŧ	÷	Ô	盦
	•		a8:f7:e0:00:01:0c	Wireless	WDAP-802AC	WDAP-802AC-AP-ETSI-V2.0- Build20181212153005	192.168.1.160		60	C	Ŧ	÷	Q	俞
	•		a8:f7:e0:00:04:03	Wireless	WBS-202N	WBS-202N-AP-FCC-V2.0- Build20190305155621	192.168.1.161		66	C	Ŧ	¢°	Q	盦
	•		a8:f7:e0:16:05:00	Wireless	WNAP-C3220A	1.3465cb171030	192.168.1.152	WNAP-C3220A	96	C	Ŧ	¢,	Ô	盦
	•		a8:f7:e0:16:05:0c	Wireless	WNAP-W2201A	1.3465cb171030	192.168.1.151	WNAP-W2201A	μļ	C	Ŧ	÷	Ô	盦
	•		a8:f7:e0:3c:38:51	Wireless	WAP-552N	WAP-552N-AP-FCC-V2.0- Build20181012155046	192.168.1.163	WAP-552N	919	ð	Ŧ	¢ ² ,	\bigcirc	â
	•		a8:f7:e0:48:f0:a4	Wireless	WNAP-C3220E	WNAP-C3220E-AP-ETST-V2.0- Build20181011112706	192.168.1.162		60	C	Ŧ	¢°	Q	盦



Total: 12, Offline: 1, Online: 11



Server Setting

- Press the "Maintenance" icon (No. 1) to make the system become Server Mode.
- Press the "Server Mode" icon (No. 2) to start setting to the Server mode and a pop-up window will display a warning message.

PLANET Neustaja E Committation Universal NMS	14 0 0 Device(s) Client(s) Group(s) 1.
Home > Maintenance > System Setting Current mode 2ent Set to Serve	ar Mode
Note: The agent mode is	s set in the system by default, but can be set to the server mode if wanted.
	192.168.1.100:8888 顯示
	Setting to UNI-NMS server mode will cause the configuration to disappear. You may need to back up the configuration first. Are you sure you want to change to UNI-NMS server mode?
	確定 取消



Server Setting

• Press the "OK" icon to start changing system to Server Mode.

🤹 uni-nms 🛛 🗙 🕂					-			×
← → C ☆ ▲ Not secure https	://192.168.1.100:8888			Q	1	7	•	
Universal NMS	4 0 0 evice(s) Client(s) Group(s)		0	2 ¢ • &	• (ሆ	•
Home > Maintenance > System Setting Current mode Agent Set to Server Mode				System Setting System Upgrade Backup / Restore Factory Default				
Note: Factory default will set	system mode to agent. The system mode can be re-define once a	igain	I.					
	192.168.1.100:8888 says							
	Set to UNI-NMS Server Mode will cause the configuration missing. You may need to backup configuration first. Do you sure change to UNI-NMS Server Mode?							
	3. OK Cancel							



Server Setting

- Press the "Site" icon (No. 1) to make the system become Server Mode.
- Press the "Add-New-Site" icon (No. 2) to add a different site to your network.

🤹 UNI-NMS 🛛 🗙	+	- 🗆 X
← → C ☆ ▲ Not secure	e https://192.168.1.100:8888	९ ☆ क़ :
PLANET Networking & Communication Universal NMS	0 0 0 0 Site(s) Site online Site offline Device(s)	2 1 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0
Sites List	Site Management	2.
	IP Address Usemane Password Site City	Description Contact Action



Adding a New Site

- Fill out the fields to build a new site.
- Press the "Apply" icon (No. 2) to add a new site.

🌏 UNI-NMS 🛛 🗙	+			– 🗆 X
← → C ☆ ▲ Not secure	https://192.168.1.100:8888			९ ☆ 歳 :
PLANET Identity Identity Identity Identity	000 Site(s) Site online Site offline I	O Device(s)		2 19 \$ • \$ • U •
Sites List	Site Management			2. Apply Back Reset
Generi			Add new site	
	IP Address	192.168.1.101		
	Web Protocol	OHTTP ●HTTPs		
	HTTPs Port	8888		
	Username	admin		
	Password	admin		
	Site Name	PLANET		
	City	New Taipei City		
	Description	Head Office		
	Contact			



Showing Different Statuses

- After adding a new site, wait for the system to be connected.
- The colored buttons show different statuses like:

Blue: connected

Red: disconnected

Gray: in connection

PLANET Networking & Communication Universal NMS	S	6 3 ite(s) Site online S	3 24 ite offline Device	(5)				@ 13 <	3- A	• 0	• U
Sites List	Site Manag	jement								6	
arch		IP Address	Usemame	Password	Site	City	Description	Contact		Action	
PLANET - AF		192.168.1.96	admin	admin	PLANET	Johannesburg	AF		86	2	畲
PLANET - CH		192.168.1.95	admin	admin	PLANET	Beijing	СН		100	2	Ê
DIANET EU		192.168.1.97	admin	admin	PLANET	Amsterdam	EU		60	ð	曲
PLANET-LU		192.168.1.100	admin	admin	PLANET	New Taipei City	Head Office		1010	8	Ê
PLANET - Head Office		192.168.1.99	admin	admin	PLANET	Tokyo	JP		1010	ð	龠
PLANET - JP		192.168.1.98	admin	admin	PLANET	San Francisco	US		100	2	Ô
PLANET - US											

• Press the colored button to see the detailed information.



Appendix 1: Checking Network Status

 UNI-NMS is set to the static IP: 192.168.1.100, so configure the network card to log in in the same network segment.

1 Network Connections	
$\leftarrow \ \ ightarrow \ \ \ \ \ \ \ \ \ \ \ \ $	
Contraction State of Receiver Connection Rename this connection Rename this connection Rename this connection State of the state of t	View status of this connection 乙太網路 2 網路 41 Generic Marvell Yukon 88E
Default gateway:	Sign in
C Obtain DNS server address automatically	https://192.168.1.100:8888
Use the following DNS server addresses: Preferred DNS server:	Username admin
Alternate DNS server:	Password
Validate settings upon exit Advanced	Sign in Cancel
OK Cancel	



Appendix 2: Upgrading System with Patch File

 Press the "Maintenance" icon to select "System Upgrade" to load patch file so as to upgrade UNI-NMS system.

Suni-NMS × C PLANET 802.11n Access Point × C PLANET 802.11n Access Point	× +	- 🗆 X
$\leftarrow \rightarrow \mathbf{C} \mathbf{\hat{\Delta}} \mathbf{A} \text{Not secure} \frac{\text{https:}}{192.168.1.100:8888}$		Q ☆ ≛ :
Universal IMMS 4 0 0 Device(s) Client(s) Group(s)		
Home > Maintenance > System Upgrade Current version V1.0b181031 File name Choose File No file chosen	Backup / Rest Factory Defau	lt



Appendix 2: Upgrading System with Patch File

 On System Upgrade screen, select "UNI-NMS_xxx.enc" patch file and then click the "System Upgrade" icon to start system upgrade.





Appendix 2: Upgrading System with Patch File

If System Upgrade is successful, Web UI will show "Upgrade finished."

Press the OK button to go to the Dashboard page.





Appendix 3: How to Shut Down the VM

Press the "Exit" icon and select "Shutdown" to shut down the

UNI-NMS system and VM; otherwise, it may cause the system to be abnormal at the next restart.

		Discov	ery Topolog	y View				Search	Apply Filter Reboot
Device	List 🔊	Num.	MAC Addres	s Device Ty	rpe Model No.		Version	Device IP	Device Description
Search:									
IP	Device Description								
192.168.1. <mark>1</mark> 53	WNAP-W2201A								
192.168.1.62	PLANET								
192.168.1.150	WAP-500N								
192.168.1.160									
192.168.1.161									
192.168.1.152	WNAP-C3220A	Event	Syslog 🔇	2019-07-05	>>			Search	Q K « 1 /3 »
192 168 1 151	WNAP-W2201A	ID	Туре	Time	Source	Status	Device Type		Information
		1	System	10:29:55	192.168. 1.1 00	Login Failed	N/A		192.168.1.10
		2	System	10:29:55	192.168.1.100	Login Failed	N/A		192.168.1.10
		3	System	08:55:13	192.168.1.100	Connect	Wireless	WDAP-802AC 1	92.168.1.160 a8:f7:e0:00:01:0c
		4	Quetom	08-55-13	102 168 1 100	Connect	Wireless	WBS-202N 192	2 168 1 161 a8 f7 e0:00:04:03



Appendix 3: Using VM to Shut Down the System

 Do Not select "Power Off" to shut down the VM; otherwise, it may cause the system to be abnormal at the next restart.





Appendix 4: Using VM to Shut Down the System

 Do Not select "Power Off" to shut down the VM; otherwise, it may cause the system to be abnormal at the next restart.





Appendix 5: VM Main Command Introduction

🜠 UNI-NMS_Agent [Running] - Oracle VM VirtualBox	_		×
File Machine View Input Devices Help			
Ubuntu 16.04.1 LTS UNI-NMS tty1			
UNI-NMS login: adminuser Password: Last login: Tue Oct 30 16:41:21 CST 2018 on tty1 Welcome to Ubuntu 16.04.1 LTS (GNU/Linux 4.4.0-79-generic i686)			
<pre>* Documentation: https://help.ubuntu.com * Management: https://landscape.canonical.com * Support: https://ubuntu.com/advantage</pre>			
1) View IP Status 3) Restart Network 5) Logout 7) Shutdown 2) Ping 4) Reset Database 6) Reboot			
Please enter your choice: 1 IP Address: 192.168.1.114 Netmask: 255.255.255.0 Gateway: 192.168.1.254 Please enter your choice: 2 Please input IP Address: 192.168.1.114 PING 192.168.1.114 (192.168.1.114) 56(84) bytes of data. 64 bytes from 192.168.1.114: icmp_seq=1 ttl=64 time=0.156 ms 64 bytes from 192.168.1.114: icmp_seq=2 ttl=64 time=0.127 ms	'est to e sam	ping e net	any work
64 bytes from 192.168.1.114: icmp_seq=3 ttl=64 time=0.125 ms 192.168.1.114 ping statistics 3 packets transmitted, 3 received, 0% packet loss, time 1999ms rtt min/aug/max/mdev = 0.125/0.136/0.156/0.014 ms Please enter your choice: 3 Restart network will take a few seconds .Network restart finished. Command 3.: Restart network.			
Please enter your choice: 4 [WARRING] All the configuration will lose. System will reboot at the end of reset. s: 192.168.1.100 Do you wish to reset database to default? [N/y] Command 4.: Reset database.	Defaul [WA	t IP f RNIN	Addres G]



ACTIVATING IP POWER

www.planet.com.tw