

**L3 24-Port 10/100/1000T 802.3bt + 2-Port 10GBASE-T  
+ 2-Port 10G SFP+ Managed Switch with Dual Modular  
Power Supply Slots**

**GS-6322 Switch Series**

**Quick Installation Guide**

# Table of Contents

1. Package Contents .....	3
2. Requirements .....	4
2.1 Power Requirements .....	4
3. Terminal Setup .....	6
3.1 Logging on to Console .....	7
3.2 Configuring IP Address.....	8
4. Starting Web Management .....	10
4.1 Logging in to the Managed PoE Switch .....	10
4.2 Saving Configuration via Web .....	12
5. Recovering Back to Default Configuration.....	13
6. Power Operation Mode Management.....	14
7. Customer Support .....	16

## 1. Package Contents

Thank you for purchasing PLANET L3 Multiple Gigabit + 4-Port 10G Managed Switch with dual modular power supply slots. The description of this model is shown below:

Model Name	PoE Ports	10G RJ45	10G SFP+	PoE Budget
GS-6322-24P4X	24-Port 802.3bt	2	2	Depended on power supply

“**Managed PoE Switch**” is used as an alternative name in this Quick Installation Guide.

Open the box of the Managed PoE Switch and carefully unpack it. The box should contain the following items:

- The Managed PoE Switch
- Quick Installation Guide
- RJ45 to RS232 Cable
- Rubber Feet
- Two Rack-mounting Brackets with Attachment Screws
- SFP Dust-proof Cap x 2

If any of these pieces are missing or damaged, please contact your dealer immediately; if possible, retain the carton including the original packing material, and use them again to repack the product in case there is a need to return it to us for repair.

## 2. Requirements

- Workstations running Windows 10/XP/2003/Vista/7/8/2008, MAC OS X or later, Linux, UNIX, or other platforms are compatible with TCP/IP protocols.
- **Serial Port Connection** (Terminal)
  - The above Workstations come with **RS232 COM Port** (DB9) or USB-to-RS232 converter.
  - The above Workstations have been installed with **terminal emulator**, such as Hyper Terminal included in Windows XP/2003.
  - Serial cable -- one end is attached to the RS232 serial port, while the other end to the console port of the Managed PoE Switch.
- **Ethernet Port Connection**
  - Workstations are installed with Ethernet NIC (Network Interface Card)
  - Network cables -- Use standard network (UTP) cables with RJ45 connectors.
  - The above PC is installed with **Web browser**.




### Note

It is recommended to use Internet Explorer 8.0 or above to access the Managed PoE Switch. If the Web interface of the Managed PoE Switch is not accessible, please turn off the anti-virus software or firewall and then try it again.

### 2.1 Power Requirements

The GS-6322-24P4X is designed with two modular power supply slots. It can work with three optional 920W/1200W/2000W AC power supplies. The final package of switch and power supplies will depend on your purchase. It doesn't install a power supply by default. Please contact your local distributor or retailer for confirming your purchase package.

Modular Power Supply	Maximum Power Output	Power Connector
PWR-CRPS920	920W (100-240 VAC)	 IEC C16, max. 12A
PWR-CRPS1200	1200W (220-240 VAC)	
PWR-CRPS2000	2000W (220-240 VAC)	

For compatibility with electrical voltages in most areas of the world, the Managed PoE Switch's modular power supply can automatically adjust line power in the range of 100-240V AC and 50/60 Hz. However, if you'd like to have maximum power output, it's required specific power input.

Plug the female C15 end of the power cord firmly into the receptacle on the rear panel of the Managed PoE Switch and the other end of the power cord into an electrical outlet and the power will be ready.

The GS-6322-24P4X is also equipped a power eject button for safe operations and indications of power supplies.



**Figure 2-1:** Power eject button




Caution

To ensure system normal operation, do not remove power supply before starting power ejection button. Please refer to user manual for standard operation procedures.

### 3. Terminal Setup

To configure the system, connect a serial cable to a **RS232 COM** port on a PC or notebook computer and to RJ45 type of serial port of the Managed PoE Switch.



**Figure 3-1:** Managed PoE Switch Console Connectivity

A terminal program is required to make the software connection to the Managed PoE Switch.

1. Run terminal program on the OS.
2. When the following screen appears, make sure that the COM port should be configured as:
  - Baud: 115200
  - Data bits: 8
  - Parity: None
  - Stop bits: 1
  - Flow control: None




**Figure 3-2:** COM Port Configuration

### 3.1 Logging on to Console

Once the terminal is connected to the device, power on the Managed PoE Switch, and the terminal will display “running testing procedures”. Then, the following message asks to log in user name and password. The factory default user name and password are shown as follows and the login screen in Figure 3-3 appears.

Username: **admin**  
Password: **admin**



**Figure 3-3:** Managed PoE Switch Console Login Screen

The user can now enter commands to manage the Managed PoE Switch. For a detailed description of the commands, please refer to the following chapters.



#### Note

1. For security reason, please change and memorize the new password after this first setup.
2. Only accept command in lowercase letter under console interface.

## 3.2 Configuring IP Address


The Managed PoE Switch is shipped with default IP address shown below.

```
IP Address: 192.168.0.100  
Subnet Mask: 255.255.255.0
```

To check the current IP address or modify a new IP address for the Switch, please use the procedures as follows:

### ■ Show the current IP Address

1. At the “#” prompt, enter “**show ip interface brief**”.
2. The screen displays the current IP address as shown in Figure 3-4.



```
COM4 - Tera Term VT  
File Edit Setup Control Window Help  
Switch# show ip interface brief  
Interface Address Method Status  
-----  
VLAN 1 192.168.0.100/24 Manual UP  
Switch#
```

Figure 3-4: IP Information Screen


### ■ Configuring IP Address

3. At the “#” prompt, enter the following command and press **<Enter>** as shown in Figure 3-5.

```
Switch# configure terminal  
Switch(config)# interface vlan 1  
Switch(config-if-vlan)# ip address 192.168.1.100 255.255.255.0
```

The previous command would apply the following settings for the Managed PoE Switch.

IP Address: **192.168.1.100**  
Subnet Mask: **255.255.255.0**



```
COM4 - Tera Term VT
File Edit Setup Control Window Help
Switch#
Switch# configure terminal
Switch(config)# interface vlan 1
Switch(config-if-vlan)# ip address 192.168.1.100 255.255.255.0
Switch(config-if-vlan)# exit
Switch(config)#
```

Figure 3-5: Configuring IP Address Screen

4. Repeat step 1 to check if the IP address has changed.

### ■ Store current switch configuration

5. At the “#” prompt, enter the following command and press <Enter>.

**# copy running-config startup-config**



```
COM4 - Tera Term VT
File Edit Setup Control Window Help
Switch#
Switch# copy running-config startup-config
Building configuration...
do not reset or power off the device!
% Saving 3408 bytes to flash:startup-config
Switch#
```

Figure 3-6: Saving Current Configuration Command Screen

If the IP is successfully configured, the Managed PoE Switch will apply the new IP address setting immediately. You can access the Web interface of the Managed PoE Switch through the new IP address.



Note

If you are not familiar with the console command or the related parameter, enter “**help**” anytime in console to get the help description.

## 4. Starting Web Management

The following shows how to start up the **Web Management** of the Managed PoE Switch. Note the Managed PoE Switch is configured through an Ethernet connection. Please make sure the manager PC must be set to the same **IP subnet address**.

For example, the default IP address of the Managed PoE Switch is **192.168.0.100**, then the manager PC should be set to **192.168.0.x** (where x is a number between 1 and 254, except 100), and the default subnet mask is 255.255.255.0.




Figure 4-1: IP Management Diagram

### 4.1 Logging in to the Managed PoE Switch

1. Use Internet Explorer 8.0 or above Web browser and enter IP address **<https://192.168.0.100>** (the factory default IP address or the one that you have just changed in console) to access the Web interface.
2. When the following dialog box appears, please enter the default user name and password "**admin**" (or the password you have changed via console). The login screen in Figure 4-2 appears.

Default IP Address: 192.168.0.100  
Default Username: **admin**  
Default Password: **admin**

The screenshot shows a web browser dialog box titled "Authentication required" for the URL "http://192.168.0.100". Below the title, it states "Your connection to this site is not private". There are two input fields: "Username" and "Password". At the bottom, there are two buttons: "Log in" and "Cancel".

Figure 4-2: Login Screen

3. After entering the password, the main screen appears as Figure 4-3 shows.



Figure 4-3: Web Main Screen of Managed PoE Switch

4. The Switch Menu on the top of the Web page lets you access all the commands and statistics the Industrial Managed Switch provides. The Switch Menu always contains one or more buttons, such as **“System”**, **“Switching”**, **“Routing”**, **“QoS”**, **“Security”**, **“PoE”**, **“Ring”**, **“ONVIF”** and **“Maintenance”**.



Figure 4-4: Switch Menu

Now, you can use the Web management interface to continue the Switch management. Please refer to the user manual for more.



If you are not familiar with Switch functions or the related parameter, press **“Help icon”** anytime on the Web page to get the help description.

## 4.2 Saving Configuration via Web

To save all applied changes and set the current configuration as a startup configuration, the startup-configuration file will be loaded automatically across a system reboot.


1. Click the **Save** icon on the top Switch Menu bar.



2. Press the **"Save Configuration"** button.



3. Or the other way to save the setting is to Click **Maintenance, Save Startup Config**.



## 5. Recovering Back to Default Configuration

### ■ IP address has been changed or admin password has been forgotten –

To reset the IP address to the default IP address “**192.168.0.100**” or reset the login password to default value, press the hardware-based **reset button** on the rear panel for about **10 seconds**. After the device is rebooted, you can log in the management Web interface within the same subnet of 192.168.0.xx.




Figure 5-1: GS-6322-24P4X Reset Button

## 6. Power Operation Mode Management

The GS-6322-24P4X is designed with two extractive modular power supply slots to support Redundant Power Supply (**RPS**) mode or Extended Power Supply (**EPS**) mode via software setting to handle the demands of power redundancy or additional power to PoE++ ports as needed.

- **RPS (1+1)** mode: Where critical services are supported by PoE application, the secondary PSU is needed to provide backup power in the event of a power outage.
- **EPS (2+0)** mode: Where more PoE budget is required to support complete application, the secondary PSU can provide additional PoE power. The two PSUs combined are able to provide a maximum of total PoE power.

Users can choose one or dual power supplies with the initial installation.

Power Module Operation Mode	PoE Budget with One 1200W PSU	PoE Budget with Two 1200W PSUs	Power Redundancy
RPS mode (1+1)	1000W	1000W	Yes
EPS mode (2+0)	1000W	2200W	-

Example on power supply: PWR-CRPS1200

The factory default power configurations are shown as follows.

Default Power Module Operation Mode: **RPS**

You can use the Web management interface and then **System > Power Management** to change the power configuration.



## Power Configuration

<b>Power Module Operation Mode</b>	EPS mode(2+0) ▾
	<b>RPS mode:</b> Provides 1+1 power redundancy when two PSUs are installed. Power budget is the same as that of one PSU. <b>EPS mode:</b> Provides double power budget by combining two PSUs to share the maximum power budget.
<b>Number of PSUs</b>	2
<b>Effective Number of PSUs</b>	2
<b>PSU Status</b>	Slot 1: Operational
	Slot 2: Operational
<b>RPS mode(1+1) Active</b>	No

**Figure 6-2:** Power Configuration web page

Please refer to the user's manual for more.

## 7. Customer Support

Thank you for purchasing PLANET products. You can browse our online FAQ resource and User's Manual on PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET switch support team.

PLANET online FAQs:

<https://www.planet.com.tw/en/support/faq>

Switch support team mail address:

[support@planet.com.tw](mailto:support@planet.com.tw)

GS-6322 Series User's Manual:

<https://www.planet.com.tw/en/support/downloads?method=keyword&keyword=GS-6322>



(Please select your switch model name from the drop-down menu of Product Model.)

Copyright © PLANET Technology Corp. 2020.

Contents are subject to revision without prior notice.

PLANET is a registered trademark of PLANET Technology Corp.

All other trademarks belong to their respective owners.