













STEP 4: Verifying the Installation

After power on the EPN-102/EPN-104, the Power LED will be bright. When system is ready, the PON LED will be flash. If the PON connection is ready, the PON LED will be off and Link

If the PON connection is ready, the PON LED will be off and Link LED is ON. And then you can enjoy the high bandwidth connection via PON technology.

10/100 1000

PWR Link PON FE GE

Note: Please refer to the User's Manual in CD-ROM for more information.

