





Copyright

Copyright © PLANET Technology Corp. 2010. All rights reserved. No part of this publication may be

reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or

computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical,

manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the

contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular

purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove

defective following their purchase, the buyer (and not PLANET, its distributor, or its dealer) assumes

the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting

from any defect in the software. Further, PLANET reserves the right to revise this publication and to

make changes from time to time in the contents hereof without obligation to notify any person of such

revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of

their respective holders.

**FCC Caution** 

This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference when the equipment is operated in a commercial environment. This

equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in

accordance with the Instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case

the user will be required to correct the interference at whose own expense.

**CE Mark Warning** 

This is a Class B product. In a domestic environment, this product may cause radio interference in

which case the user may be required to take adequate measures.

Revision

User's Manual for PLANET PCI Express Dual/Single Port 10 Gigabit Ethernet Adapter

For Models: ENW-9800 / 9801

Revision: 1.1 (January.2010)

Part No. EM-ENW9800\_9801v1.1 (2080-A14090-001)

2

# **Table of Contents**

CHAPTER 1	INTRODUCTION	1		
1.1 Dookogo	Content	1		
	Content			
	Tools and Documentations			
	HARDWARE INSTALLATION			
2.1 LED defin	nitions	2		
2.2 Hardware	Installation	3		
CHAPTER 3	DRIVER INSTALLATION	4		
3.1 Installing	Driver to Windows Server 2003/2003R2	4		
3.2 Installing	VLAN Support Driver To Windows Server 2003/2003R2	7		
CHAPTER 4 SPECIFICATIONS11				

### **Chapter 1 Introduction**

Meet the next gerneration interface - PCI Express dual / single port 10 Gigabit Ethernet adapter can provide the best solution for one of the major issues of Local Area Networks - communication speed. Hundred times as fast as the existing 100Base-TX solutions, using the PLANET ENW-9800 / 9801 to connect your servers and workstations guarantees extremely high throughput and excellent signal quality.

The ENW-9800 / 9801 is a PCI Express dual / single port 10 Gigabit Ethernet adapter designed to address high-performance system application requirements. With the higher bandwitdh of x8, x4 PCI Express Bus Architecture, ENW-9800 / 9801 can provide better performance than the network cards which base on 32/64bit PCI architecture. It is specifically designed to allow throughput at rates up to 2.5Gbps, thus eliminating the existing 32/64bit PCI network card.

#### 1.1 Package Content

Check that your package contains the following items:

- √ 1 x 10G Ethernet Adapter
- √ 1 x Quick Installation Guide
- √ 1 x CD-ROM Manual / Driver

Please contact the seller if any of the items is missing or damaged.



Be sure to retain your proof of purchase, as it is required to receive warranty service.

#### 1.2 Features

- ➤ Compliant with PCI Express 1.1 x8 PCI Express standard
- ➤ Supports IEEE 802.3ae, IEEE 802.3x, IEEE 802.1Q VLAN.
- Integrated Frame Buffer Memory for Dual TX 32KB and Dual RX 64KB.
- Supports Jumbo Frame up to 16K
- > IP, TCP and UDP checksum offload

#### 1.3 Gathering Tools and Documentations


To install the adapter, you need the following items:

- ✓ A suitable screw driver
- ✓ Your operating system documentation
- ✓ Your system unit documentation, including any service documentation

## **Chapter 2 Hardware Installation**

#### 2.1 LED definitions

The faceplate of ENW-9800 has two LEDs: 100, 1000 and ACT. The pictures below have showed the faceplate of ENW-9800. Table 2-1 explains the function and state of the LED.



Faceplate of ENW-9800

The faceplate of ENW-9801 has one LED: 100, 1000 and ACT. The pictures below have showed the faceplate of ENW-9801. Table 2-1 explains the function and state of the LED.




Faceplate of ENW-9801

LED	Description
Link	Lights to indicate a functional network link through the port.
Act	Blinks to indicate data has been sending and receiving via the
Act	port.

Table 2-1 Descriptions of ENW-9800 / 9801 LED

#### 2.2 Hardware Installation

- Step 1: Please turn off your PC.
- **Step 2**: Remove any metal decorations from your hands and wrists.
- Step 3: Remove the cover from your PC.
- **Step 4**: Locate an empty PCI Express slot and remove the corresponding back plate. Save the screw for use in Step 6.
- **Step 5**: Carefully insert the adapter into the chosen slot and press firmly with proper push to ensure it is fully seated in the slot.



- **Step 6**: Secure the adapter with the screw you saved in step 4.
- Step 7: Replace the PC cover.
- **Step 8**: Power on the PC and refer to next chapter to install the driver of this adapter.

## **Chapter 3 Driver Installation**

A device driver must be installed before your ENW-9800/9801 can be used with your computer. This chapter describes how to install the driver for various operating systems. Before you begin the driver installation process, make sure you have the installation disks for your computer's operation system.


#### 3.1 Installing Driver to Windows Server 2003/2003R2



The following installation uses ENW-9801 and operates under Window2003R2. Procedures will be similar to Window Server 2003 and ENW-9800.

The ENW-9800 installation procedure is the same with ENW-9801.

- 1. Install ENW-9801 into your PC's PCI Express slot.
- 2. Power on the PC and insert Driver Disk into CD-ROM drive.
- Windows 2003R2 will detect ENW-9801 and ask you to install driver. Please select the second option and click "Next".



4. Please select "Include this location in the search" and then click "Browse" to specify ENW-9801 driver location to install. (Assume "E" is your CD-ROM drive, you can find ENW-9801 driver in E:\planet\_NIC10G\3.23\drivers\ENW-9801\W2003R2). Please click "Next" to continue.



5. Win2003R2 will show you this dialog box to prompt you the driver is not digitally signed by Microsoft, please press "Continue Anyway" to continue.



6. Please click "Finish" to complete the driver installation.



### 3.2 Installing VLAN Support Driver to Windows Server 2003/2003R2




The following installation uses ENW-9801 and operates under Window2003R2.

Procedures will be similar to Window Server 2003 and ENW-9800.


The ENW-9800 installation procedure is the same with ENW-9801.

.


1. Open Network Connection properties by Start\Settings\Control Panel\Network Connections then click "Install" Button.



2. Select "Protocol" and click "Add" button




3. In "Select Network Protocol" window click "Have Disk" Button



4. Press "Browse" to specify ENW-9801 VLAN driver location to install. (Assume "E" is your CD-ROM drive, you can find ENW-9801 driver in E:\planet\_NIC10G\3.23\tools\vlan\W2003). Please click "OK" to continue.




In "Select Network Protocol" window select "PLANET 10GbE Server Adapter VLAN Protocol Driver"



6. Win2003R2 will show you this dialog box to prompt you the driver is not digitally signed by Microsoft, Pease press "Continue Anyway" to continue.



Wait a moment or more until "Select Network Protocol" window is closed and installation is completed



# **Chapter 4 Specifications**

Product	ENW-9800	ENW-9801	
Hardware Specification			
Attachment Interface	PCI Express Host Bus Interface, 8 lanes / 4 lanes PCI Express Rev 1.1a		
Media Interface	2 SFP+ connectors (SFF-8431)	1 SFP+ connector (SFF-8431)	
Optical Module Options	LRM, LR, SR		
Cabling Options	SFP+		
Memory	3Mb internal memory		
Jumbo Frame	9K/16Kbytes		
LED Indicators	Link / Active per port		
Typical Power Dissipation	10W		
Dimension ( W x D)	147 x 63.5 mm (Low Profile)		
Advanced Function			
Layer 2 Features	IEEE 802.3x flow control support     IEEE 802.1Q VLAN support     Multicast ACL		
Performance enhancements	<ul> <li>Microsoft Scalable Networking</li> <li>Receive-side scaling (RSS): Optimization for multiple CPUs under Windows OS control</li> <li>Reduced host bus traffic</li> <li>Optimization for multiple CPUs</li> <li>IP acceleration</li> <li>Widely used network protocol</li> <li>IP, TCP and UDP checksum offloading</li> <li>Large Send (up to 64 KB): Increased network throughput</li> <li>IPv4, IPv6</li> </ul>		
OS Support	<ul> <li>Windows Server 2003, Windows Server 2008</li> <li>Windows XP, Windows Vista™, Windows 7</li> <li>Linux 2.4, Linux 2.6, Linux 64-bit</li> <li>Redhat Enterprise Linux 4.7 &amp; 5.3</li> <li>VMware® ESX 3.5</li> <li>Multiple queues management</li> <li>Windows Management Interface (WMI)</li> </ul>		
Standards Conformance			
Regulation Compliance	FCC Part 15 Class B, CE		
Standards Compliance	IEEE Std 802.3ae: 10Gb/s Ethernet IEEE 802.3x: Flow Control and Back pressure IEEE 802.1Q: VLAN Tagging		
Environment			
Operating	Temperature: 0 ~ 65 Deg Relative Humidity: 5 ~ 95% (n	ree C on-condensing)	
Storage	Temperature: -10 ~ 85 D Relative Humidity: 5 ~ 95% (n	egree C on-condensing)	



## **EC Declaration of Conformity**

For the following equipment:

\*Type of Product : Dual 10G SFP+ Server Adapter

\*Model Number : ENW-9800

\* Produced by:

Manufacturer's Name : Planet Technology Corp.

Manufacturer's Address : 11F, No. 96, Min Chuan Road, Hsin Tien,

Taipei, Taiwan, R.O.C.

is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directive on (2004/108/EC).

For the evaluation regarding the EMC, the following standards were applied:

	Emission	EN 55022	(2006)
	Harmonic	EN 61000-3-2	(2006)
	Flicker	EN 61000-3-3	(1995 + A1:2001 + A2:2005)
	Immunity	EN 55024	(1998 + A1:2001 + A2:2003)
	ESD	IEC 61000-4-2	(1995 + A1:1998 + A2:2000)
	RS	IEC 61000-4-3	(2006)
	EFT/ Burst	IEC 61000-4-4	(2004)
	Surge	IEC 61000-4-5	(2005)
	CS	IEC 61000-4-6	(2007)
	Magnetic Field	IEC 61000-4-8	(1993 + A1:2000)
	Voltage Disp	IEC 61000-4-11	(2004)

Responsible for marking this declaration if the:

Authorized representative established within the EU (if applicable):

Company Name: Planet Technology Corp.

Company Address: 11F, No.96, Min Chuan Road, Hsin Tien, Taipei, Taiwan, R.O.C

Person responsible for making this declaration

Name, Surname Kent Kang

Position / Title : <u>Product Manager</u>

Taiwan 9<sup>th</sup>, July, 2009

Place Date

Legal Signature



## **EC Declaration of Conformity**

For the following equipment:

\*Type of Product : 10G SFP+ Server Adapter

\*Model Number : ENW-9801

\* Produced by:

Manufacturer's Name : Planet Technology Corp.

Manufacturer's Address : 11F, No. 96, Min Chuan Road, Hsin Tien,

Taipei, Taiwan, R.O.C.

is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directive on (2004/108/EC).

For the evaluation regarding the EMC, the following standards were applied:

	Emission	EN 55022	(2006)
	Harmonic	EN 61000-3-2	(2006)
	Flicker	EN 61000-3-3	(1995 + A1:2001 + A2:2005)
	Immunity	EN 55024	(1998 + A1:2001 + A2:2003)
	ESD	IEC 61000-4-2	(1995 + A1:1998 + A2:2000)
	RS	IEC 61000-4-3	(2006)
	EFT/ Burst	IEC 61000-4-4	(2004)
	Surge	IEC 61000-4-5	(2005)
	CS	IEC 61000-4-6	(2007)
	Magnetic Field	IEC 61000-4-8	(1993 + A1:2000)
	Voltage Disp	IEC 61000-4-11	(2004)

Responsible for marking this declaration if the:

Authorized representative established within the EU (if applicable):

Company Name: Planet Technology Corp.

Company Address: 11F, No.96, Min Chuan Road, Hsin Tien, Taipei, Taiwan, R.O.C

Person responsible for making this declaration

Name, Surname Kent Kang

Position / Title : <u>Product Manager</u>

Taiwan 1<sup>th</sup>, Feb. 2010

Place Date

egal Signature