

# **48-Port ADSL 2/2+ IP DSLAM**

IDL-4802 / IDL-4802-48

---

## **User's Manual**

---

## **Copyright**

Copyright (C) 2009 PLANET Technology Corp. All rights reserved.

The products and programs described in this User's Manual are licensed products of PLANET Technology, This User's Manual contains proprietary information protected by copyright, and this User's Manual and all accompanying hardware, software, and documentation are copyrighted.

No part of this User's Manual may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form by any means by electronic or mechanical. Including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, and without the prior express written permission of PLANET Technology.

## **Disclaimer**

PLANET Technology does not warrant that the hardware will work properly in all environments and applications, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose.

PLANET has made every effort to ensure that this User's Manual is accurate; PLANET disclaims liability for any inaccuracies or omissions that may have occurred.

Information in this User's Manual is subject to change without notice and does not represent a commitment on the part of PLANET. PLANET assumes no responsibility for any inaccuracies that may be contained in this User's Manual. PLANET makes no commitment to update or keep current the information in this User's Manual, and reserves the right to make improvements to this User's Manual and/or to the products described in this User's Manual, at any time without notice.

If you find information in this manual that is incorrect, misleading, or incomplete, we would appreciate your comments and suggestions.

## **FCC Warning**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## **FCC Caution**

To assure continued compliance (example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

## **CE mark Warning**

The is a class A device, In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## **Trademarks**

The PLANET logo is a trademark of PLANET Technology. This documentation may refer to numerous hardware and software products by their trade names. In most, if not all cases, these designations are claimed as trademarks or registered trademarks by their respective companies.

## **WEEE Warning**



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

## **Safety**

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

## **Revision**

User's Manual for PLANET 48-Port ADSL 2/2+ IP DSLAM

Model: IDL-4802 / IDL-4802-48

Rev: 1.0 (Mar. 2009)

Part No.: EM-IDL4802\_v1

## Table of Contents

<b>Introduction</b> .....	<b>15</b>
<b>1.1 Product Features</b> .....	<b>15</b>
<b>1.2 Package Contents</b> .....	<b>16</b>
<b>1.3 Application</b> .....	<b>17</b>
<b>1.4 Outlook</b> .....	<b>18</b>
1.4.1 Front Panel .....	18
1.4.2 Rear Panel.....	19
<b>1.5 Technical Specifications</b> .....	<b>20</b>
<b>Installation</b> .....	<b>22</b>
<b>2.1 Safety Instruction</b> .....	<b>22</b>
<b>2.2 Hardware Installation</b> .....	<b>23</b>
2.2.1 System Requirements .....	23
2.2.2 Installation Procedure .....	24
<b>2.3 WEB Configuration</b> .....	<b>34</b>
2.3.1 System Preparation .....	34
2.3.2 WEB Configuration Procedure.....	35
2.3.3 How to backup / Restore the Configuration .....	40
2.3.4 Firmware Update .....	50
<b>Software Introduction</b> .....	<b>53</b>
<b>3.1 General Overview</b> .....	<b>53</b>
3.1.1 Features of Management Interface.....	54
<b>3.2 Configuration Management</b> .....	<b>55</b>
3.2.1 Bridge Configuration .....	55
3.2.2 ADSL Configuration .....	56
<b>3.3 Performance management</b> .....	<b>57</b>
3.3.1 RMON Feature .....	59
<b>3.4 Fault Management</b> .....	<b>60</b>
<b>3.5 Loopback Testing</b> .....	<b>62</b>
<b>3.6 Cluster Feature</b> .....	<b>63</b>
<b>WEB Management</b> .....	<b>64</b>
<b>4.1 System</b> .....	<b>70</b>
4.1.1 System Information.....	70
4.1.2 Board IP Setup .....	71
4.1.3 Ethernet Port Service .....	72
4.1.4 ADSL Port Service .....	73
4.1.5 CLI Setup.....	75
4.1.6 Cluster Setup.....	76
4.1.7 System Inventory .....	80
4.1.8 System Contact Info .....	81
4.1.9 SNTP .....	82
4.1.10 IP Routes.....	83
4.1.11 User Administration.....	84
4.1.12 Duplicator .....	86
<b>4.2 Bridge</b> .....	<b>87</b>
4.2.1 Interface Setup .....	87
4.2.2 VLAN Configuration.....	96
4.2.3 Spanning Tree .....	104
4.2.4 Access Control.....	108
4.2.5 Forwarding.....	134
4.2.6 Relay .....	136
4.2.7 IGMP .....	138

4.2.8 IPOA .....	145
<b>4.3 ADSL .....</b>	<b>147</b>
4.3.1 Profile .....	147
4.3.2 Data & Inventory .....	155
4.3.3 Line Config & Info .....	162
<b>4.4 Traffic .....</b>	<b>164</b>
4.4.1 ATM Traffic Descriptor .....	164
<b>4.5 SNMP .....</b>	<b>166</b>
4.5.1 SNMP Community .....	166
4.5.2 SNMP Target .....	167
4.5.3 SNMP Notify .....	168
<b>4.6 Maintenance .....</b>	<b>169</b>
4.6.1 SYS Log Server .....	169
4.6.2 Database .....	170
4.6.3 Firmware Update .....	178
4.6.4 ATM Loopbacks .....	181
4.6.5 Fault Management.....	182
4.6.6 Performance Monitoring .....	187
<b>CLI Command Reference .....</b>	<b>204</b>
<b>5.1 Global Commands.....</b>	<b>209</b>
5.1.1    bye .....	209
5.1.2    cluster .....	209
5.1.3    cluster local .....	209
5.1.4    disable.....	209
5.1.5    end .....	209
5.1.6    exit .....	209
5.1.7    help .....	210
5.1.8    list.....	210
5.1.9    list opmode.....	210
5.1.10   system contact .....	210
5.1.11   system location .....	210
5.1.12   system name.....	211
5.1.13   system restart.....	211
<b>5.2 Initialize Mode Commands.....</b>	<b>212</b>
5.2.1    enable .....	212
5.2.2    show license .....	212
5.2.3    show time .....	212
5.2.4    show uptime .....	212
5.2.5    show version .....	212
<b>5.3 Enable Mode Commands .....</b>	<b>213</b>
5.3.1    configure .....	213
5.3.2    ping .....	213
5.3.3    show access-list bcrate .....	213
5.3.4    show access-list dstip .....	213
5.3.5    show access-list dstmac .....	214
5.3.6    show access-list ethertype .....	214
5.3.7    show access-list ip-allowed .....	214
5.3.8    show access-list ipprotocol .....	214
5.3.9    show access-list l4dstport .....	215
5.3.10   show access-list mcfldrate .....	215
5.3.11   show access-list srcip .....	215
5.3.12   show access-list srcmac .....	215

5.3.13	show account .....	216
5.3.14	show aging .....	216
5.3.15	show alarm current.....	216
5.3.16	show alarm event.....	216
5.3.17	show alarm history .....	216
5.3.18	show alarm aco .....	216
5.3.19	show atmdesc .....	216
5.3.20	show atm-loopback .....	217
5.3.21	show cli-config.....	217
5.3.22	show cluster .....	217
5.3.23	show cpu .....	217
5.3.24	show dsl-line-identify .....	217
5.3.25	show fdb.....	217
5.3.26	show fdbstatic .....	218
5.3.27	show firmware .....	218
5.3.28	show help .....	218
5.3.29	show http.....	218
5.3.30	show igmp .....	218
5.3.31	show igmp group.....	219
5.3.32	show igmp rtpport.....	219
5.3.33	show igmp-acl bind gigabit.....	219
5.3.34	show igmp-acl bind gigabit la .....	220
5.3.35	show igmp-acl bind xdsl .....	220
5.3.36	show interface xdsl {all   <port>} adsl carrier fe ds snr .....	220
5.3.37	show interface xdsl {all   <port>} adsl carrier fe ds qln .....	220
5.3.38	show interface xdsl {all   <port>} adsl carrier fe ds hlin .....	221
5.3.39	show interface xdsl {all   <port>} adsl carrier fe ds hlog .....	221
5.3.40	show interface xdsl {all   <port>} adsl carrier fe us load .....	221
5.3.41	show interface xdsl {all   <port>} adsl carrier fe us gain .....	221
5.3.42	show interface xdsl {all   <port>} adsl carrier fe us tss .....	222
5.3.43	show interface xdsl {all   <port>} adsl carrier ne us snr .....	222
5.3.44	show interface xdsl {all   <port>} adsl carrier ne us qln .....	222
5.3.45	show interface xdsl {all   <port>} adsl carrier ne us hlin .....	223
5.3.46	show interface xdsl {all   <port>} adsl carrier ne us hlog .....	223
5.3.47	show interface xdsl {all   <port>} adsl carrier ne ds load .....	223
5.3.48	show interface xdsl {all   <port>} adsl carrier ne ds gain .....	223
5.3.49	show interface xdsl {all   <port>} adsl carrier ne ds tss .....	224
5.3.50	show interface xdsl {all   <port>} adsl channel .....	224
5.3.51	show interface xdsl {all   <port>} adsl failure .....	224
5.3.52	show interface xdsl {all   <port>} adsl line .....	224
5.3.53	show interface xdsl {all   <port>} adsl line config.....	225
5.3.54	show interface xdsl {all   <port>} adsl line delt-test.....	225
5.3.55	show interface xdsl {all   <port>} adsl line information.....	225
5.3.56	show interface xdsl {all   <port>} adsl inventory .....	225
5.3.57	show interface xdsl {all   <port>} adsl operational .....	226
5.3.58	show interface xdsl {all   <port>} bridge .....	226
5.3.59	show interface xdsl {all   <port>} cellcount .....	226
5.3.60	show interface xdsl {all   <port>} counter .....	226
5.3.61	show interface xdsl {all   <port>} ipoa.....	227
5.3.62	show interface xdsl {all   <port>} vc.....	227
5.3.63	show interface xdsl {all   <port>} vlan .....	227
5.3.64	show interface bridge .....	227

5.3.65	show interface counter .....	227
5.3.66	show interface gigabit [<port>] bridge .....	228
5.3.67	show interface gigabit [<port>] counter .....	228
5.3.68	show interface gigabit [<port>] stp .....	228
5.3.69	show interface gigabit [<port>] vlan.....	229
5.3.70	show interface gigabit la bridge.....	229
5.3.71	show interface gigabit la counter.....	229
5.3.72	show interface gigabit la lacp .....	229
5.3.73	show interface gigabit la vlan .....	229
5.3.74	show lacp .....	229
5.3.75	show mac-spoofing-detect config.....	229
5.3.76	show mac-spoofing-detect log.....	230
5.3.77	show management all .....	230
5.3.78	show management dhcp .....	230
5.3.79	show management gbe.....	230
5.3.80	show management mgmt.....	230
5.3.81	show pm <port> adsl day .....	230
5.3.82	show pm <port> adsl interval .....	231
5.3.83	show port-template parameter .....	231
5.3.84	show priority-list ds.....	231
5.3.85	show priority-list dstip.....	231
5.3.86	show priority-list dstmac.....	232
5.3.87	show priority-list ethertype .....	232
5.3.88	show priority-list ipprotocol.....	232
5.3.89	show priority-list srcip.....	232
5.3.90	show priority-list srcmac.....	233
5.3.91	show priority-list tos.....	233
5.3.92	show priority-list vlanid .....	233
5.3.93	show priority-queue config .....	233
5.3.94	show priority-regen.....	233
5.3.95	show profile alarm all .....	234
5.3.96	show profile igmp-acl .....	234
5.3.97	show profile rate-limit policer.....	234
5.3.98	show profile service adsl .....	234
5.3.99	show profile spectrum adsl.....	234
5.3.100	show profile tca adsl .....	235
5.3.101	show rmon alarm .....	235
5.3.102	show rmon ether_history.....	235
5.3.103	show rmon event.....	235
5.3.104	show rmon history.....	236
5.3.105	show rmon log.....	236
5.3.106	show rmon statistic .....	236
5.3.107	show route .....	236
5.3.108	show runningcfg.....	236
5.3.109	show runningcfg interface xdsl.....	237
5.3.110	show runningcfg interface gigabit.....	237
5.3.111	show snmp.....	237
5.3.112	show snmp.....	237
5.3.113	show stp.....	237
5.3.114	show syslog server .....	237
5.3.115	show system .....	238
5.3.116	show tcm config .....	238

5.3.117	show tcm-policer .....	238
5.3.118	show temperature .....	238
5.3.119	show time .....	238
5.3.120	show uptime .....	238
5.3.121	show version .....	238
5.3.122	show version detail .....	238
5.3.123	show vlan .....	239
5.3.124	show vlan ethertype .....	239
5.3.125	show vlan protocol-base .....	239
5.3.126	show vlan-translation one-to-one .....	239
5.3.127	show vlan-translation many-to-one .....	239
5.3.128	telnet .....	239
5.3.129	traceroute .....	240
<b>5.4</b>	<b>Configure Mode Commands .....</b>	<b>241</b>
5.4.1	access-list .....	241
5.4.2	account add .....	241
5.4.3	account delete .....	242
5.4.4	account modify .....	242
5.4.5	aging .....	243
5.4.6	alarm aco active .....	243
5.4.7	alarm event clear .....	243
5.4.8	alarm history clear .....	243
5.4.9	atmdesc .....	243
5.4.10	atm-loopback .....	244
5.4.11	cli-config session .....	244
5.4.12	cli-config timeout .....	244
5.4.13	cluster-cfg domain .....	245
5.4.14	cluster-cfg management .....	245
5.4.15	cluster-cfg name .....	245
5.4.16	cluster-cfg role .....	245
5.4.17	cluster-cfg voting-key .....	246
5.4.18	dsl-line-identify dhcp .....	246
5.4.19	dsl-line-identify dhcp option82 circuit .....	246
5.4.20	dsl-line-identify dhcp option82 dslam-name .....	246
5.4.21	dsl-line-identify dhcp option82 dslam-name-cluster .....	246
5.4.22	dsl-line-identify dhcp option82 dslam-name-customer .....	246
5.4.23	dsl-line-identify dhcp option82 sub .....	247
5.4.24	dsl-line-identify dhcp option82 remote .....	247
5.4.25	dsl-line-identify pppoe srv-name .....	247
5.4.26	dsl-line-identify pppoe srv-name-check .....	247
5.4.27	fdbstatic <number> {xdsl   gigabit} .....	248
5.4.28	fdbstatic <number> disable .....	248
5.4.29	fdbstatic list .....	249
5.4.30	firmware bootcode-upgrade .....	249
5.4.31	firmware login .....	249
5.4.32	firmware partition .....	250
5.4.33	firmware upgrade .....	250
5.4.34	http port .....	250
5.4.35	igmp acl .....	250
5.4.36	igmp default .....	250
5.4.37	igmp deny no-router-alert .....	251
5.4.38	igmp disable .....	251



5.4.39	igmp max-group-limit.....	251
5.4.40	igmp proxy .....	251
5.4.41	igmp snooping.....	251
5.4.42	igmp rtpport gigabit .....	252
5.4.43	igmp rtpport list.....	252
5.4.44	igmp timeout .....	253
5.4.45	igmp version.....	253
5.4.46	interface gigabit.....	253
5.4.47	interface gigabit la .....	253
5.4.48	interface xdsl .....	254
5.4.49	mac-spoofing-detect.....	254
5.4.50	mac-spoofing-detect log.....	254
5.4.51	management dhcp .....	254
5.4.52	management dhcp timeout.....	254
5.4.53	management dhcp leasetime .....	255
5.4.54	management gbe .....	255
5.4.55	management gbe vlan.....	255
5.4.56	management gbe vlan priority .....	256
5.4.57	management mgmt .....	256
5.4.58	pm clear .....	256
5.4.59	port-template mask .....	257
5.4.60	port-template unmask .....	257
5.4.61	port-template template-port.....	257
5.4.62	priority-list.....	257
5.4.63	priority-queue atm priority .....	258
5.4.64	priority-queue atm queue0-weight.....	258
5.4.65	priority-queue atm queue1-weight.....	258
5.4.66	priority-queue atm queue2-weight.....	259
5.4.67	priority-queue atm queue3-weight.....	259
5.4.68	priority-queue atm scheduling .....	259
5.4.69	priority-queue gigabit priority .....	259
5.4.70	profile alarm .....	260
5.4.71	profile igmp-acl.....	260
5.4.72	profile service adsl .....	260
5.4.73	profile spectrum.....	260
5.4.74	profile tca xdsl .....	261
5.4.75	profile rate-limit.....	261
5.4.76	remotecfg login.....	261
5.4.77	restore-factory .....	262
5.4.78	rmon alarm <index> alarm_interval.....	262
5.4.79	rmon alarm <index> delete .....	262
5.4.80	rmon alarm <index> falling_eventindex.....	263
5.4.81	rmon alarm <index> falling_threshold .....	263
5.4.82	rmon alarm <index> owner .....	263
5.4.83	rmon alarm <index> rising_eventindex .....	264
5.4.84	rmon alarm <index> rising_threshold.....	264
5.4.85	rmon alarm <index> sample_type .....	264
5.4.86	rmon alarm <index> startup_alarm .....	265
5.4.87	rmon alarm <index> variable.....	266
5.4.88	rmon event <index> community .....	267
5.4.89	rmon event <index> delete.....	267
5.4.90	rmon event <index> description .....	267

5.4.91	rmon event <index> owner.....	268
5.4.92	rmon event <index> type.....	268
5.4.93	rmon history <index> buckets_requested .....	268
5.4.94	rmon history <index> delete .....	269
5.4.95	rmon history <index> ifc .....	269
5.4.96	rmon history <index> interval .....	269
5.4.97	rmon history <index> owner .....	270
5.4.98	rmon statistic <index> delete.....	270
5.4.99	rmon statistic <index> ifc.....	270
5.4.100	rmon statistic <index> owner .....	271
5.4.101	route.....	271
5.4.102	route default.....	271
5.4.103	route delete .....	272
5.4.104	runningcfg active partition .....	272
5.4.105	runningcfg load partition.....	272
5.4.106	runningcfg login.....	273
5.4.107	runningcfg write partition .....	273
5.4.108	snmp <index> community .....	273
5.4.109	snmp notify.....	274
5.4.110	snmp target <name> address .....	274
5.4.111	snmp target <name> delete .....	274
5.4.112	snmp target <name> tag-list .....	275
5.4.113	snmp target <name> version .....	275
5.4.114	sntp polling interval .....	275
5.4.115	sntp server address .....	276
5.4.116	stp .....	276
5.4.117	stp enable .....	276
5.4.118	stp disable.....	276
5.4.119	stp forward delay.....	276
5.4.120	stp hello time.....	277
5.4.121	stp max-age .....	277
5.4.122	stp priority .....	277
5.4.123	stp version.....	277
5.4.124	syslog server.....	278
5.4.125	tcm color-aware .....	278
5.4.126	tcm color-field.....	278
5.4.127	tcm green .....	278
5.4.128	tcm non-conform-pkt .....	278
5.4.129	tcm red.....	279
5.4.130	tcm yellow .....	279
5.4.131	temperature threshold.....	279
5.4.132	temperature shelf time .....	280
5.4.133	time set date .....	280
5.4.134	time set time.....	281
5.4.135	time set timezone.....	281
5.4.136	trunk-mode.....	283
5.4.137	vlan ethertype s-tag .....	283
5.4.138	vlan protocol-base.....	284
5.4.139	vlan-translation <port>/<pvc> <VLAN ID> gigabit <port> one-to-one	285
5.4.140	vlan-translation <port>/<pvc> <VLAN ID> gigabit <port> many-to-one	286

5.4.141	vlan-translation <port>/<pvc> <VLAN ID> gigabit la one-to-one 287	
5.4.142	vlan-translation <port>/<pvc> <VLAN ID> gigabit la many-to-one 288	
5.4.143	vlan-translation <port>/<pvc> <VLAN ID> disable .....	289
<b>5.5</b>	<b>Ethernet Interface Mode Commands .....</b>	<b>290</b>
5.5.1	bridge .....	290
5.5.2	gbe admin .....	290
5.5.3	gbe speed .....	290
<b>5.6</b>	<b>Interface Mode Commands.....</b>	<b>291</b>
5.6.1	bridge .....	291
5.6.2	adsl-config.....	291
5.6.3	ipoa .....	291
<b>5.7</b>	<b>ATM Bridge Mode Commands.....</b>	<b>292</b>
5.7.1	accfrm .....	292
5.7.2	default vlan.....	292
5.7.3	default prio .....	292
5.7.4	dhcp-relay .....	293
5.7.5	egress .....	293
5.7.6	force priority .....	293
5.7.7	igmp-acl bind.....	293
5.7.8	igmp-acl max-group .....	294
5.7.9	ingress .....	294
5.7.10	ip-allowed .....	294
5.7.11	isolation.....	294
5.7.12	mac-learning .....	294
5.7.13	max-mac .....	294
5.7.14	priority-regen .....	295
5.7.15	protocol-base .....	295
5.7.16	pvc .....	295
5.7.17	pvc atmdesc.....	295
5.7.18	pvc atmdesc plc .....	296
5.7.19	pvc atmdesc shp .....	296
5.7.20	pvc encapsulation .....	296
5.7.21	stack.....	297
5.7.22	stack tls port enable .....	297
5.7.23	tcm-policer .....	297
5.7.24	vlan <VLAN ID> disable .....	297
5.7.25	vlan <VLAN ID> list.....	297
5.7.26	vlan <VLAN ID> priority.....	298
5.7.27	vlan list.....	298
<b>5.8</b>	<b>GBE Bridge Mode Commands.....</b>	<b>299</b>
5.8.1	accfrm .....	299
5.8.2	default vlan.....	299
5.8.3	default prio .....	299
5.8.4	egress .....	299
5.8.5	ingress .....	299
5.8.6	isolation.....	300
5.8.7	link mode.....	300
5.8.8	max-mac .....	300
5.8.9	priority-regen .....	300
5.8.10	stack.....	300

5.8.11	stpport edge .....	301
5.8.12	stpport enable/disable .....	301
5.8.13	stpport pathcost.....	301
5.8.14	stpport priority .....	301
5.8.15	tcm-policer .....	301
5.8.16	vlan <VLAN ID> disable .....	302
5.8.17	vlan <VLAN ID> list.....	302
5.8.18	vlan <VLAN ID> priority.....	302
5.8.19	vlan list .....	303
<b>5.9</b>	<b>GBE-LA Bridge Mode Commands.....</b>	<b>304</b>
5.9.1	accfrm .....	304
5.9.2	default vlan.....	304
5.9.3	default prio .....	304
5.9.4	egress .....	304
5.9.5	ingress .....	304
5.9.6	isolation.....	305
5.9.7	lacp actor priority system .....	305
5.9.8	link mode.....	305
5.9.9	max-mac .....	305
5.9.10	priority-regen .....	306
5.9.11	stack.....	306
5.9.12	tcm-policer .....	306
5.9.13	vlan <VLAN ID> disable .....	306
5.9.14	vlan <VLAN ID> list.....	307
5.9.15	vlan <VLAN ID> priority.....	307
5.9.16	vlan list .....	307
<b>5.10</b>	<b>ADSL Configure Mode Commands .....</b>	<b>308</b>
5.10.1	line mode carrier .....	308
5.10.2	line mode diagnostic .....	308
5.10.3	line mode force-l3.....	308
5.10.4	line mode mask.....	308
5.10.5	line port .....	309
5.10.6	line profile.....	309
5.10.7	line status service.....	309
<b>5.11</b>	<b>IPOA Configure Mode Commands.....</b>	<b>310</b>
5.11.1	brasmac .....	310
5.11.2	brasmac list.....	310
5.11.3	cpriority .....	310
5.11.4	cvlan.....	310
5.11.5	ipoa-status.....	311
5.11.6	max-mac .....	311
5.11.7	pvc .....	311
5.11.8	pvc atmdesc.....	311
5.11.9	pvc atmdesc plc .....	312
5.11.10	pvc atmdesc shp .....	312
5.11.11	pvc encapsulation .....	312
5.11.12	uplink gigabit.....	312
<b>5.12</b>	<b>Access List Mode Commands.....</b>	<b>313</b>
5.12.1	bcrate cir .....	313
5.12.2	bcrate list.....	313
5.12.3	dstmac .....	314
5.12.4	dstmac list .....	314

5.12.5	dstip .....	315
5.12.6	dstip list .....	315
5.12.7	ethertype .....	316
5.12.8	ethertype list.....	316
5.12.9	ip-allowed .....	317
5.12.10	ip-allowed list .....	317
5.12.11	ipprotocol .....	318
5.12.12	ipprotocol list .....	319
5.12.13	l4dstport .....	319
5.12.14	l4dstport list.....	319
5.12.15	mcfldrate list.....	320
5.12.16	mcfldrate vlan.....	320
5.12.17	srcip .....	321
5.12.18	srcip list.....	321
5.12.19	srcmac .....	322
5.12.20	srcmac list .....	322
<b>5.13</b>	<b>ATM Description Mode Commands.....</b>	<b>323</b>
5.13.1	cbr .....	323
5.13.2	no atmdesc .....	323
5.13.3	ubr1 .....	324
5.13.4	ubr2 .....	324
5.13.5	unshp .....	325
5.13.6	vbr1 .....	325
5.13.7	vbr2 .....	326
5.13.8	vbr3 .....	327
5.13.9	ubr-shp .....	328
5.13.10	cbr-shp .....	328
5.13.11	vbr-shp .....	329
5.13.12	vbrnrt.....	330
<b>5.14</b>	<b>Priority List Mode Commands.....</b>	<b>331</b>
5.14.1	ds .....	331
5.14.2	ds list.....	332
5.14.3	dstip .....	332
5.14.4	dstip list.....	333
5.14.5	dstmac .....	333
5.14.6	dstmac list .....	334
5.14.7	ethertype .....	334
5.14.8	ethertype list.....	335
5.14.9	ipprotocol .....	335
5.14.10	ipprotocol list.....	336
5.14.11	srcip .....	336
5.14.12	srcip list.....	337
5.14.13	srcmac .....	337
5.14.14	srcmac list .....	338
5.14.15	tos .....	338
5.14.16	tos list.....	339
5.14.17	vlanid .....	339
5.14.18	vlanid list .....	339
<b>5.15</b>	<b>Alarm Profile Mode Commands .....</b>	<b>340</b>
5.15.1	alarm mask .....	340
5.15.2	alarm unmask.....	340
5.15.3	alarm major .....	340

	5.15.4	alarm minor .....	341
<b>5.16</b>		<b>IGMP-ACL Profile Mode Commands .....</b>	<b>342</b>
	5.16.1	igmp-acl .....	342
	5.16.2	igmp-acl rebind.....	342
<b>5.17</b>		<b>Rate Limit Profile Mode Commands .....</b>	<b>343</b>
	5.17.1	share-slb .....	343
	5.17.2	share-dlb .....	343
	5.17.3	non-share-slb .....	344
	5.17.4	non-share-dlb .....	344
<b>5.18</b>		<b>Service Profile Configure Mode Commands .....</b>	<b>346</b>
	5.18.1	bitrate .....	346
	5.18.2	delay .....	346
	5.18.3	l2-packet.....	346
	5.18.4	mode .....	346
	5.18.5	noise .....	347
	5.18.6	noisemargin .....	347
	5.18.7	ra-interval .....	347
	5.18.8	service name.....	347
<b>5.19</b>		<b>Spectrum Profile Configure Mode Commands .....</b>	<b>348</b>
	5.19.1	aggregate .....	348
	5.19.2	bands <index> {start   stop}.....	348
	5.19.3	bands <index> mask .....	348
	5.19.4	carriermask .....	349
	5.19.5	message-based.....	349
	5.19.6	modem features .....	349
	5.19.7	noisemargin .....	350
	5.19.8	opmode .....	350
	5.19.9	pbomode .....	350
	5.19.10	power-mgt disable.....	350
	5.19.11	power-mgt l2 enable .....	350
	5.19.12	power-mgt l2_l3 enable .....	351
	5.19.13	power-mgt l0-time .....	351
	5.19.14	power-mgt l2-time .....	351
	5.19.15	power-mgt l2-atpr.....	351
	5.19.16	power-mgt l2-atprt.....	352
	5.19.17	psdlevel.....	352
	5.19.18	psdshape .....	352
	5.19.19	rxaggregate us max powerlevel .....	353
	5.19.20	spectrum name .....	353
	5.19.21	status modify complete .....	353
<b>5.20</b>		<b>TCA Profile Mode Commands .....</b>	<b>354</b>
	5.20.1	adsl-tca day.....	354
	5.20.2	adsl-tca disable .....	354
	5.20.3	adsl-tca enable.....	354
	5.20.4	adsl-tca interval .....	354
		<b>Appendix A ADSL Operational Mask Table.....</b>	<b>355</b>
		<b>Appendix B Alarm Table.....</b>	<b>356</b>
		<b>Appendix C Maintenance Requirement .....</b>	<b>357</b>
		<b>Appendix D Introduction for Troubleshooting .....</b>	<b>361</b>

# Introduction

The PLANET IDL-4802 is a 48-Port ADSL/ADSL2/ADSL2+ mini IP DSLAM which equips with combo electrical (RJ-45) and fiber optical (SFP) uplink interfaces offering scalable and easy deployment for the network with small ADSL environment. With the built-in POTS splitter subscriber ports, the IDL-4802 performs a cost-effective solution for network service providers to offer multiple subscribers excellent services.

Moreover, the IDL-4802 supports local and remote managed capabilities of CLI, SNMP, and Telnet via RS-232 console port and Web GUI management interface. Via user-friendly Web GUI, the IDL-4802 can be managed by workstations running standard web browsers that provide the easy-to-use operation and convenient maintenance.

To enhance the network security, the PLANET IDL-4802 also provides features such as QoS, VLAN, Multicast, Bandwidth Management, Traffic Prioritization, and Access Control List. With the advanced QoS features, the IDL-4802 is an ideal solution for next generation broadband network to deliver rich video contents, DSL, POTS, and VoIP service over ADSL2+ connection.

## 1.1 Product Features

---

- ◆ 48-Port ADSL / ADSL2 / ADSL2+ Subscriber Interface with Built-in POTS Splitter
- ◆ DMT data rate: Downstream up to 25 Mbps / Upstream up to 3Mbps
- ◆ 2 x 1000Base-T or 2 x mini-GbE Uplink Interfaces
- ◆ Web-based GUI Management
- ◆ Local RS-232 CLI and Ethernet SNMP / Telnet / SSH Management
- ◆ Firmware Upgradeable via FTP
- ◆ Configuration Backup and Restoration via TFTP
- ◆ Supports IPSec / L2TP / PPTP VPN Pass-through
- ◆ Supports 4K MAC address
- ◆ Supports IEEE 802.1q Tag-based VLAN and Protocol-based VLAN
- ◆ Layer 2 / 3 Filtering Based on MAC, IP, Protocol, Port Number and Ether Type
- ◆ Access Control List by MAC / IP / Protocol / Port number
- ◆ Traffic prioritization (802.1p)
- ◆ Supports IGMP Snooping / Proxy per IGMP v1, v2, and v3
- ◆ FAN Alarm Indicating
- ◆ Temperature Monitoring and System Overheating Trap Functionality
- ◆ Supports IEEE 802.1d Spanning Tree Protocol and IEEE 802.3ad Link Aggregation

## 1.2 Package Contents

---

### IDL-4802

- IDL-4802 Unit x 1
- AC Power Cord x 1
- CD x 1
- Quick Installation Guide x 1
- 2-Meter Telco-50 Cable x 4
- Console Cable x 1
- Rack-mounting Ear x 2
- Screw Package x 2
- Connect Tenon x 4
- RJ-45 Cable for Fan x 1

### IDL-4802-48

- IDL-4802-48Unit x 1
- DC Power Terminal Block x 1
- CD x 1
- Quick Installation Guide x 1
- 2-Meter Telco-50 Cable x 4
- Console Cable x 1
- Rack-mounting Ear x 2
- Screw Package x 2
- Connect Tenon x 4
- RJ-45 Cable for Fan x 1

If any of above items are damaged or missing, please contact your dealer immediately.




## 1.3 Application


### Perfect solution for NSP (Network Service Provider) to offer broadband services

The PLANET IDL-4802 offers the benefit of high performance to central office co-location and MTU (Multi-Tenant Unit) / MDU (Multi-Dwelling Unit) markets. It provides service of broadband data over existing copper wires without affecting the conventional voice service by 48 subscriber ports with built-in POTS splitter. The PLANET IP DSLAM is the perfect solution for NSP with cost-effective and high-value central management capability.

#### Application 1: For Community




#### Application 2: For Building




## 1.4 Outlook

### 1.4.1 Front Panel



**IDL-4802**



**IDL-4802-48**


### Interface Definition

Interface	Description
POWER	Power On / Off switch.
-48V	-48V DC Power plug-in. (*IDL-4802-48)
FAN	RJ-45 port for connection with the RJ-45 port on the front panel of fan card to provide power to the fan.
HK	RJ-50 port for housekeeping inputs and one alarm contact output.
Console	RS-232 port for system configuration and maintenance. (9600, 8, N, 1)
RST	A hidden reset button for hardware resetting.
ACO	Alarm Cut Off
MGMT	Ethernet Port connected to LAN for providing system out-band Telnet control interface, such as system monitor, control or software upgrade.
Uplink 1 & 2	Gigabit Ethernet electrical trunk ports.
SFP 1 & 2	Gigabit Ethernet SFP trunk ports.
PHONE 1 & 2	RJ-21 connector for connecting POTS lines.
LINE 1 & 2	RJ-21 connector for connecting DSL lines.


### LED Definition

LED	Color	Description	
Uplink	Orange	On	Uplink Port connect with 100/1000Mbps Ethernet link
		Off	Uplink Port connect with 10Mbps Ethernet link
	Green	On	Active
		Off	Inactive
		Flash	Uplink Port Transmit / receive data
SYS	Green	Normal Operation	
	Red	Self-test fail	
ALM	Green	Normal Operation	
	Red	To indicate the system alarm status	
DSL status	Green	On	ADSL Port is activated and linked
		Off	ADSL Port is Disabled
		Flash	ADSL Port is activated but not linked

## 1.4.2 Rear Panel



IDL-4802



IDL-4802-48

## Port Definition

Port	Description
AC PWR	AC Power cord plug-in, 100 - 240VAC is allowed. (*IDL-4802)

## 1.5 Technical Specifications

<b>Product</b>	<b>48-Port ADSL 2/2+ IP DSLAM</b>	
<b>Model</b>	<b>IDL-4802 / IDL-4802-48</b>	
<b>Hardware Specification</b>		
Case	1.5U high box-type with a rack-mountable enclosure	
Ports	Uplink	2 x RJ-45 (10/100/1000Base-T) 2 x SFP (1000Base-T/SX/LX/EX/ZX/LHX)
	MGMT	1 x RJ-45 (10/100Base-TX)
	Console	1 x RJ-45 (RS-232 serial port, 9600, 8, N, 1)
	LINE	2 x RJ-21 connectors
	PHONE	2 x RJ-21 connectors
	Fan	2 x RJ-45
	HK	1 x RJ-50
LED Indicators	1 x SYS LED 1 x ALM LED 2 x Uplink LEDs 48 x ADSL LEDs	
<b>Software Specification</b>		
Standard	Compliant with ADSL standard - ANSI T1.413 issue 2 - G.dmt (ITU G.992.1) - G.lite (ITU G.992.2) - G.hs (ITU G.994.1) Capable of ADSL2 standard - G.dmt.bis (ITU G.992.3) Capable of ADSL2+ standard - G.dmt.bisplus (ITU G.992.5)	
System	- Subscriber interface with built-in POTS splitter - Downstream DMT data rate up to 25 Mbps - Upstream DMT data rate up to 3 Mbps (Annex M) - Distance up to 18 kft - 8 PVCs per xDSL port - DHCP forward - DHCP relay agent - PPPoE relay - IPSec/L2TP/PPTP VPN pass-through function - PPPoA to PPPoE inter-working	
Bridge Function	- Supports IPv4 packet - Supports IEEE802.1d Ethernet bridge function between trunk Ether port and ATM VCs - Supports static source MAC table provisioning, automatic source MAC learning and block duplicate ones - Supports 4K static MAC address table - 128 MAC address per x DSL port - Supports IEEE802.1d Ethernet bridge function between trunk Ether port and ATM VCs - Supports Rapid Spanning Tree Protocol (RSTP) for the trunk interfaces per IEEE 802.1w - Support Link Aggregation in IEEE 802.3ad for 2 GBE links to be aggregated together as a logical link - Support both LACP protocol (dynamic) for load sharing and failover in case of loss of Ethernet link	
VLAN Function	- IEEE 802.1q Port-based / Protocol-based VLAN - 512 non-stacked VLAN-ID simultaneously ranging from 1 to 4095 - VLAN stacking and VLAN cross-connect - IP Spoofing prevention	

	<ul style="list-style-type: none"> <li>- MAC anti-Spoofing</li> <li>- Port isolation functionality</li> <li>- Static VLAN group and membership provisioning</li> </ul>
Multicast Function	<ul style="list-style-type: none"> <li>- IP multicast forwarding</li> <li>- Complies with RFC2684 bridged payload encapsulation mode</li> <li>- Up to 256 multicast groups and 512 copies simultaneously</li> <li>- Up to 48 profile-based Multicast Access Control</li> <li>- Limit maximum number of IGMP groups joined per bridge port</li> <li>- IGMP snooping / proxy per IGMP v1, v2, and v3</li> <li>- IGMP proxy and IGMP snooping Selection</li> </ul>
Security	<ul style="list-style-type: none"> <li>- Supports Layer-2 frame filtering based on MAC and Ether Type</li> <li>- Supports Layer-3 filtering based on IP, Protocol, and Port number</li> <li>- IEEE 802.1X authentication</li> </ul>
QoS	<ul style="list-style-type: none"> <li>- Control the bandwidth occupied by broadcast, multicast, and unknown unicast (flooding)</li> <li>- Rate-limit profile binding per bridge port</li> <li>- Three Color Marking (TCM) policer</li> <li>- Ethernet rate limit per bridge port</li> <li>- ToS (type of service) / DiffServ (differentiated services) stripping and priority queuing</li> <li>- DSCP mapping to 802.1p</li> <li>- Selectable adopted priority queue mechanisms according to Strict Priority Queue (SPQ) and Weighted Fair Queue (WFQ)</li> <li>- Configurable mapping function between ATM PVC and 802.1p priority queue</li> <li>- Supports IP CoS technology</li> </ul>
Management	<ul style="list-style-type: none"> <li>- Web based GUI management</li> <li>- Local RS-232 CLI, and Ethernet SNMP / Telnet / SSH management</li> <li>- Remote in-band SNMP / Telnet / SSH management</li> <li>- Firmware upgradeable via FTP</li> <li>◆ SNMP v1, v2c</li> </ul>

# Installation

The followings are instructions for setting up the IDL-4802. Refer to the illustration and follow the simple steps below to quickly install your IP DSLAM.

## 2.1 Safety Instruction

---

The following is the safety instructions for IP DSLAM before installing.

>> The maximum operating temperature of the IP DSLAM is 65°C. Care must be taken to allow sufficient air circulation or space between units when the IP DSLAM is installed inside a closed rack assembly and racks should safely support the combined weight of all IP DSLAM.

>> The connections and equipment that supply power to the IP DSLAM should be capable of operating safely with the maximum power requirements of the IP DSLAM. In the event of a power overload, the supply circuits and supply wiring should not become hazardous.

>> The AC power cord must plug into the right supply voltage. Make sure that the supplied AC voltage is correct and stable. If the input AC voltage is over 10% lower than the standard may cause the IP DSLAM to malfunction.

>> Generally, when installed after the final configuration, the product must comply with the applicable safety standards and regulatory requirements of the country in which it is installed. If necessary, consult for technical support.


>> A rare condition can create a voltage potential between the earth grounds of two or more buildings. If products installed in separate building are interconnected, the voltage potential can cause a hazardous condition. Consult a qualified electrical consultant to determine whether or not this phenomenon exists and, if necessary, implement corrective action before interconnecting the products. If the equipment is to be used with telecommunications circuit, take the following precautions:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet location unless the jack is specially - designed for wet location.
- Never touch un-insulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Caution when installing or modifying telephone lines (other than a cordless telephone) during an electrical storm. There is a remote risk of electric shock from lightning.
- Do not use a telephone or other equipment connected to telephone lines to report a gas leak in the vicinity of the leak.

## 2.2 Hardware Installation

---

The PLANET IDL-4802 is a 1.5U high box-type IP DSLAM with rack-mountable enclosure. It can be installed in a standard 19-inch rack by using the mounting brackets provided. Mount the shelf on the rack using the large screws provided.



### 2.2.1 System Requirements


- Workstation with Windows NT/2000/XP
- RJ-45 cables
- RJ-11 cables
- Telco-50 cables
- RS-232 console cable
- <Optional> MDF Patch Panel (Model No.: IDL-PAN-48)

## 2.2.2 Installation Procedure

### 1. Power and Ground Connections

#### Power Connections


With IDL-4802, connect the ac power cord to the ac supply socket on the rear panel as below figure, and plug the cord into the external power source. The voltage must be 100 to 240V AC.



With IDL-4802-48, the DC power interface is a 4-pin terminal block with polarity signs on the front panel as below figure.

It can be powered from two  $-48V$  DC power supply. The DC power connector is a 4P terminal block; 2P is for accommodating one DC power input and other 2P is for accommodating another DC power input. The DC power should be connected to a well-fused power supply.

After completing chassis installation, please apply power to the fused power distribution panel feeding the chassis. When using a DC voltmeter, please check for proper voltage:  $-60V \sim -36V$  DC, and make sure that the polarity is correct.



#### **Note:**

1. Ensure that all power sources to the device are turned off during the installation.
2. It is recommended that the  $-48VDC$  power be supplied directly and independently by a power feeding system and also avoid having a parallel or mutual connection with other  $-48VDC$  power supplier of telecom equipment. This is to guarantee our products against interferences by other equipment while they are working.

#### Ground Connections




■ **In Central Office:**


There should be a co gnd that is adequately grounded. If the measured resistance from the grounding screw (on the rear panel of the DSLAM, refer to below figure) to co gnd is less than 5 ohm, then it can be assumed that the system is well grounded. If the measured resistance is larger than 5 ohm, it is recommended to connect the grounding screw to co gnd using #14 or #12 awg wire gauge conductor.

■ **In Remote Cabinet:**

The IDL-4802 should be grounded by connecting a #14 or #12 AWG conductor between the grounding screw (on the rear panel of the DSLAM, refer to below figure) and the earth ground or main grounding bar. The resistance between the chassis and the grounding bar should be less than 25 Ohm.




Grounding Screw of IDL-4802




Grounding Screw of IDL-4802-48

## 2: FAN Cable Connection



There are two FAN ports on the front panel. One is on the FAN card; the other is beside the HK port. To make the fans work, you must use an RJ45-to-RJ45 connector cable to connect the two FAN ports.

FAN Port RJ-45 pin assignment:

1 2 3 4 5 6 7 8	<b>3, 4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>
	GND	FAN ERR1	FAN ERR2	FAN ERR3	FAN Status

### 3: ADSL and POTS Connections

The IDL-4802 supports 48 ports ADSL subscribers per box. There are four RJ-21 50-pin female connectors on the front panel of the system. Two for ADSL lines and two for POTS interfaces.

To connect the subscriber lines, use cables with the RJ-21 50-pin male connectors. When installing, just plug the end of cable with connector into the LINE and PHONE connectors on the front panel. The other end of the cable is generally tied to the MDF (Main Distribution Frame).


---

**Note:**

The MDF Patch panel is optional of standard package.


---

Please plug-in the RJ-21 cable with connector tenon as below figures.




LINE / PHONE interface pin assignment:

**For port 1~24:**




<b>PIN Number</b>	1	2	3	4	5	6	7	8	~	18	19	20	21	22	23	24	25
<b>Port Number</b>	Tip 1	Tip 2	Tip 3	Tip 4	Tip 5	Tip 6	Tip 7	Tip 8	~	Tip 18	Tip 19	Tip 20	Tip 21	Tip 22	Tip 23	Tip 24	X
<b>PIN Number</b>	26	27	28	29	30	31	32	33	~	43	44	45	46	47	48	49	50
<b>Port Number</b>	Ring 1	Ring 2	Ring 3	Ring 4	Ring 5	Ring 6	Ring 7	Ring 8	~	Ring 18	Ring 19	Ring 20	Ring 21	Ring 22	Ring 23	Ring 24	X

**For port 25~48:**



<b>PIN Number</b>	1	2	3	4	5	6	7	8	~	18	19	20	21	22	23	24	25
<b>Port Number</b>	Tip 25	Tip 26	Tip 27	Tip 28	Tip 29	Tip 30	Tip 31	Tip 32	~	Tip 42	Tip 43	Tip 44	Tip 45	Tip 46	Tip 47	Tip 48	X
<b>PIN Number</b>	26	27	28	29	30	31	32	33	~	43	44	45	46	47	48	49	50
<b>Port Number</b>	Ring 25	Ring 26	Ring 27	Ring 28	Ring 29	Ring 30	Ring 31	Ring 32	~	Ring 42	Ring 43	Ring 44	Ring 45	Ring 46	Ring 47	Ring 48	X

## 4: Uplink Interfaces Connections



The system provides two types of trunk interfaces (two ports for each type). There are electrical (RJ-45) and optical (SFP) interfaces. When both electrical and optical ports are connected, system will automatically select the interface according to the priority setting (Fiber first or Copper first).


RJ-45 electrical trunk port pin assignment:

	1,2	T/Rx+,T/Rx-
	3,6	T/Rx+,T/Rx-
	4,5	T/Rx+,T/Rx-
	7,8	T/Rx+,T/Rx-

### SFP (Mini-GBIC):

Prepare a proper SFP module and install it into the optical trunk port. Then you can connect fiber optics cabling that uses LC connectors or SC connectors (with the use of an optional SC-to-LC adapter) to the fiber optics connector on the trunk port.

## 5: Management Port Connection




The IDL-4802 provides one RJ45 (MGMT) on the front panel for Ethernet interface connection. To connect the Ethernet interface to PC directly, an Ethernet crossover cable is required.

Ethernet Port RJ-45 pin assignment:


	<b>1</b>	<b>2</b>	<b>3</b>	<b>6</b>	<b>Other pins</b>
	TX +	TX -	RX +	RX -	Bob Smith Termination

To connect the Ethernet interface to PC, the Ethernet crossover cable is required. The detailed pin assignment is shown below.




Name	Pin		Pin	Name
Tx+	1	↔	3	Rx+
Tx-	2	↔	6	Rx-
Rx+	3	↔	1	Tx+
Rx-	6	↔	2	Tx-

## 6: Console Port Connection




The Console interface on the front panel is the main control interface of the IDL-4802. To connect the host PC to the console port, a RJ45 (male) connector-to-RS232 DB9 (female) connector cable is required. The RJ45 connector of the cable is connected to the COM port of the DSLAM; the DB9 connector of the cable is connected to the PC COM port.

Console Port RJ-45 pin assignment:


1 2 3 4 5 6 7 8	<b>3</b>	<b>4</b>	<b>6</b>	<b>Other pins</b>
	TX	RX	GND	unused

To connect the host PC to the console port, a RJ45 (male) connector-to-RS232 DB9 (female) connector cable is required. The RJ45 connector of the cable is connected to the COM port of the DSLAM; the DB9 connector of the cable is connected to the PC COM port. The pin assignment of the console cable is shown below:



DB-9F	RJ-45M Pin
	1
	2
Pin 2 RD	3
Pin 3 TD	4
	5
Pin 5 DGND	6
	7
	8


## 7: Housekeeping Connection



The IDL-4802 equips with a RJ-50 port (HK) on the front panel to provide four housekeeping inputs and one alarm contact output. Generally, housekeeping contacts can connect to environment-sensor-controlled switch to indicate the operation environment condition.

The HK circuit contains a photo coupler powered by the IDL-4802 to detect the “open” or “close” status of the loop between HK\_IN and HK\_COM (users don’t need to feed 3.3v power into the circuit). As to the alarm output, there is a relay between ALMOUT and ALMCOM to control the status of the loop to be “OPEN” or “CLOSE” to the alarm equipment (close between ALMOUT and ALMCOM for alarm; open if no alarm).

HK Port RJ-50 pin assignment:




---


### Note:

The maximum current and voltage for ALMOUT / ALMCOM is restricted to 0.5 A 30 VDC or 0.15 A 125 VAC (resistive load).

---



Operation diagram of Housekeeping Inputs and Alarm Contact Output:



## 2.3 WEB Configuration


---

This section describes how to use Web Configuration Tool to maintain your IP DSLAM. The IDL-4802 contains a HTTP server. You can login and configure it by using your Web Browser.

### 2.3.1 System Preparation

Before attempting to configure the IDL-4802, please ensure as below:  
Set your computer's IP with the same network segment of the IP DSLAM.  
**(For example: IDL-4802 default MGMT IP is 192.168.1.1 / 255.255.255.0)**

Then you can set computer's IP to:  
**192.168.1.x / 255.255.255.0.** (The range for x is from 2 to 253)



## 2.3.2 WEB Configuration Procedure

### Step 1: Using your WEB Browser

Open web browser and type **http://192.168.1.1** in the browser's address box. This IP is the default MGMT IP address of IDL-4802. Press Enter.




### Step 2: Login the IDL-4802

A login page will appear. Please type your username / password and click "Sign in". (The default **username / password** is **admin / admin**)

A screenshot of the "Web Interface Login" page. The page has a light blue background. At the top right, it says "Web Interface Login". In the center, there is a login form with two input fields: "Username: admin" and "Password: [masked with dots]". Below the password field is a "Sign in" button. Underneath the login form, there is a list of user levels:

- Level 1: SuperUser, R/W Management all
- Level 2: Engineer, R/W (Disabled from User Account)
- Level 3: Guest, Read only

After you login the IDL-4802, you will see the system information as below.

A screenshot of the "System Information" page in the IDL-4802 web interface. On the left is a blue sidebar with a menu containing: System, Bridge, ADSL, Traffic, SNMP, and Maintenance. The main content area is titled "System Information" and contains several sections:

- ACCESS LOGIN**: A table with columns: Access Level, System Date, FW Boot, Active DB, Current DB. Row: Super user, 2009/03/27, Partition-1, Partition-1, Partition-1.
- SYSTEM MAC**: A table with columns: Bridge MAC, Giga1 MAC, Giga2 MAC. Row: 00:30:4F:71:53:BD, 00:30:4F:71:53:BB, 00:30:4F:71:53:BC.
- SYSTEM VERSION**: A table with columns: Hardware, Firmware, Software, Web, Circuit.1-48. Row: C, 0.77B03, 0.77B03, Ud-08.26a, AnnexA.
- GIGA STATUS**: A table with columns: Giga1, Giga2, LA, SYS LED, ALM LED. Row: Config Enabled, Config Enabled, Config Disabled, [Green dot], [Yellow dot].

### Step 3: Configure the DSL PVC

Go to “**Bridge** → **Interface Setup** → **ADSL PVC**” setting screen, select the ADSL port and click “**Create**” to apply the PVC settings.

(For example, create PVC-1 to Port 1. The default **VPI / VCI** is **0 / 35**)

The screenshot shows the configuration interface for ADSL PVC. On the left, a navigation menu is visible with the following structure:

- System
  - Bridge
    - Interface Setup
      - GIGA Bridge
      - ADSL PVC (selected)
      - ADSL Bridge
      - ADSL Port Security
    - VLAN Configuration
    - Access Control
    - Forwarding
    - Relay
    - IGMP
    - IPoA
    - ADSL
    - Traffic
    - SNMP
    - Maintenance

The main configuration area includes the following fields:

- VPI: 0, VCI: 35, Traffic: Rx Default[UnShaped], Tx Default[UnShaped]
- Encap: LLC, Protocol Base VLAN: Disabled
- Buttons: ALL, Create, Modify, Delete
- Dropdowns: Port 01~12, PVC-1, Query

Below the configuration fields is a table with the following columns: Select, Port, VPI, VCI, Rx Traffic, Tx Traffic, EICAP, Protocol Base VLAN. The first row (Port 1) is selected, and the 'Create' button is highlighted.

Select	Port	VPI	VCI	Rx Traffic	Tx Traffic	EICAP	Protocol Base VLAN
<input checked="" type="radio"/>	1	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	2						
<input type="radio"/>	3						
<input type="radio"/>	4						
<input type="radio"/>	5						
<input type="radio"/>	6						
<input type="radio"/>	7						
<input type="radio"/>	8						
<input type="radio"/>	9						
<input type="radio"/>	10						
<input type="radio"/>	11						
<input type="radio"/>	12						

You can see the Port has been created.

This is a close-up view of the table from the previous screenshot. The first row is highlighted with a red box, showing the following data:

Select	Port	VPI	VCI	Rx Traffic	Tx Traffic	EICAP	Protocol Base VLAN
<input checked="" type="radio"/>	1	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	2						
<input type="radio"/>	3						
<input type="radio"/>	4						
<input type="radio"/>	5						
<input type="radio"/>	6						
<input type="radio"/>	7						
<input type="radio"/>	8						
<input type="radio"/>	9						
<input type="radio"/>	10						
<input type="radio"/>	11						
<input type="radio"/>	12						

#### Step 4: Enable the ADSL Port Service

Go to “**System → ADSL Port Service**” setting screen, select the ADSL port and Admin is “ON”. Click “**Modify**” to make this Port is ON.

The screenshot shows the 'System >> ADSL Port Service' configuration page. On the left sidebar, 'System' is expanded and 'ADSL Port Service' is selected. The main content area shows the configuration for port 01-12. The 'Admin' status is set to 'ON', and the 'Modify' button is highlighted. The table below shows the status of ports 1 through 11.

Select	Port	Admin Status	Current Status	Service Profile	Spectrum Profile	TCA Profile
<input checked="" type="radio"/>	1	OFF	OFF	1	1	1
<input type="radio"/>	2	OFF	OFF	1	1	1
<input type="radio"/>	3	OFF	OFF	1	1	1
<input type="radio"/>	4	OFF	OFF	1	1	1
<input type="radio"/>	5	OFF	OFF	1	1	1
<input type="radio"/>	6	OFF	OFF	1	1	1
<input type="radio"/>	7	OFF	OFF	1	1	1
<input type="radio"/>	8	OFF	OFF	1	1	1
<input type="radio"/>	9	OFF	OFF	1	1	1
<input type="radio"/>	10	OFF	OFF	1	1	1
<input type="radio"/>	11	OFF	OFF	1	1	1

You can see the Admin status became to ON.

The screenshot shows the 'System >> ADSL Port Service' configuration page. On the left sidebar, 'System' is expanded and 'ADSL Port Service' is selected. The main content area shows the configuration for port 01-12. The 'Admin' status is set to 'ON', and the 'Modify' button is highlighted. The table below shows the status of ports 1 through 11.

Select	Port	Admin Status	Current Status	Service Profile	Spectrum Profile	TCA Profile
<input checked="" type="radio"/>	1	ON	OFF	1	1	1
<input type="radio"/>	2	OFF	OFF	1	1	1
<input type="radio"/>	3	OFF	OFF	1	1	1
<input type="radio"/>	4	OFF	OFF	1	1	1
<input type="radio"/>	5	OFF	OFF	1	1	1
<input type="radio"/>	6	OFF	OFF	1	1	1
<input type="radio"/>	7	OFF	OFF	1	1	1
<input type="radio"/>	8	OFF	OFF	1	1	1
<input type="radio"/>	9	OFF	OFF	1	1	1
<input type="radio"/>	10	OFF	OFF	1	1	1
<input type="radio"/>	11	OFF	OFF	1	1	1

### Step 5: Connect the ADSL2/2+ CPE to Patch Panel

Connect the ADSL2/2+ CPE to Patch Panel and configure it, the VPI / VCI value must be the same with IDL-4802.

After finish setting, the CPE will establish the ADSL connection with IDL-4802. You can check the connection status as below figure. The Current Status is ON.

Now the clients can access to Internet through IDL-4802.

Admin: ON Service Profile: 1 Spectrum Profile: 1 TCA Profile: 1 All  Modify

The Service Profile range from 1 to 120  
The Spectrum Profile range from 1 to 120  
The TCA Profile range from 1 to 64

Port 01~12 Query

Select	Port	Admin Status	Current Status	Service Profile	Spectrum Profile	TCA Profile
<input checked="" type="radio"/>	1	ON	ON	1	1	1
<input type="radio"/>	2	OFF	OFF	1	1	1
<input type="radio"/>	3	OFF	OFF	1	1	1
<input type="radio"/>	4	OFF	OFF	1	1	1
<input type="radio"/>	5	OFF	OFF	1	1	1
<input type="radio"/>	6	OFF	OFF	1	1	1
<input type="radio"/>	7	OFF	OFF	1	1	1
<input type="radio"/>	8	OFF	OFF	1	1	1
<input type="radio"/>	9	OFF	OFF	1	1	1
<input type="radio"/>	10	OFF	OFF	1	1	1
<input type="radio"/>	11	OFF	OFF	1	1	1
<input type="radio"/>	12	OFF	OFF	1	1	1

[ SERVICE PROFILE | SPECTRUM PROFILE | TCA PROFILE ]

## Step 6: Save the running configuration to Flash

Remember to save your running configuration to the flash, otherwise the settings will be lost if you power-off IDL-4802.



Go to “**Maintenance → Database**” setting screen, select the “**(D) Save Running Config to Flash (System Config)** “. There are two partitions on flash, select your Partition which you want to save and click “**Write Running**”. The configuration will save to the Flash.

---

### Note:

Default Partition is **Partition1**.


---



### 2.3.3 How to backup / Restore the Configuration

#### Configuration Import / Export

The IDL-4802 provides the configuration preservation feature that the configuration database is stored in flash memory (two partitions available). In addition to the configuration preservation feature, the IDL-4802 also provides the configuration export/import feature.



#### For CLI:

Suppose that TFTP Server IP address is 172.16.100.181 and configuration file name is 'testcfg':

**(A)** Import file from TFTP Server to the Download Config and then write Download Config to the Flash (partition 1 or partition 2).

Ex:

```
enable
configure
remotecfg login 172.16.100.181 get testcfg write partition <number>
```



**(B)** Import file from TFTP Server to the Download Config and then load Download Config to the Running Config.

**Ex:**

```
enable
configure
remotecfg login 172.16.100.181 get testcfg load
```

**(C)** Export: export file from Running config to the TFTP server.

**Ex:**

```
enable
configure
runningcfg login 172.16.100.181 put testcfg
```

**(D)** Save Running config to the Flash (partition 1 or partition 2).

**Ex:**

```
enable
configure
runningcfg write partition <number>
```

**(E)** Reload Flash data to the Running config

**Ex:**

```
enable
configure
runningcfg load partition <number>
```

**(F)** Set system configuration (current boot point) to factory default value

**Ex:**

```
enable
configure
restore-factory
```

**(G)** Select Configuration Flash Boot Point

**Ex:**

```
enable
configure
runningcfg active partition <number>
```

**For Web:**

On the menu tree, click on **Maintenance** --- > **Database**. The *Database Configuration* page is displayed. Select the database configuration action you want to perform.

Database Configuration

DB Config Select: [Select]
(A)Import File (Write Download Config To FLASH)
(B)Import File (Load Remote Config to Running Config)
(C)Export File (Put Running Config To Remote TFTP Server)
(D)Save Running Config to Flash(System Config)
(E)Reload FLASH(System Config) to Running Config
(F)Restore Factory Default
(G)Flash Boot Point Configuration Select

**(A) Import File (Write Download Config To Flash):**

Type in the TFTP Server IP address and the name of the file you want to download. Then click on **Get File** button.

Database Configuration

DB Config Select: (A)Import File (Write Download Config To FLASH)
Write flash at: Partition2
TFTP Server IP: 172.16.10.241 File Name: config1 <input type="button" value="Get File"/>

**Write downloaded Config to Flash in progress:**

Database Configuration

DB Config Select: (A)Import File (Write Download Config To FLASH)
Write flash at: Partition2
TFTP Server IP: 172.16.10.241 File Name: config1 <input type="button" value="Get File"/>
<b>Action Name</b> WRITE_DOWNLOAD
<b>Action Status</b>   MEMORY WRITE IN PROGRESS

### Write to memory successfully:

#### Database Configuration

DB Config Select:	(A)Import File (Write Download Config To FLASH)			
Write flash at:	Partition2			
TFTP Server IP:	172.16.10.241	File Name:	config1	Get File
<b>Action Name</b>	WRITE_DOWNLOAD			
<b>Action Status</b>	MEMORY WRITE SUCCESS			

### Fail to Get File:

DB Config Select:	(A)Import File (Write Download Config To FLASH)			
Write flash at:	Partition2			
TFTP Server IP:	172.16.10.28	File Name:	config1	Get File
<b>Action Name</b>	GET_LOCAL			
<b>Action Status</b>	TFTP GET FAIL			

## (B) Import File (Load Remote Config to Running Config)

Type in the TFTP Server IP address and the name of the file you want to download. Then click on **Get File** button.

### Database Configuration

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.241	File Name: config1
		<input type="button" value="Get File"/>

## Load to Running Config successfully:

### Database Configuration

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.241	File Name: config1
		<input type="button" value="Get File"/>
<b>Action Name</b>	LOAD_REMOTE	
<b>Action Status</b>	MEMORY READ SUCCESS	

## Fail to Get File:

### Database Configuration

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.28	File Name: config1
		<input type="button" value="Get File"/>
<b>Action Name</b>	GET_LOCAL	
<b>Action Status</b>	TFTP GET FAIL	

### (C) Export File (Put Running Config to Remote TFTP Server)

Type in the TFTP Server IP address and the name of the file you want to export. Then click on **Put File** button.

#### Database Configuration

---

DB Config Select: (C)Export File (Put Running Config To Remote TFTP Server) ▼		
TFTP Server IP: 172.16.10.241	File Name: config1	Put File

### TFTP put file successfully:

#### Database Configuration

---

DB Config Select: (C)Export File (Put Running Config To Remote TFTP Server) ▼		
TFTP Server IP: 172.16.10.241	File Name: config1	Put File
<b>Action Name</b>	PUT_REMOTE	
<b>Action Status</b>	TFTP PUT SUCCESS	

### TFTP put file fail:

#### Database Configuration

---

DB Config Select: (C)Export File (Put Running Config To Remote TFTP Server) ▼		
TFTP Server IP: 172.16.10.28	File Name: config1	Put File
<b>Action Name</b>	PUT_REMOTE	
<b>Action Status</b>	TFTP PUT FAIL	

### (D) Save Running Config to Flash (System Config)

Click on the drop-down list and select partition, and then click on **Write\_Running** button to write running configuration to Flash.

#### Database Configuration

---

DB Config Select:	(D)Save Running Config to Flash(System Config) ▼
Write flash at:	Partition2 ▼ <input type="button" value="Write_Running"/>

### Write running config to Flash successfully:

#### Database Configuration

---

DB Config Select:	(D)Save Running Config to Flash(System Config) ▼
Write flash at:	Partition2 ▼ <input type="button" value="Write_Running"/>
<b>Action Name</b>	WRITE_RUNNING
<b>Action Status</b>	MEMORY WRITE SUCCESS

## (E) Reload Flash to Running Config

Click on the drop-down list and select partition, and then click on **LOAD\_FLASH** button to load configuration from Flash to Running Config.

### Database Configuration

---

DB Config Select:	(E)Reload FLASH(System Config) to Running Config	▼	
Load flash at:	Partition2	▼	LOAD_FLASH

**Load configuration from Flash to Running Config successfully:**

### Database Configuration

---

DB Config Select:	(E)Reload FLASH(System Config) to Running Config	▼	
Load flash at:	Partition2	▼	LOAD_FLASH
<b>Action Name</b>	LOAD_FLASH		
<b>Action Status</b>	MEMORY READ SUCCESS		

## (F) Restore Factory Default

Click on **Factory\_Default** button to restore factory default configuration.

Database Configuration

---

DB Config Select: (F)Restore Factory Default

After loading default configuration to Flash successfully, you must click on **RESTART** button to restart the system so that the configuration can take effect.

Database Configuration

---

DB Config Select: (F)Restore Factory Default

<b>Action Name</b>	RESTORE_FACTORY
<b>Action Status</b>	MEMORY WRITE SUCCESS


**Would you like to restart system?**



## (G) Flash Boot Point Configuration Select

Click on the *Boot Config* drop-down list and select the partition (Partition1 or Partition2) as the boot point. Click on **Apply** button and then restart the system. The system will restart and load the configuration in the partition you select into the running configuration.

### Database Configuration



## 2.3.4 Firmware Update

### For CLI:

If you want to update firmware code, you must get image file from FTP Server. Suppose that FTP Server IP address is 172.16.10.219 and the image filename is 'vmlinux\_u4802\_0.73B05'.

### Example:

#### 1. Firmware update:

```
enable //go to enable mode
configure //go to configuration mode
firmware login 172.16.10.219 username share password tg123
firmware upgrade vmlinux_u4802_0.73B05
(Firmware upgrade may take a few minutes, don't turn off or reset the system
during the process. You can get status using command 'show firmware status' in
Enable execution mode.)

exit //back to enable mode
show firmware status
(When status returns "Upgraded already!", you can restart the system to run
new firmware image. Once you upgrade successfully, you can't upgrade the
second time unless you have restarted the system.)
show firmware partition //show partition information
```

Current Version:0.71B09

Partition	Version	Date	Status
1	0.71B09	2007/07/05	--
2	0.71B09	2007/07/10	Active

(**Note:** the 'Active' status of the firmware partition information means the active partition for next time restart, not current running partition. You can see which partition is current running partition by referring to the Current Version. )

2. The IDL-4802 provides two firmware memory partitions. If you want to change the firmware partition for booting, use the following commands (if you change to the non-active partition, system will restart immediately):

```
enable //go to enable mode
configure //go to configuration mode
firmware partition <number> //select partition 1 or 2 for next power-on
```

**For Web:**

On the menu tree, click on **Maintenance** --- > **Firmware Update**. The *Firmware Update* page is displayed. Once you have entered all the necessary values, click on **Firmware Update** button to start updating the firmware.

Firmware Update			
<b>Remote FTP Server IP</b>	172 . 16 . 10 . 41 : 21		
<b>Server User Name</b>	[ share ]		
<b>Server Password</b>	[ ***** ]		
<b>File Name</b>	[ vmlinux_u4802_0.73B05 ]		
<b>Firmware Update Status</b>	<b>No Action[0]</b>		
Firmware Partition Select: Partition 2 ▾			
Once system has 2 versions, an operator can use Partition Select from 1 to 2, vice versa. (e.g)Partition changes from version A.a to version B.b			
<b>Partition Location</b>	Version	Build Date	Status
<b>Partition:1</b>	0.73B05	2007/07/10	----
<b>Partition:2</b>	0.73B05	2007/07/10	Active
<b>Current Version</b>	0.73B05		
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>			
<b>2.Once the system has upgraded already, please restart it!</b>			

Label	Description
Firmware Update	Once you have typed in the parameter values, click on this button to start firmware update.
Remote FTP Server IP	Type in the IP address of the FTP server.
Server User Name	Type in the ftp user name.
Server Password	Type in the ftp password.
File Name	Type in the firmware filename.
Firmware Update Status	This field shows current status of firmware update process.
Firmware Partition Select	Select firmware memory partition (Partition 1 or 2). If you change to the other partition (not current partition), the system will restart immediately.

Partition Information	This section displays the partition information including firmware version, updating date, and status (active or not). Note that active partition means the partition for next power-up, not current partition in use. You can refer to <b>Current Version</b> to know which partition is the current partition in use. When you update the firmware, new firmware will be written to the partition that is not currently in use.
-----------------------	---

### FTP Get in progress:

The following message is displayed during getting file from FTP server.

```
incoming cluster id 0
FTP SERVER IP=172.16.10.219
Waiting for FTP Session (about 30 sec..)
```

### Firmware Write in progress:

The Flash Write process may take a few minutes; **you must not turn off or reset the system during the process.**

Current Service	james@172.16.10.41,File:vmlinux_u4802_0.73B05
Firmware Update Status	/ FLASH WRITE IN PROGRESS /
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>	
<b>2.Once the system has upgraded already, please restart it!</b>	

### Firmware Write successfully:


When the Flash Write process has completed successfully, the Firmware Update Status shows "Firmware has upgraded already". You can now restart the system.

Firmware Update			
Remote FTP Server IP	. . . . . : 21		
Server User Name	[ ]		
Server Password	[ ]		
File Name	[ ]		
Firmware Update Status	Firmware has upgraded already[7]		
Firmware Partition Select: Partition 1 <input type="button" value="v"/>			
Once system has 2 versions, an operator can use Partition Select from 1 to 2, vice versa. (e.g)Partition changes from version A.a to version B.b			
Partition Location	Version	Build Date	Status
Partition:1	0.73B05	2007/07/10	Active
Partition:2	0.73B05	2007/07/10	-----
Current Version	0.73B05		
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>			
<b>2.Once the system has upgraded already, please restart it!</b>			

# Software Introduction

## 3.1 General Overview

The software architecture of the IDL-4802 is shown in the figure below. It can be divided into three layers: the management layer, the OAM&P layer, and the firmware layer.



Management Software Model

As in the figure, CLI shell, SNMP agent, and WEB server are in the top-most layer (management layer) of the system software and offering OAM&P function of the DSLAM based on the conceptual management features as follows:

- Configuration Management
- Performance Management
- Fault Management

The IDL-4802 uses flash memory as the database (DB) to store system configuration parameters, alarms and events. The firmware layer includes ADSL drivers, Memory and I/O control, etc.

### 3.1.1 Features of Management Interface

- Support CLI, SNMP (v1, v2c), and web-based GUI management interface through both in-band and out-band channels
- Support up to 10 CLI sessions at the same time
- The in-band management connection of the system is the highest priority of all supported in-band traffic categories
- Support out-band management via:
  - UART at full duplex line rate of 9600 bps (Craft port)
  - 10/100 base-T Ethernet
- Support Telnet interface for remote operators to login system operating console
- Support up to 32 configurable SNMP trap destinations and allow the SNMP traps to be sent to any specified SNMP aware device, for instance, Network management center

## 3.2 Configuration Management

---

The configuration management contains the following aspects:

1. System Setup, such as setup for management IP address/net mask, GBE interface (including to enable/disable and query the administrative/operational status of the trunk port), line port (including to enable/disable/reset ADSL port, query the administrative/operational status of the port, and bind profiles on a per port basis), CLI session and timeout, Cluster, SNTP, IP routes, and user administration (including login authorization and provides three security levels).
2. Bridge Configuration (see “Bridge Configuration” below for more description)
3. ADSL Configuration (see “ADSL configuration” below for more description)
4. ATM traffic management
5. SNMP setup

The configuration management provides detecting and reporting to the operators through SNMP Trap for all memory updates reflecting changes in the system configuration. It also provides logging the changes in the operational state and making this information available (on-demand) to the operators over the operation interface.

The system contains a database (DB) to store all the provisioning data so that the configuration can be restored in re-booting. Authorized operators can query the DB to obtain configuration data.

### 3.2.1 Bridge Configuration

The bridge configuration of the IDL-4802 includes the following aspects:

- Interface setup
- VLAN configuration: static VLAN, protocol based VLAN, VLAN translation, and IP/MAC anti-spoofing.
- Spanning Tree configuration
- Access Control: Filtering, VLAN priority remark, rate limit, and priority queue mapping.
- Forwarding database
- PPPoE and DHCP Relay
- IGMP configuration
- IPoA configuration

### 3.2.2 ADSL Configuration

Configuration for an ADSLx user port is provisioned by the parameter set, which is a group of attributes that determine the user port behaviors; and we call it as profile. The IDL-4802 provides a profile-based provisioning per the definition of ITUT G997.1 and RFC 2662 for ADSL line configuration data and a mechanism to associate the ADSL port to these profiles. One or more ADSL lines may be configured to share parameters of a single profile.

The ADSL profiles of IDL-4802 include:

- Service Profile  
The parameters include Rate adaptive mode selection, Min/max/planned bit rate, Interleaving Max delay, and Minimum impulse noise protection.
- Spectrum Profile  
The parameters include the Power management setting, Min/max/target noise margin, allowed ADSL modes of operation, Carrier mask, RFI band data, Maximum nominal aggregate transmit power, Maximum PSD level, PSD shape (for ADSL2+), Power back off initiation, and Maximum aggregate receive power.
- TCA Profile  
The parameters include ESs, SESs, UASs for interval and day PM, and LOS, LOF, LOPWR, LOL, Error Frame for interval PM only.

The system provides up to 120 Service profiles and Spectrum profiles respectively, and provides up to 64 TCA profiles. One of the profiles is a fix default that cannot be modified; users are allowed to create, delete, and edit the other profiles. Each profile contains a parameter set for downstream and upstream direction respectively. Users can also observe the actual values of these parameters through CLI, Web-GUI, or EMS.

The ADSL configuration also includes the function for user to query the line status, the physical layer status, and the channel interface status for ATU-C and ATU-R. The status information includes the attenuation rate, actual net data rate, the line attenuation, SNR margin, transmission power, actual interleaving delay, channel characteristics per subcarrier, quiet line noise PSD, ...etc.



### 3.3 Performance management

---

Performance management supports performance monitoring by collecting and thresholding performance parameter counters against 15-minute intervals for each interface and module respectively. Users can query the data of these parameters through CLI, Web-GUI, or EMS.

Performance statistics include the following:

1. Statistics for current interval:  
A real-time aspect contains the reflection of the current value situation before the new interval. The current value includes values of current 15-min interval and current 1-day interval.
2. Statistics history at 15-minute basis:  
The system stores previous 96 statistics of PM parameters at 15-min interval for retrieving.
3. Statistics history at 1-day basis:  
The system stores previous 1 statistics of PM parameters at 1-day interval for retrieving.

Most of the performance parameter thresholds are user-programmable. The IDL-4802 uses a threshold crossing alert (TCA) to notify the management system when one of the counts during a measurement interval exceeds its threshold.

The TCA contains the following information:

- Specific interface involved
- Error condition identifying the measurement type
- Value of the parameter
- Occurrence date and time of the event

The performance management also provides the traffic counter including transmitted packets, error packets and discarded packets for each interface (network and subscriber interface) and ATM cell counter in both transmit and receive direction. Users can observe these data through CLI, Web-GUI, or EMS.

## ADSL PM

The IDL-4802 provides the following ADSL PM statistics:

Item	Description
ATUC_LOS	Loss of signal count
ATUC_LOF	Loss of frame count
ATUC_LOM	Loss of margin count
ATUC_ES	Errored Seconds
ATUC_SES	Severely Errored Seconds
ATUC_UAS	Unavailable Seconds
ATUC_ReInitCounter	The number of times the modem left showtime and tried to re-initialize the line because of detection of a persistent defect
ATUC_FailedInitCounter	The number of times the modem tries to initialize the line but fails.
ATUC_CU	User Total Cell Count
ATUC_CD	Delineated Total Cell Count
ATUC_HEC	ATM Header Error Count
ATUC_IBE	Idle Cell Bit Error Count
ATUC_CVS	The counter associated with the number of Coding Violations encountered by the channel.
ATUC_FECCS	The counter associated with the number of corrected codewords encountered by the channel.
ATUR_LOS	Far End Loss of signal count
ATUR_LOF	Far End Loss of frame count
ATUR_LOM	Far End Loss of margin count
ATUR_LPR	Far End Loss of power count
ATUR_LPR	Far End Loss of power failure count
ATUR_ES	Far End Errored Seconds
ATUR_SES	Far End Severely Errored Seconds
ATUR_UAS	Far End Unavailable Seconds
ATUR_HEC	Far End ATM Header Error Count
ATUR_IBE	Far End Idle Cell Bit Error Count
ATUR_CVS	The far end counter associated with the number of Coding Violations encountered by the channel.
ATUR_FECCS	The far end counter associated with the number of corrected code words encountered by the channel.

The IDL-4802 provides the following ADSL PM thresholds:

NE threshold	FE threshold
15min ES threshold	15min ES threshold
15min SES threshold	15min SES threshold
15min UAS threshold	15min UAS threshold
15min LOS threshold	15min LOS threshold
15min LOF threshold	Not support
Not support	15min LOPWR threshold
15min LOL threshold	Not support
15min ErrFrm threshold	15min ErrFrm threshold
24hour ES threshold	24hour ES threshold
24hour SES threshold	24hour SES threshold
24hour UAS threshold	24hour UAS threshold

### 3.3.1 RMON Feature

The IDL-4802 supports performance statistics defined in RMON MIB groups 1 (Ethernet statistics), 2 (history control), 3 (alarm), and 9 (event) per RFC 2819 for all network uplink 10/100/1000 ports. The supported parameters are as follows:

RMON ETH Statistics variables

Variable	Description
DropEvents	Monitoring rx dropped packets
Octets	Monitoring rx bytes packets
Pkts	Monitoring rx packets
BroadcastPkts	Monitoring rx broadcast packets
MulticastPkts	Monitoring rx multicast packets
CRCAAlignErrors	Monitoring rx error alignment packets
UndersizePkts	Monitoring rx undersize packets
OversizePkts	Monitoring rx oversize packets
Fragments	Monitoring rx fragments packets
Jabbers	Monitoring rx jabber packets
Collisions	Monitoring tx single collision packets
Pkts64Octets	Monitoring tx 64 octets
Pkts65to127Octets	Monitoring tx 65 to 127 octets
Pkts128to255Octets	Monitoring tx 128 to 255 octets
Pkts256to511Octets	Monitoring tx 256 to 511 octets
Pkts512to1023Octets	Monitoring tx 512 to 1023 octets
Pkts1024to1518Octets	Monitoring tx 1024 to 1518 octets

RMON ETH History Control variables

Variable	Description
HistoryDropEvents	Monitoring rx dropped packets
HistoryOctets	Monitoring rx bytes packets
HistoryPkts	Monitoring rx packets
HistoryBroadcastPkts	Monitoring rx broadcast packets
HistoryMulticastPkts	Monitoring rx multicast packets
HistoryCRCAAlignErrors	Monitoring rx error alignment packets
HistoryUndersizePkts	Monitoring rx undersize packets
HistoryOversizePkts	Monitoring rx oversize packets
HistoryFragments	Monitoring rx fragments packets
HistoryJabbers	Monitoring rx jabber packets
HistoryCollisions	Monitoring tx single collision packets
HistoryTxBytes	Monitoring tx bytes
HistoryTxPackets	Monitoring tx packets
HistoryTxMulticast	Monitoring tx multicast
HistoryTxBroadcast	Monitoring tx broadcast
HistoryUtilization	Monitoring tx Utilization

### 3.4 Fault Management

---

Fault management is conceptually partitioned into two levels: the system top level, and interface-specific level. Both levels are alarm-level configurable and can be Major and Minor. All the alarms are mask-able.

Fault management provides the alarm output through hardware output interface (on the system front panel) and visible indicator (LED). The alarm/status indications are automatically generated as a result of certain events/conditions. The IDL-4802 supports query of all current alarm status. It is also able to keep 256 records of historical alarms and events respectively.

The IDL-4802 provides the ability to group alarms in a hierarchical alarm presentation scheme. Alarms of the same rank can exist at the same time. A lower-ranking alarm will be demoted if a higher-ranking alarm is raised for the same object. For example, if a far-end LOS is raised on a circuit and then a far-end LPR is raised on the circuit, the LPR alarm stands and the LOS closes. The alarm hierarchy used in the IDL-4802 system is shown in the following table:

Alarm Hierarchy

Priority	Alarm Type
Highest	all activation failures (ADSL_COMMF_FE or ADSL_NOPEER_FE)
—	far-end LPR
—	near-end LOS or far-end LOS
Lowest	near-end LOF or far-end LOF (near-end and far-end are independent; for example, FE-LOS does not restrain NE-LOF)

Note: 1.LOM, LCD, and NCD are not included in the alarm hierarchy; they're treated independently.  
2.The PM counters LPR, LOS, and LOF follow the alarm hierarchy rule. When these alarms exist at the same time, only the PM counter of a higher-ranking alarm will count (the PM counters of other lower-ranking alarms will not).

#### System Alarms

The IDL-4802 provides the following System alarms:

- House Keeping Alarm 1
- House Keeping Alarm 2
- House Keeping Alarm 3
- House Keeping Alarm 4
- Fan Failure Alarm
- Fan card unequipped alarm
- Above Temperature
- Below Temperature
- Self-test Fail
- DSP Fail - you can see which DSP chip is fail from the user interface (Web GUI, CLI, etc.). There is a number 1 ~ 4 in the alarm message/description corresponding to the DSP chip 1 ~ chip 4

## **GBE Alarms**

The IDL-4802 provides the following alarms for GBE interfaces:

- GBE1 SFP Loss of Signal
- GBE2 SFP Loss of Signal

## **ADSL Alarms**

The IDL-4802 provides the following ADSL alarms:

- LOS (Loss of Signal) -Near End/Far End
- LOF (Loss of Frame) -Near End/Far End
- LOM (Loss of Margin) -Near End/Far End
- LCD (Loss of Cell Delineation) -Near End/Far End
- NCD (No Cell Delineation) -Near End/Far End
- LOPWR (Loss of Power) -Far End
- COMMF: Unable to communicate with peer modem -Far End
- NOPEER: No peer present – Far End

### 3.5 Loopback Testing

---

The IDL-4802 supports ATM and ADSL loop diagnostics.

**ATM:**

The system provides F5 end-to-end or segment loopback.

**ADSL:**

The system provides Dual Ended Loop Testing (DELT) for each ADSL line on a per port basis.


The following test parameters are supported:

- Channel Characteristics Function  $H(f)$  per subcarrier (CCF-ps),
- Quiet Line Noise PSD  $QLN(f)$  per subcarrier (QLN-ps),
- Signal-to-Noise Ratio  $SNR(f)$  per subcarrier (SNR-ps),
- Line Attenuation (LATN),
- Signal Attenuation (SATN),
- Signal-to-Noise Ratio Margin (SNRM),
- Attainable Net Data Rate (ATTNDR),
- Far-end Actual Aggregate Transmit Power (ACTATP),
- Near-End Actual Aggregate Transmit Power (ACTATP).


### 3.6 Cluster Feature

The IDL-4802 supports Cluster feature that can make a group of NEs (network elements) work together as a single NE from the management point of view. Operators can manage the NEs in a cluster, called cluster nodes, via the same single IP address in terms of CLI, Web-based GUI or SNMP based management interfaces. The IDL-4802 currently provides cluster feature that a cluster can include up to four cluster members (NEs). There are one Master and the other members are all Slaves in a cluster. The Master works as a gateway of the Slaves, and it also can forward CLI/Web/SNMP commands to the destination Slave. The Slaves can execute the commands and respond to the Master.

There are two possible network topologies for conducting a Clustering Management group: Daisy chain and Star.



Cluster network topology – Daisy Chain



Cluster network topology – Star

# WEB Management

## Web Configuration Tool Overview

To access Web Configuration Tool on an IDL-4802:

- 1 Connect a PC to the console port of the DSLAM. At the console, type the following CLI command:

**WDS:>enable** /\*enter the enable command mode from initial mode\*/

**WDS:%show management all** /\*display all in-band and out-band management IP setting\*/

Note that the default in-band/out-band IP address of the IDL-4802 is 192.168.100.1/192.168.1.1.

- 2 At your web browser, enter the URL you retrieve by using the above command.

If you need to change the accessing port number (default is 80) of the Web Configuration Tool, use the following CLI command (with the correct values added):

**WDS:%configure** /\*enter the configuration command mode from enable mode\*/

**WDS:(conf)#http port <number>** /\*set http port number\*/

- 3 Logging in to Web Configuration Tool:

Once you connect to the DSLAM, a login page is displayed. You must enter your username and password to access the pages. The default login username and password are as follows:

User Name: **admin**

Password: **admin**

Click on the *Sign in* button.

You are now ready to configure your IDL-4802 using the Web Configuration Tool.

Web Interface Login

Username:

Password:

- Level 1: SuperUser, R/W Management all
- Level 2: Engineer, R/W (Disabled from User Account)
- Level 3: Guest, Read only

**Web Configuration Tool login page**



4 The following page is displayed. This is the homepage of the Web Configuration Tool.

The screenshot displays the homepage of the Web Configuration Tool. On the left is a blue sidebar with a menu containing: System, Bridge, ADSL, Traffic, SNMP, and Maintenance. The main content area is titled "System Information" and contains four sections: ACCESS LOGIN, SYSTEM MAC, SYSTEM VERSION, and GIGA STATUS. Each section contains a table of system parameters.

ACCESS LOGIN				
Access Level	System Date	FW Boot	Active DB	Current DB
Super user	2007/10/22	Partition-2	Partition-2	Partition-2

SYSTEM MAC		
Bridge MAC	Giga1 MAC	Giga2 MAC
00:30:4F:71:1F:F5	00:30:4F:71:10:F0	00:30:4F:71:1F:FC

SYSTEM VERSION				
Hardware	Firmware	Software	Web	Circuit:1~48
B	0.74B08	0.74B08	Uc-09.21d	AnnexA

GIGA STATUS				
Giga1	Giga2	LA	SYS LED	ALM LED
Config Enabled	Config Enabled	Config Disabled	●	●

Web Configuration Tool homepage

## About Web Configuration Tool Pages

The Web Configuration Tool provides a series of web pages for users to setup and configure the IDL-4802 System. These pages are organized into six main topics including **System**, **Bridge**, **ADSL**, **Traffic**, **SNMP**, and **Maintenance**. You can select each topic from the menu on the left-hand side of the main window. Below table lists the various pages of the web configuration tool.

The exact information displayed on each web page depends on the specific configuration that an operator is using. The following chapters provide a general description of the setup and configuration details.

Pages of the Web Configuration Tool

<b>System</b>	System Information	
	Board IP Setup	
	Ethernet Port Service	
	ADSL Port Service	
	CLI Setup	
	Cluster Setup	
	System Inventory	
	SNTP	
	IP Routes	
	User Administration	
	Duplicator	
<b>Bridge</b>	Interface Setup	GIGA Bridge
		ADSL PVC
		ADSL Bridge
		ADSL Port Security
	VLAN Configuration	Static VLAN
		Protocol Based VLAN
		Translation VLAN
		Static Allowed IP
		MAC Spoofing
	Spanning Tree	Spanning Tree Protocol
		STP Port Settings
	Access Control	Filtering
		VLAN Priority Remark
		Rate Limit
		Priority Queue Mapping
	Forwarding	TP Forwarding DB
		Forwarding Static
	Relay	DSL Line Identify
	IGMP	Protocol & Route Port
		IGMP Profile

		IGMP Multicast	
	IPOA	BRAS MAC	
		Interface Setup	
<b>ADSL</b>	Profile	Service Profile (main)	
		Service Profile (Channel)	
		Spectrum Profile (main)	
		Spectrum Profile (ADSLx)	
		TCA Profile	
	Data & Inventory	Inventory	
		Loop Test	
		Carrier Data	
		OP Data	
	Line Config & Info	Line Configuration	
		Line Information	
<b>Traffic</b>	ATM Traffic Descriptor		
<b>SNMP</b>	SNMP Community		
	SNMP Target		
	SNMP Notify		
<b>Maintenance</b>	SYS Log Server		
	Database		
	Firmware Update		
	ATM Loopbacks		
	Fault Management	Alarm/Event	
		Alarm Profile	
		Hardware Temp.	
	Performance Monitoring	System Utilization	
		Ethernet Statistics	
		ATM Statistics	
		RMON	
ADSL Day/Interval			

## Operating Examples

This section explains how to operate in the web pages of this tool.

The screenshot shows the ADSL PVC Setup web interface. It is divided into several functional areas:

- Index Selecting area:** Contains dropdown menus for selecting the port range (Port 01~12) and the PVC number (PVC-1).
- Configuration area:** Contains input fields and dropdowns for VPI (0), VCI (35), Rx Traffic (Default[UnShaped]), Tx Traffic (Default[UnShaped]), Encap (LLC), and Protocol Base VLAN (Disabled).
- Action buttons:** Includes buttons for ALL, Create, Modify, Delete, and Query.
- Data Table:** A table listing 12 ports with columns for Select, Port, VPI, VCI, Rx Traffic, Tx Traffic, ENCAP, and Protocol Base VLAN.
- ATM TRAFFIC PARAMETER:** A link at the bottom of the configuration area.

Select	Port	VPI	VCI	Rx Traffic	Tx Traffic	ENCAP	Protocol Base VLAN
<input type="radio"/>	1	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	2	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	3	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	4	0	35	Default	Default	LLC	Disabled
<input checked="" type="radio"/>	5						
<input type="radio"/>	6						
<input type="radio"/>	7						
<input type="radio"/>	8						
<input type="radio"/>	9	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	10	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	11	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	12	0	35	Default	Default	LLC	Disabled

Click on the hyperlinks below on each configuration page will lead you to the related page(s) directly without the need to search in the menu tree.

The Index Selecting area is usually for selecting the range of interface(s) to be configured. In this case, the filters (such as link type, circuit number, PVC number, or bridge port index) will enable the operator to easily locate the target interface(s) that he would like to provision. The Configuration area is for setting the parameter value of the entries in the table. This area shows the data of selected entry in Data Table to allow operator to modify the parameter values. The Data Table is for listing the setting of each interface (bridge port). Often, there is a radio button for each port. By clicking on the radio button, you can specify which entry to be created, modified, or deleted.

For the above example, first you must select the link type, circuit number range and PVC to identify the range of interfaces, and then the corresponding data of those interfaces will be listed in Data Table. Click on the radio button to select a circuit and modify the parameter values in the

Configuration area. Then click on **Create** to create a new entry or **Modify** to change the

setting of an existing entry. You can click on **Delete** to remove an entry. Click on **Query** to get current data whenever you want to make sure actual status of the system.

In some pages, there is the Global setup area (often with a **Set** button) on top of a page. After fill up the fields in this area, you have to click on **Set** to save the modification. Also the Configuration area is often located at the top inside the Data Table.

Global setup area IP Routes

---

System Gateway:  ,  ,  ,

Next No:

	Destination	Net Mask	Gateway
Next →	[ 0 . 0 . 0 . 0 ]	[ 0 . 0 . 0 . 0 ]	[ 0 . 0 . 0 . 0 ]

Page 1 of 2

Delete Select	No	Destination	Net Mask	Gateway
<input type="radio"/>	1	192.168.7.0	255.255.255.0	172.16.10.244
<input type="radio"/>	2	--	--	--
<input type="radio"/>	3	--	--	--

In some pages, you modify the data directly in the entry fields (remember to click on the check box or radio button to select the entry before you click on Modify button; thus the new values can really be saved into the system).

DSL Line Identify Global setup area

---

**DSL Global Configuration**  
 PPP Service Name:  PPP Service Name Check mode:    
 DSLAM Name:  DSLAM Name mode:   
 Dhcp Mode:  ID Select:   
 Circuit ID Type:  Remote ID Type:

**DSL Line ID Configuration**

Select Port	Circuit ID	Remote ID	Trusted
<input type="checkbox"/>	01	IPDSLAM:001:000:00035	IPDSLAM:004
<input type="checkbox"/>	02	IPDSLAM:002:000:00035	IPDSLAM:005
<input type="checkbox"/>	03	IPDSLAM:003:000:00035	IPDSLAM:006
<input type="checkbox"/>	04	IPDSLAM:004:000:00035	IPDSLAM:007
<input type="checkbox"/>	05	IPDSLAM:005:000:00035	IPDSLAM:008

Modify values here

## 4.1 System

---

### 4.1.1 System Information

The System Information page (the default page you'll see after you login the web configuration tool) contains information about the user access level, current system date and time, current boot configuration partition, system MAC address, system HW/SW/FW version, web configuration software version, supported subscriber line type (AnnexA or AnnexB), GBE interface status, and LED status (SYS and ALM).

From the System menu, click on System Info. The following page is displayed:

### System Information

#### ACCESS LOGIN

Access Level	System Date	FW Boot	Active DB	Current DB
Super user	2007/10/22	Partition-2	Partition-2	Partition-2



#### SYSTEM MAC

Bridge MAC	Giga1 MAC	Giga2 MAC
00:30:4F:71:1F:F5	00:30:4F:71:10:F0	00:30:4F:71:1F:FC

#### SYSTEM VERSION

Hardware	Firmware	Software	Web	Circuit:1~48
B	0.74B08	0.74B08	Uc-09.21d	AnnexA

#### GIGA STATUS

Giga1	Giga2	LA	SYS LED	ALM LED
Config Enabled	Config Enabled	Config Disabled		

### 4.1.2 Board IP Setup

This option allows you to configure the Gigabit Ethernet interface and out band management interface including the management IP setting, DHCP configuration, HTTP port setting, etc. From the *System* menu, click on *Board IP Setup*. The following page is displayed:

Board IP Setup

<input type="button" value="Modify"/>		<input type="button" value="RESTART"/>	
Address Management			
GBE (In Band)		MGMT (Out Band)	
IP Address	192 . 168 . 100 . 1	IP Address	172 . 16 . 100 . 23
Subnet Mask	255 . 255 . 255 . 0	Subnet Mask	255 . 255 . 0 . 0
NO Limit VID	<input checked="" type="checkbox"/>	DHCP Client	Disable DHCP Client
Limit VID	<input type="text"/>	DHCP Timeout	60
Priority	0	DHCP Lease	4294967295
HTTP Port	80	MGMT Speed	Auto Negotiate
		Remote IP	192.168.7.168
		System Name	u711F1A
[ <a href="#">System Inventory</a> ]			
<b>Modify the configuration may cause the connection loss</b>			

	Label	Description
<b>GBE (In Band)</b>	IP Address	Type in the IP address of the DSLAM for in-band management.
	Subnet Mask	Type in the in-band subnet mask of the DSLAM.
	No Limit VID	Select this checkbox if no specific in-band management VLAN is required, and the setting in "Limit VID" parameter will be ignored.
	Limit VID	The VLAN ID for individual in-band management VLAN.
	Priority	Select the VLAN priority level (0~7) of the in-band management traffic sent out from GBE port.
<b>MGMT (Out Band)</b>	IP Address	Type in the out-band IP address of the DSLAM.
	Subnet Mask	Type in the out-band subnet mask of the DSLAM.
	DHCP Client	Click on the drop-down list and select Enable, Disable, or Renew (obtain IP address again) DHCP Client function. This option is used to get a dynamic IP address via DHCP for out-band management interface (MGMT port).
	DHCP Timeout	Type in DHCP Timeout (second). Valid value: 1~4294967295. Default is 60.
	DHCP Lease	Type in DHCP lease time (second). Valid value: 1~4294967295.
	HTTP Port	Shows current HTTP port setting for Web access. You can modify http port setting in this field.
	MGMT Speed	Shows current speed / mode of the MGMT port.
	Remote IP	Shows the IP address of the management PC currently connected to this DLSAM.
	System Name	You can modify the name of the system here.
	Modify	Click on this button to submit the modification.
	RESTART	Click on this button to restart the system.

### 4.1.3 Ethernet Port Service

This option allows you to set the administration state, select the speed mode, and select the transmission medium for the Gigabit Ethernet ports. From the *System* menu, click on *Ethernet Port Service*. The following page is displayed:

#### Ethernet Port Setup

Modify						
Port	Admin Status	Selected Speed	Selected Media	Link Status	Current Speed	Current Media
1	Admin ON ▼	AutoNegotiate ▼	SFP First ▼	OFF	down	N/A
2	Admin ON ▼	AutoNegotiate ▼	SFP First ▼	ON	1000M bps	Copper

[ [System Inventory](#) ]

#### Ethernet Port Service Setup

Label	Description
Port	This field shows port number of the Gigabit Ethernet interfaces.
Admin Status	Click on the drop-down list and select the administrative state (ON/OFF) to enable/disable GBE ports.
Selected Speed	Click on the drop-down list and select the speed mode for trunk GBE port. Supported options are: AutoNegotiate, 100Mbps Half (duplex), 100Mbps Full (duplex).
Selected Media	Click on the drop-down list and select the cable mode for trunk GBE port. Options are: SFP First: when both optical and electrical uplinks are connected, optical interface is chosen to transport data. Copper First: when both optical and electrical uplinks are connected, electrical interface is chosen to transport data.
Link Status	Show operational status of the trunk ports (ON/OFF).
Current Speed	Show current speed mode of the trunk ports.
Current Media	Show current uplink transmission medium (via copper or SFP). This field will show N/A when Oper Status is OFF.
Modify	Click on this button to submit the modification.



#### 4.1.4 ADSL Port Service

This option allows you to setup the service status of the line ports and to bind the selected service profiles and spectrum profiles. Also, you can query current setting and the operational status of the line ports. From the *System* menu, click on *ADSL Port Service*.

The following page is displayed:

First click on the drop-down list to select the port range to be displayed. Remember to click on the radio button to select a port to be modified (or select the **All** checkbox to modify all ports of the page at a time).

#### ADSL Circuit Service

Admin  Service Profile  Spectrum Profile  TCA Profile  All

The Service Profile range from 1 to 120  
The Spectrum Profile range from 1 to 120  
The TCA Profile range from 1 to 64

Select	Port	Admin Status	Current Status	Service Profile	Spectrum Profile	TCA Profile
<input checked="" type="radio"/>	1	ON	ON	1	1	1
<input type="radio"/>	2	OFF	OFF	1	1	1
<input type="radio"/>	3	OFF	OFF	1	1	1
<input type="radio"/>	4	OFF	OFF	1	1	1
<input type="radio"/>	5	OFF	OFF	1	1	1
<input type="radio"/>	6	OFF	OFF	1	1	1
<input type="radio"/>	7	OFF	OFF	1	1	1
<input type="radio"/>	8	OFF	OFF	1	1	1
<input type="radio"/>	9	OFF	OFF	1	1	1
<input type="radio"/>	10	OFF	OFF	1	1	1
<input type="radio"/>	11	OFF	OFF	1	1	1
<input type="radio"/>	12	OFF	OFF	1	1	1

[ [SERVICE PROFILE](#) | [SPECTRUM PROFILE](#) | [TCA PROFILE](#) ]


<b>Label</b>	<b>Description</b>
Admin	Click on the drop-down list and select the Administrative status: ON, OFF, or RESET.
Service Profile	Type in the index of the Service Profile (1~120).
Spectrum Profile	Type in the index of the Spectrum Profile (1~120).
TCA Profile	Type in the index of the TCA Profile (1~64).
All	Select the check box to select all circuits of current page.

Modify	Click on this button to submit the modification.
Query	Click on this button to get most recent status of the circuits.
Select	Click on the radio button to select the port to be modified.
Current Status	This field shows the operational status of the line ports. Possible values are ON (enabled), OFF (disabled), and Testing (in loop testing now).

### 4.1.5 CLI Setup

This option allows you to modify the timeout setting for a CLI session and the allowable number of CLI sessions. From the *System* menu, click on *CLI Setup*.

#### CLI Setup



#### CLI Setup

Label	Description
CLI Session	Allowable number of CLI sessions at the same time. Valid value: 1~10.
CLI Timeout	CLI session will be closed once the idle time exceeds this timeout value. Valid value: 180~3600 (sec).
Default	Click on this button to set default values (CLI session: 5, CLI timeout: 300 sec).
Modify	Click on this button to submit the modification.

### 4.1.6 Cluster Setup

This option allows you to setup Cluster function, which can make a group of NEs (network elements) work together as a single NE from the management point of view. Before you group a Master and a Slave IPDSLAM, some parameters need to be well configured:

**1. Cluster domain name:**

The group name for a cluster. Must be the same on Master and Slave.

**2. Cluster IP address:**

IP address to be used for remote management when Master and Slave are grouped together.

**3. NE cluster name:**


A name to identify Master or Slave.

4. Set private IP address on in-band port for both Master and Slave IPDSLAM. The private IP is used for communication between Master and Slave. The management center actually uses Cluster IP address for remote management.


5. Master and Slave need to be configured with same management VLAN.

6. The default gateway should be configured to the router that is aware how to route management traffic to Management Center of the management network. The setting of Cluster default gateway should be the same between Master and Slave.

Currently a IDL-4802 cluster can support up to four cluster members (NEs). The IPDSLAMs in a cluster must all be in-band connected through the GBE ports. There are two possible network topologies for conducting a Clustering Management group: *Daisy chain* and *Star*.



Cluster network topology – Daisy Chain



Cluster network topology – Star

For a cluster in Daisy Chain topology, each IPDSLAM must have one GBE port configured as Uplink and the other one configured as User link.

From the *System* menu, click on *Cluster Setup*. The following page is displayed:

[Cluster Setup](#)

Cluster Configuration			
<input type="button" value="Modify"/>		<input type="button" value="Query"/>	
<b>State</b>	IDLE		
<b>Name</b>	NE1	<b>IP</b>	172 . 31 . 1 . 1
<b>Domain</b>	default	<b>Netmask</b>	255 . 255 . 255 . 0
<b>Role</b>	Individual	<b>Gateway</b>	172 . 31 . 1 . 254
<b>Voting key</b>	0		

By default, the DSLAM is not in a cluster. The state of the Cluster Configuration shows “IDLE” and the Role shows “Individual”.

To make the DSLAM join a cluster, select the Role as “Cluster” or “Slave only” according to your plan and then click on Modify. The state of the Cluster Configuration will show from **DISCOVERING** to **VOTING** to **MASTER** or **SLAVE** at last.

[Cluster Setup](#)

Cluster Configuration			
<input type="button" value="Modify"/>		<input type="button" value="Query"/>	
<b>State</b>	DISCOVERING		
<b>Name</b>	NE1	<b>IP</b>	172 . 31 . 1 . 1
<b>Domain</b>	default	<b>Netmask</b>	255 . 255 . 255 . 0
<b>Role</b>	Cluster	<b>Gateway</b>	172 . 31 . 1 . 254
<b>Voting key</b>	0		

The following figure shows the Cluster Setup page of a cluster containing two cluster members. You will see the following page if you’re connecting directly to the Master via its in-band/ out-band IP address or connecting to the Cluster IP “172.31.1.1”. You can control all the IP DSLAMs in a cluster by connecting to the Cluster IP address, or by directly connecting to the Master IPDSLAM via its in-band or out-band IP address that is configured in the *Board IP Setup* page.

## Cluster Setup

Cluster Configuration					
<input type="button" value="Modify"/> <input type="button" value="Query"/>					
<b>State</b>	MASTER				
<b>Name</b>	<input type="text" value="NE1"/>	<b>IP</b>	<input type="text" value="172 . 31 . 1 . 1"/>		
<b>Domain</b>	<input type="text" value="default"/>	<b>Netmask</b>	<input type="text" value="255 . 255 . 255 . 0"/>		
<b>Role</b>	<input type="text" value="Cluster"/>	<b>Gateway</b>	<input type="text" value="172 . 31 . 1 . 254"/>		
<b>Voting key</b>	<input type="text" value="0"/>				
Cluster Information					
<input type="button" value="Apply"/>					
Select	ID	IP	Role	Name	Domain
<input checked="" type="radio"/>	Local				
<input type="radio"/>	101	192.168.100.1	Master	NE1	default
<input type="radio"/>	102	192.168.100.2	Slave	NE2	default

## Cluster Setup

Label	Description
Name	Type in the NE name in the cluster.
Domain	Type in the name of the cluster domain.
Role	Valid options are: Cluster (Master or Slave is decided by the system), Slave only (role of the DSLAM is always Slave), and Individual (not in a cluster).
Voting Key	Type in 0 or a positive integer as the priority to be Master. 0 means to let system decides Master and Slaves. If positive integer is typed in, the smaller the number is, the higher priority for the DSLAM to be a master in a cluster. But if there's already a Master in a cluster, a new added DSLAM cannot try to be the Master by entering a smaller voting key number; the Master cannot be changed in this way.
IP	Type in the cluster IP address. Users can connect to and manage the cluster via the cluster IP address through in-band connection.
Netmask	Type in the cluster's subnet mask.
Gateway	Type in the cluster's gateway IP address.
Local	Click on this radio button and click on Apply to control the DSLAM you're now directly connected (it will be the Master DSLAM if you're connecting to the cluster via the cluster IP address).
ID	This field shows Cluster ID, which indicates cluster ordering.
Modify	Click on this button to submit the modification.
Query	Click on this button to query current status.
Apply	Once you have selected an entry (NE) in the cluster information table, click on this button to apply your selection.

### To control a member in the cluster:

Select a Cluster member in the Cluster Information table and click on Apply. When switching to that NE successfully, you can see the name of that NE displayed on the left top of the page. You are controlling that NE now. If you click on the **Local** radio button and click on Apply, you'll switch back to the NE you're directly connected to.

Cluster Name=NE2 ,Act ClusterID=102

### Cluster Setup

Cluster Configuration					
Modify		Query			
<b>State</b>	SLAVE				
<b>Name</b>	NE2	<b>IP</b>	172 . 31 . 1 . 2		
<b>Domain</b>	default	<b>Netmask</b>	255 . 255 . 255 . 0		
<b>Role</b>	Slave Only	<b>Gateway</b>	172 . 31 . 1 . 254		
<b>Voting key</b>	0				
Cluster Information					
Apply					
Select	ID	IP	Role	Name Domain	
<input type="radio"/>	Local				
<input type="radio"/>	101	192.168.100.1	Master	NE1	default
<input checked="" type="radio"/>	102	192.168.100.2	Slave	NE2	default

Every time you modify the setting (for example, changing the Role) of any cluster member, the cluster will be reconstructed (cluster state Discovering → Voting → Master or Slave).

If you modify the Role to "Individual", Cluster State will show 'IDLE'. The DSLAM is not in a cluster now.

If you are directly connecting to a Slave in the cluster (connecting via its in-band/out-band IP address), you cannot switch to any other member in the cluster. When you select other member in the table and click on Apply, an error message is displayed on screen.

### 4.1.7 System Inventory

This option allows you to retrieve the system inventory including Description of the System, HW/FW/SW Version, Model Information, Part Number, Hardware Revision, and Serial Number. From the *System* menu, click on *System Inventory*. Click on the **Query** button. The following page is displayed:

#### System Inventory

Query			
Description	Hardware	Firmware	Software
Model Information	Part Number	HW Revision	S/N
48-Port ADSL2/2+ IP DSLAM	B	0.73B05	0.73B05
IDL-4802	GF28U-AR6A-P201B00	B00	G06C042846



#### 4.1.8 System Contact Info

This option allows you to specify the system name, system contact, and system location. From the *System* menu, click on *System Contact Info*. The following page is displayed:

#### System Contact Information

<input type="button" value="Query"/> <input type="button" value="Modify"/>	
<b>Name</b>	IDL-4802
<b>Contact</b>	
<b>Location</b>	
<b>Description</b>	48-Port ADSL2/2+ IP DSLAM

Type in the value you desire, and then click on **Modify** to apply the setting. Click on **Query** to verify if the value is changed.

#### System Contact Info Setup

Label	Description
Name	Type in the system name (1 ~ 32 characters in length).
Contact	Type in the system contact (0 ~ 63 characters in length).
Location	Type in the system location (0 ~ 63 characters in length).
Description	Description of the system (Read-only).

#### 4.1.9 SNTP

This option allows you to setup the Simple Network Time Protocol (SNTP). From the *System* menu, click on *SNTP*. The following page is displayed.

#### Simple Network Time Protocol

Modify	
<b>Time Zone</b>	(25) 0, 0, GMT ,Greenwich Mean Time
<b>System Date</b>	2007 / 7 / 12
<b>System Time</b>	05 : 46 : 36
<b>Polling Interval (60..65535) sec</b>	65535
<b>SNTP Server address</b>	61 . 206 . 115 . 3

#### SNTP Setup

Label	Description
Time Zone	Sets the local time zone by selecting in the Time Zone drop-down list. Sixty-five of the world's time zones are presented (including those using standard time and summer/daylight savings time).
System Date	Sets system date (yyyy/mm/dd).
System Time	Sets system time (hh:mm:ss).
Polling Interval	Sets the polling interval (in seconds) that SNTP client will sync with a designated SNTP server.
SNTP Server address	Sets the dedicated unicast server IP address for which the SNTP client can synchronize its time.
Modify	Click on this button to submit the modification.

#### 4.1.10 IP Routes

This option allows you to configure the IP route table for the in-band and out-band management traffic. From the *System* menu, click on *IP Routes*. The following page is displayed:

Click on the drop-down list to select the page to be displayed first.

#### IP Routes

System Gateway: <input type="text" value="172"/> . <input type="text" value="31"/> . <input type="text" value="1"/> . <input type="text" value="254"/> <input type="button" value="Set"/>			
Next No: <input type="text" value="5"/> <input type="button" value="ADD Next"/>			
	<b>Destination</b>	<b>Net Mask</b>	<b>Gateway</b>
<b>Next</b> →	[ <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> ]	[ <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> ]	[ <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> ]
Page 1 of 2 <input type="button" value="Delete"/>			
<b>Delete Select</b>	<b>No</b>	<b>Destination</b>	<b>Net Mask</b>
<input type="radio"/>	1	192.168.8.0	255.255.255.0
<input type="radio"/>	2	192.168.7.0	255.255.255.0
<input type="radio"/>	3	192.168.9.0	255.255.255.0
<input type="radio"/>	4	192.168.5.0	255.255.255.0
<input type="radio"/>	5	--	--
<input type="radio"/>	6	--	--
<input type="radio"/>	7	--	--
<input type="radio"/>	8	--	--

#### IP Route Setup

Label	Description
System Gateway	This field shows current system default gateway. You can modify the gateway address by typing in new value and then click on <b>Set</b> . If the DSLAM is a Slave in a cluster, this field shows the in-band IP address of the Master; if the DSLAM is a Master in a cluster, this field shows the IP address of the Cluster gateway.
ADD Next	Click on this button to add a new IP route.
Destination	Type in the destination IP address for the new IP route.
Net Mask	Type in the subnet mask for the new IP route.
Gateway	Type in the IP address of the gateway for the new IP route.
Delete Select	Click on the radio button to select a route and then click on <b>Delete</b> to remove this route from the table.


#### 4.1.11 User Administration

This option allows you to administer accounts for users who access the DSLAM. From the *System* menu, click on *User Administration*. Click on *Select*: drop-down list and select a page to display. The following page is displayed:

#### User Administration

Page: Page 1 of 4(No.1 to 8) <input type="button" value="New"/> To Create an new user account need not select radiobox " <input checked="" type="radio"/> "							
<input type="button" value="Delete"/> <input type="button" value="Modify"/>							
The "admin" account supports without deleting.							
(modify/delete) Select	No.	User Name	Level	Aging day	Start Date	Last Login	Comment
<input checked="" type="radio"/>	1	admin	Super	0		2007/07/12	
<input type="radio"/>	2	Test1	Guest	0		2007/07/12	comment2

#### User Administration

Label	Description
Page	Click on the drop-down list and select the page to be displayed.
New	<p>Click on this button to create a new user. You will enter the following page:</p> <p style="text-align: center;"><a href="#">User Administration</a></p> <hr/>  <p>Once you have typed in all the information for the new user, click on the <b>Create</b> button.</p>
Delete / Modify	Click on the radio button on the leftmost column of the user table to select the user you want to delete / modify. Then click on <b>Delete / Modify</b> button. Note that the default <b>admin</b> user cannot be deleted.
User Name	Shows the name of the user (up to 32 characters).
Level	The available access levels include: <b>SUPERUSER, ENGINEER, and GUEST.</b>
Aging day	Set password expiration days (0 for no expiration days)
Start Date	Shows the day when the account was first created.
Last Login	Shows the day when a user last login.
Comment	Description about the user account (up to 31 characters).

When a new account is added: (for example, **Test1** is added)

When user **Test1** intends to login for the first time, he will be asked to change his password (see the figure below) and then login with the new password.

Hi! [Test1](#) Please Change your password!

<b>Old Password:</b>	****
<b>New Password:</b>	*****
<b>Retry Password:</b>	*****
<input type="button" value="SUBMIT"/>	

### 4.1.12 Duplicator

This option allows you to duplicate all/partial the configurations of one selected line port (as a template) to other ports (as many as you want). From the *System* menu, click on *Duplicator*. The following page is displayed. Select the types of configurations (ADSL line configuration, ADSL profiles, or...) you want to duplicate first. Then specify the port number as the template (the source port to be copied), and select the target ports to which the template is going to be copied. At last click on **Paste** to apply.

#### System Duplicator

Templated ADSL Port 1																							
<input type="button" value="Paste"/>																							
To be duplicated ADSL Port:																							
01	<input type="checkbox"/>	02	<input checked="" type="checkbox"/>	03	<input checked="" type="checkbox"/>	04	<input checked="" type="checkbox"/>	05	<input checked="" type="checkbox"/>	06	<input type="checkbox"/>	07	<input type="checkbox"/>	08	<input type="checkbox"/>	09	<input type="checkbox"/>	10	<input type="checkbox"/>	11	<input type="checkbox"/>	12	<input type="checkbox"/>
13	<input type="checkbox"/>	14	<input type="checkbox"/>	15	<input type="checkbox"/>	16	<input type="checkbox"/>	17	<input type="checkbox"/>	18	<input type="checkbox"/>	19	<input type="checkbox"/>	20	<input type="checkbox"/>	21	<input type="checkbox"/>	22	<input type="checkbox"/>	23	<input type="checkbox"/>	24	<input type="checkbox"/>
25	<input type="checkbox"/>	26	<input type="checkbox"/>	27	<input type="checkbox"/>	28	<input type="checkbox"/>	29	<input type="checkbox"/>	30	<input type="checkbox"/>	31	<input type="checkbox"/>	32	<input type="checkbox"/>	33	<input type="checkbox"/>	34	<input type="checkbox"/>	35	<input type="checkbox"/>	36	<input type="checkbox"/>
37	<input type="checkbox"/>	38	<input type="checkbox"/>	39	<input type="checkbox"/>	40	<input type="checkbox"/>	41	<input type="checkbox"/>	42	<input type="checkbox"/>	43	<input type="checkbox"/>	44	<input type="checkbox"/>	45	<input type="checkbox"/>	46	<input type="checkbox"/>	47	<input type="checkbox"/>	48	<input type="checkbox"/>
Select	Function	Decription																					
<input checked="" type="checkbox"/>	ADSL Line Configuration	ADSL Line configuration																					
<input checked="" type="checkbox"/>	ADSL Profiles	Service profile, Specturm profile and TCA profile have serviced in ADSL Port																					
<input checked="" type="checkbox"/>	ADSL Port Admin Status	ADSL line Admin Status																					
<input type="checkbox"/>	DSL Identify Trust	DSL Identify Trusted Status																					
<input type="checkbox"/>	PVC VLAN BRIDGE	ADSL Port PVC,Bridge and VLAN Settings																					
<input type="checkbox"/>	IGMP ACL	IGMP ACL Profile in Binding table																					
<input type="checkbox"/>	FILTERING	All of the Filtering																					
<input type="checkbox"/>	Priority Remark	VLAN Priority Remark table exclude Re-Generation function																					
<input type="checkbox"/>	Priority Re-Generation	The Re-Generation function in VLAN VLAN Priority Remark table																					
<input type="checkbox"/>	Ether policer	Ether policer of the Rate limit table																					

**Note:**

Except the top three functions, every function must be selected with the “PVC VLAN Bridge” function selected, or the configuration cannot be duplicated to other ports.

## 4.2 Bridge

### 4.2.1 Interface Setup

#### 4.2.1.1 GIGA Bridge

This option allows you to setup the GBE (trunk) bridge interfaces. From the *Bridge* menu, click on *Interface Setup* and then *GIGA Bridge*. The following page is displayed:

GIGA Bridge

Select	Port	VID	MaxMac	VPri	VTag	Stack	Ingress	Acc.Frm	Isolation
<input checked="" type="radio"/>	Uplink#1	1	1024	0	Untagged	No Stack	On	ALL	ON
<input type="radio"/>	Uplink#2	2	1024	0	Tagged	No Stack	On	ALL	ON

[ [ADSL PVC CONFIGURATION](#) | [STATIC VLAN](#) ]

#### GIGA (Trunk) Bridge Setup

Label	Description
Mode	Click on the drop-down list and specify the trunk port to be an Uplink or User (especially for system stacking).
VID	Type in the default port VLAN ID. Valid value is 1 ~ 4094.
Max MAC	Type in the maximum number of MAC addresses that can be learned by the giga bridge port (1 ~ 4096).
VLAN	VLAN setting for the traffic. Includes three drop-down lists: <b>Pri-0 ~ 7:</b> Set the default VLAN priority level. <b>UnTagged/Tagged:</b> Select to untag / tag the outgoing (upstream direction for trunk bridge ports) packets. If UnTagged is selected, a double-tagged packet will leave single-tagged (the outer most VLAN tag is removed) and a single-tagged packet will leave untagged. <b>no Stack/Stack:</b> Disable/Enable N:1 VLAN stacking (our system adds the default VLAN tag to all the incoming frames through this port). <i>Note:</i> When an untagged frame enters the IDL-4802, it is assigned the default PVID of the ingress (incoming) bridge port and become a single-tagged frame no matter VLAN stacking is enabled or not.
Ingress	Set Ingress ON: check if the VID of the incoming frame is in the member set. If not in the member set, block the frame. Set Ingress OFF: Ingress filter disabled.
Acc.Frm	Click on the drop-down list and select to accept ALL Frame, only VLAN tagged frame, or only Untagged frame.
Isol	ON/OFF: to enable/disable isolation. When port isolation is enabled, packets received from a trunk port (when both the trunk interfaces are configured as up-link) cannot be forwarded to the other trunk port even for broadcasting.
Modify	To modify the configuration of a giga port: 1. Click on the radio button to select trunk port 1 or port 2 2. Change the parameter values 3. Click on Modify button to apply new values
Query	Click on this button to query current status.
giga-->la	Click on this button to enable LACP (Link Aggregation Control Protocol) function. The LACP is part of IEEE 802.3ad that allows bundling trunk ports together to form a single logical channel. This feature can provide load sharing and failover when link status fails on a port.

When LACP mode is enabled, the following page is displayed:

## GIGA Bridge

Mode: Uplink ▼	VID: 1	MaxMAC: 1024	VLAN: Pri-0 ▼	UnTagged ▼	no Stack ▼		
Ingress: ON ▼	Acc.Frm: (2)ALL Frame ▼	Isolation: ON ▼	Actor Priority: 21845				
<input type="button" value="Modify"/> <input type="button" value="Query"/>							
<input type="button" value="la--&gt;giga"/> <input type="button" value="Aggregator Port"/>							
Select	Port	VID	MaxMac	VPri	VTag	Stack	Ingress
<input checked="" type="radio"/>	<b>UpLink#3 LACP</b>	1	1024	0	Untagged	No Stack	On
<b>Accept Frame</b>		<b>Isolation</b>		<b>Aggregate Or Individual</b>			
ALL		ON		Aggregate Link			
<b>Actor</b>				<b>Partner</b>			
<b>System ID</b>				00:00:00:00:00:00		00:00:00:00:00:00	
<b>System Priority</b>				21845		00000	
<b>Admin Key</b>				0x0001		----	
<b>Oper Key</b>				0x0000		0x0000	
[ <a href="#">ADSL PVC CONFIGURATION</a>   <a href="#">STATIC VLAN</a> ]							

### GIGA Bridge LACP Setup

Label	Description
Mode	Click on this drop-down list and specify the trunk port to be an Uplink or User.
VID	Type in the VLAN ID (1 ~ 4094).
Max MAC	Type in the maximum number of MAC addresses that can be learned by the bridge port.
VLAN	VLAN setting for the egress traffic. Includes three drop-down lists: Pri-0 ~ 7: Set the VLAN priority Level. UnTagged/Tagged: Select to untag / tag the frame no Stack/Stack:: Disable/Enable stacking.
Ingress	Set Ingress ON: check if the VID of the incoming frame is in the member set. If not in the member set, block the frame. Set Ingress OFF: Ingress filter disabled.
AccFrm	Click on the drop-down list and select to accept ALL Frame, only VLAN tagged frame, or only Untagged frame.
Isol	ON/OFF: to enable/disable isolation. When port isolation is enabled, packets received from a trunk port (when both the trunk interfaces are configured as up-link) cannot be forwarded to the other trunk port even for broadcasting.
Actor Priority	Type in the System Priority of the Actor. System Priority is a value indicating the priority value associated with the Actor's System ID. Valid value: 0 ~ 65535.
Modify	Click on this button to submit the modification.
Query	Click on this button to query current status.
la-->giga	Click on this button to leave LACP and go to normal gigabit mode.
Aggregator Port	Click on this button to enter the Aggregator Port setting page.
Aggregate Or Individual	Indicating whether the Aggregation Port is able to Aggregate or is only able to operate as an Individual link.
Actor	The local entity in a Link Aggregation Control Protocol exchange.
Partner	The remote entity in a Link Aggregation Control Protocol exchange.
System ID	A 6-octet MAC address which is a unique identifier for the System that contains this Aggregator.
System Priority	System Priority is a value indicating the priority value associated with the Actor's/Partner's System ID.
Admin Key	The current administrative value of the Key for the Aggregator. The administrative Key value may differ from the operational Key value. The meaning of particular Key values is of local significance.
Oper Key	The current operational value of the Key for the Aggregator. The administrative Key value may differ from the operational Key value. The meaning of particular Key values is of local significance.



Click on **Aggregator Port** in the previous figure, the following page is displayed:

GIGA Bridge

Back	Query								
Apply	Aggregate ports support without setting.								
<b>Aggregation Port1link=[Aggregate]</b> <b>Aggregation Port2link=[Aggregate]</b>									
<b>Actor Admin State</b>	LA_ACT <input checked="" type="checkbox"/> LA_Timeout <input type="checkbox"/> Aggr <input checked="" type="checkbox"/> Sync <input type="checkbox"/> Collect <input type="checkbox"/> Distribute <input type="checkbox"/> Default <input type="checkbox"/> Expire <input type="checkbox"/>								
<b>Actor Oper State</b>	LA_ACT <input type="radio"/> LA_Timeout <input type="radio"/> Aggr <input type="radio"/> Sync <input type="radio"/> Collect <input type="radio"/> Distribute <input type="radio"/> Default <input type="radio"/> Expire <input type="radio"/>								
<b>Partner Admin State</b>									
<b>Partner Oper State</b>	LA_ACT <input type="radio"/> LA_Timeout <input type="radio"/> Aggr <input type="radio"/> Sync <input type="radio"/> Collect <input type="radio"/> Distribute <input type="radio"/> Default <input type="radio"/> Expire <input type="radio"/>								
	<table border="0" style="width: 100%;"> <tr> <td style="width: 25%; text-align: center;">Actor</td> <td style="width: 25%; text-align: center;">Partner</td> <td style="width: 25%; text-align: center;">Actor</td> <td style="width: 25%; text-align: center;">Partner</td> </tr> <tr> <td style="text-align: center;"><b>Admin</b></td> <td style="text-align: center;"><b>Oper</b></td> <td style="text-align: center;"><b>Admin</b></td> <td style="text-align: center;"><b>Oper</b></td> </tr> </table>	Actor	Partner	Actor	Partner	<b>Admin</b>	<b>Oper</b>	<b>Admin</b>	<b>Oper</b>
Actor	Partner	Actor	Partner						
<b>Admin</b>	<b>Oper</b>	<b>Admin</b>	<b>Oper</b>						
<b>LACP Key</b>	0001    0001                      0001                      0001    0000                      0000								
<b>System ID</b>	00:05:65:71:1F:F5                      00:00:00:00:00:00                      00:00:00:00:00:00                      00:00:00:00:00:00								
<b>System Priority</b>	21845                      0                      0                      0								
<b>Port</b>	1                      1                      0                      0								
<b>Port Priority</b>	1                      1                      0                      0								

GIGA Bridge Aggregator Port Setup

\* The following labels may appear in the Actor's or Partner's Administrative/Operational state.

Label	Description
LA_ACT	If the operational state shows LA_ACT ON, this indicates the Activity control is Active LACP; otherwise, the Activity control is Passive LACP.
LA_Timeout	LA_Timeout means the Timeout control value with regard to this link. If the operational state shows LA_Timeout ON, this indicates Short Timeout, otherwise, Long Timeout.
Aggr	If the operational state shows Aggr ON, this indicates that the System considers this link to be Aggregatable; i.e., a potential candidate for aggregation. If not, the link is considered to be Individual; i.e., this link can be operated only as an individual link.

Sync	If the operational state shows Sync ON, the system considers this link to be IN_SYNC; i.e., it has been allocated to the correct Link Aggregation Group, the group has been associated with a compatible Aggregator, and the identity of the Link Aggregation Group is consistent with the System ID and operational Key information transmitted. If Sync OFF, then this link is currently OUT_OF_SYNC; i.e., it is not in the right Aggregation.
Collect	If the operational state shows Collect ON, this means collection of incoming frames on this link is definitely enabled; i.e., collection is currently enabled and is not expected to be disabled in the absence of administrative changes or changes in received protocol information.
Distribute	If the operational state shows Distribute OFF, this means distribution of outgoing frames on this link is definitely disabled; i.e., distribution is currently disabled and is not expected to be enabled in the absence of administrative changes or changes in received protocol information.
Default	If the operational state shows Default ON, this indicates that the Actor's Receive machine is using Defaulted operational Partner information, administratively configured for the Partner. If Default OFF, the operational Partner information in use has been received in a LACPDU.
Expire	If the operational state shows Expire ON, this indicates that the Actor's Receive machine is in the EXPIRED state; if Expire OFF, this indicates that the Actor's Receive machine is not in the EXPIRED state.
LACP Key	The current administrative / operational value of the Key for the Aggregation Port. This is a value between 0000 ~ FFFF. The meaning of particular Key values is of local significance.
System ID	A 6-octet MAC address value that defines the value of the System ID for the System that contains this Aggregation Port.
System Priority	A value that indicates the priority value associated with the Actor's / Partner's System ID. Value range is 0 ~ 65535.
Port	The port number associated with this link assigned to the port by the Actor/Partner. Port number range is 0 ~ 65535.
Port Priority	The current value of the port priority for the protocol Actor / Partner. Value range is 0 ~ 65535.

#### 4.2.1.2 ADSL PVC

This option allows you to setup the ADSL PVC. From the *Bridge* menu, click on *Interface Setup* and then *ADSL PVC*. The following page is displayed:

ADSL PVC Setup

Select	Port	VPI	VCI	Rx Traffic	Tx Traffic	ENCAP	Protocol Base VLAN
<input type="radio"/>	1	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	2	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	3	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	4	0	35	Default	Default	LLC	Disabled
<input checked="" type="radio"/>	5						
<input type="radio"/>	6						
<input type="radio"/>	7						
<input type="radio"/>	8						
<input type="radio"/>	9	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	10	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	11	0	35	Default	Default	LLC	Disabled
<input type="radio"/>	12	0	35	Default	Default	LLC	Disabled

You shall click on the drop-down lists to select port range and PVC first. Then the data of these PVCs (bridge ports) you selected will be displayed. Click on the radio button to select the PVC you want to create, modify, or delete.

ADSL PVC Setup

Label	Description
VPI	Type in the VPI value: 0 ~ 255. Default value is 0.
VCI	Type in the VCI value: 21, 32 ~ 65535. Default value is 35.
Traffic	Click on the drop-down list and select a traffic type for transmit and receive direction respectively. Available options are created in the ATM Traffic Descriptor page.
Encap	Select AAL5 Encapsulation Type: VCMUX, LLC, or AUTO (for PVC#1 ~ PVC#4 only)*.
Protocol Based VLAN	Select in the drop-down list to enable or disable protocol based VLAN function. When protocol based VLAN is enabled, the bridge port will work according to the protocol based VLAN table.
All	Select the check box to copy specified circuit to all remainder circuits in current page.

Create	Click on the radio button to select a PVC (bridge port) that has not been created. Set the parameter values and then click on <b>Create</b> to create a PVC.
Modify	Click on the radio button to select the PVC (bridge port) you want to modify. Change the parameter values and then click on <b>Modify</b> .
Delete	Click on the radio button to select the PVC (bridge port) you want to delete. Then click on <b>Delete</b> to remove the PVC.
Query	Click on this button to get the most recent data.

\*The IDL-4802 supports auto-detection of the ATM AAL5 encapsulation method, LLC or VC-Mux. Meanwhile, the IDL-4802 is also able to automatically sense the following protocol encapsulations: PPPoE over ATM (per RFC 2684), IPoE over ATM bridge mode, and PPP over ATM. IPoA works on individual PVC.

However, there are limitations on auto-detection of encapsulations:

1. LLC/VC-Mux automatically detection is only applicable to PVC#1 ~ PVC#4 of each ADSL port. PVC#5 ~ PVC#8 must be assigned the ATM AAL5 encapsulation method manually.
2. PPPoA works only for PVC#1 ~ PVC#4 and the LLC/VC-Mux automatically detection must be enabled.

Refer to IPoA configuration.

### 4.2.1.3 ADSL Bridge

This option allows you to setup the ADSL bridge interface. From the *Bridge* menu, click on *Interface Setup* and then *ADSL Bridge*. The following page is displayed:

ADSL Bridge

VID: 
 VLAN 
 Pri-0

Ingress 
 AccFrm 
 Isolation 
 Priority Force

ALL

Port 01~12 
 PVC-1

Select	Port	VID	VLAN	Ingress	Acc.Frm	Isolation	Priority Force
<input checked="" type="radio"/>	1	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	2	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	3	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	4	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	5	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	6						
<input type="radio"/>	7	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	8	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	9	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	10	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	11	1	UnTagged / pri-0 / No Stack	ON	ALL	ON	Disbale
<input type="radio"/>	12						

[\[ ADSL PVC CONFIGURATION | STATIC VLAN \]](#)

You shall click on the drop-down lists to select port range and PVC first. Then the data of these PVCs (bridge ports) you selected will be displayed. Click on the radio button to select the bridge port you want to modify.

### ADSL Bridge Setup

Label	Description
VID	Type in the default port VLAN ID. Valid value is 1 ~ 4094.
VLAN	VLAN setting for the egress traffic. Includes three drop-down lists: <b>UnTagged/Tagged:</b> select untagging/tagging the outgoing frames (downstream direction for line bridge port). If UnTagged is selected, a double-tagged packet will leave single-tagged (the outer most VLAN tag is removed) and a single-tagged packet will leave untagged. <b>Pri-0 ~ 7:</b> set the default VLAN priority level. <b>no Stack/Stack/TLS:</b> disable N:1 VLAN stacking / enable N:1 VLAN stacking (our system adds the default VLAN tag to all the incoming frames through this port) / enable TLS (transparent LAN service) so that this bridge port becomes VLAN transparent (refer to DSL Forum, TR-101). A pre-configured S-Tag is used to encapsulate TLS traffic going through this port. That is, an S-Tag

	<p>(PVID here) will be added to all the upstream frames received on this port, and the C-Tags will be the original tags of these frames (no C-Tag for untagged incoming frames). On the other hand, the S-tag will be removed from all the downstream (outgoing) frames.</p> <p><i>Note:</i> When an untagged frame enters the IDL-4802, it is assigned the default PVID of the ingress (incoming) bridge port and become a single-tagged frame no matter VLAN stacking is enabled or not.</p>
Ingress	<p>Set Ingress ON: check if the VID of the incoming frame is in the member set. If not in the member set, block the frame.</p> <p>Set Ingress OFF: Ingress filter disabled.</p>
AccFrm	Click on the drop-down list and select to accept ALL Frame, only VLAN tagged frame, or only Untagged frame.
Isolation	ON/OFF: to enable/disable isolation. When port isolation is enabled, packets received from a line bridge port (including trunk interface configured as user-link) cannot be forwarded to any other line bridge port even for broadcasting.
Priority Force	<p>Click on the drop-down list and select the priority-forcing mode. Options are:</p> <p><b>Disabled:</b> Reserve the original priority of all packets.</p> <p><b>Ingress:</b> Force applying the default VLAN priority value to all the packets received on this bridge port (so this rule will work on all the member-set of this bridge port).</p> <p><b>Egress:</b> Force the priority value of all packets sent out from this bridge port's default VLAN to be the default VLAN priority (so this rule only works on default VLAN of this bridge port).</p> <p><b>Both:</b> Combine the rules of Ingress and Egress.</p>
All	Select the check box to copy specified circuit to all remainder circuits in current page.
Modify	Click on the radio button to select the bridge port you want to modify. Change the parameter values and then click on <b>Modify</b> .
Query	Click on this button to get the most recent data.

#### 4.2.1.4 ADSL Port Security

This option allows you to setup the ADSL port security. From the *Bridge* menu, click on *Interface Setup* and then *ADSL Port Security*. The following page is displayed:

ADSL Port Security

MaxMAC:  MAC Learning:  IP Allowed:

ALL

Port 01~12

Select	Port	Max MAC	MAC Learning	IP Allowed
<input checked="" type="radio"/>	1	4	Enabled	Disabled
<input type="radio"/>	2	4	Enabled	Disabled
<input type="radio"/>	3	4	Enabled	Disabled
<input type="radio"/>	4	4	Enabled	Disabled
<input type="radio"/>	5	8	Enabled	Disabled
<input type="radio"/>	6			
<input type="radio"/>	7	8	Enabled	Disabled
<input type="radio"/>	8	8	Enabled	Disabled
<input type="radio"/>	9	4	Enabled	Disabled
<input type="radio"/>	10	4	Enabled	Disabled
<input type="radio"/>	11	4	Enabled	Disabled
<input type="radio"/>	12			

[ [ADSL PVC CONFIGURATION](#) | [STATIC VLAN](#) ]

You shall click on the drop-down lists to select port range and PVC first. Then the data of these PVCs (bridge ports) you selected will be displayed. Click on the radio button to select the bridge port you want to modify.

#### ADSL Port Security Setup

Label	Description
Max MAC	Type in the maximum number of MAC addresses that can be learned by the ADSL bridge port (1 ~ 128).
MAC Learning	Select to enable/disable MAC learning ability. Sometimes you can disable MAC learning on specified bridge port. This function is for 1:1 VLAN translation scenario.
IP Allowed	Select to enable/disable IP Allowed function. When you enable IP Allowed function on a bridge port, this bridge port will work according to the Static Allowed IP table. So you need to define the source IP addresses that bind to this bridge port. Then the IP packets that contain these source IP addresses can pass through this bridge port; otherwise the packets will be blocked.
All	Select the check box to copy specified circuit to all remainder circuits in current page.
Modify	Click on the radio button to select the bridge port you want to modify. Change the parameter values and then click on <b>Modify</b> .
Query	Click on this button to get the most recent data.

## 4.2.2 VLAN Configuration

### 4.2.2.1 Static VLAN

This option allows you to configure the static VLAN table. From the *Bridge* menu, click on *VLAN Configuration* and then *Static VLAN*. The following page is displayed. Click on the radio button to select *CONFIG VLAN* to configure static VLAN for the bridge ports or *SHOW VLAN* to display the VLAN table.

#### CONFIG VLAN

Click on the drop-down list to select ADSL or GIGA port, and then select a port and PVC if ADSL is selected. Once you have selected the bridge interface, its current static VLAN setting is displayed. To add a new VLAN member, type in VID for the **New VID** field and then select Tagged/UnTagged for **VLAN Tag**, ON/OFF for **Isolation**, and VLAN priority level (specify a number or reserve the original value) for **Priority**. At last click on **Create==>** button. To delete a VLAN, select the checkboxes of the entries you want to delete and then click on **Delete** button.

#### Static VLAN

CONFIG VLAN  SHOW VLAN

ADSL ▾ Port-1 ▾ PVC-1 ▾				
Port	Default VID	VLAN ID List		
ADSL Port1-PVC1	1	5,8		
<input type="checkbox"/> Delete	Added VID	Vlan Tag	Isolation	Priority
<input type="checkbox"/>	5	Tagged ▾	ON ▾	Reserved ▾
<input type="checkbox"/>	8	UnTagged ▾	ON ▾	Reserved ▾
	New VID	Vlan Tag	Isolation	Priority
<input type="button" value="Create==&gt;"/>	[ -- ]	Tagged ▾	ON ▾	Reserved ▾
[ GIGA BRIDGE   ADSL BRIDGE ]				



## SHOW VLAN

In the following page, type in the VID and then click on Query. All the bridge ports belonging to the VLAN and the configuration data of these ports will be displayed in the table.

### Static VLAN

**CONFIG VLAN**  **SHOW VLAN**

No.	Default VID	VLAN Tag	VLAN Priority	Isolated	Egress Port
1	True	UnTagged	Reserved	Enabled	GIGA UPLINK:1
2	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:1-1
3	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:2-1
4	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:3-1
5	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:4-1
6	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:5-1
7	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:7-1
8	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:8-1
9	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:9-1
10	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:10-1
11	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:11-1
12	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:12-1
13	True	UnTagged	Reserved	Enabled	ADSL Port-PVC:6-5

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) ]

### 4.2.2.2 Protocol Base VLAN

This option allows you to configure the protocol based VLAN table. From the *Bridge* menu, click on *VLAN Configuration* and then *Protocol Base VLAN*. The following page is displayed. Select the checkboxes of the entries you want to create or delete. To create a new entry, type in the VLAN ID and select the EtherType (protocol). If you select **Other** for EtherType, type the EtherType value in the rightmost field.

#### Protocol Base VLAN

(1)Page1 of 4				
<input type="button" value="Create"/> <input type="button" value="Delete"/> <input type="button" value="Query"/>				
Select	NO	VLAN ID (1..4094)	EtherType	
<input type="checkbox"/>	1	1	PPPoE Discovery Stage	--
<input type="checkbox"/>	2	2	PPPoE Session Stage	--
<input checked="" type="checkbox"/>	3	3	Other	0x 8035
<input type="checkbox"/>	4		Select	0x
<input type="checkbox"/>	5		Select	0x
<input type="checkbox"/>	6		Select	0x
<input type="checkbox"/>	7		Select	0x
<input type="checkbox"/>	8		Select	0x
[ STATIC VLAN ]				

### 4.2.2.3 Translation VLAN

This option allows you to configure the translation VLAN table, which defines some special VLAN working rules such as VLAN stack, VLAN cross-connect, etc. Before you configure the Translation VLAN table for a line bridge port, you shall configure the Static VLAN table for this line bridge port and the GIGA bridge port in advance. Also, you shall disable VLAN stacking feature of this line bridge port in the ADSL bridge interface setup page, otherwise the VLAN translation rule here will not take effect. From the *Bridge* menu, click on *VLAN Configuration* and then *Translation VLAN*. The following page is displayed. Click on the radio button to select translation Mode first.

Translation VLAN

---

1:1 User Mode  
  N:1 User Mode  
  C\_VLAN Stacking Replaced Mode

sTag ether type: 0x 8100

ADSL Port-1 PVC-1

Port	Default VID	VLAN ID List			
ADSL Port1-PVC1	1	1,5,8			
<input type="button" value="Delete"/>	ADSL VID	UPLINK Port	UPLINK VID	UPLINK Priority	VLAN MODE
<input type="checkbox"/>	5	GIGA1	1	RESERVED	REPLACED
<input type="checkbox"/>	8	GIGA1	8	RESERVED	STACKING
	ADSL VID	G1/LA UPLINK VID	G2 UPLINK VID	UPLINK Priority	VLAN MODE
<input type="button" value="Create==&gt;"/>	1	Select	G2_VID:2	6	REPLACED

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) | [STATIC VLAN](#) ]

Actually the IDL-4802 provides five translation modes: four for 1:1 VLAN, one for N: 1 VLAN.

#### 1:1 VLAN (including 1:1 User Mode and C\_VLAN Stacking Replaced Mode):

If the ADSL user bridge port only has 1:1 VLAN, then MAC learning function of this bridge port can be disabled.

##### 1. Reserved

In this mode, the system does not make any change on C-Tag. That is the uplink port's S-Tag is actually the C-Tag. The system provides a tunnel for the user port and uplink port. And one VLAN ID can only make one tunnel.

##### 2. Replaced

In this mode, the system will change the user port's C-Tag to the Uplink port's S-Tag. And the mapping is one to one, that is, one user port's C-Tag (one VID) can only translate to one uplink port's S-Tag (one VID), and vice versa. For example, for ADSL Port1-PVC1, if ADSL VID 5 translates to GIGA1 VID 1, then you cannot make ADSL VID 5 translate to another GIGA VID. You also cannot make another ADSL VID translate to GIGA VID1.

Upstream:

C-Tag→(User port)-----(Uplink port)→S-Tag

Downstream:

S-Tag→(Uplink port)-----(User port)→C-Tag

### 3. Stacking

In this mode, the system will add S-TAG before user port's C-TAG. Note that the mapping from C-Tag to S-Tag+C-Tag is still one to one. So a user port's C-Tag can't be used for another translation rule, as well as an uplink port's S-Tag+C-Tag.

Upstream:

C-Tag→(User port)------(Uplink port)→S-Tag+C-Tag

Downstream:

S-Tag+C-Tag→(Uplink port)------(User port)→C-Tag

### 4. Stacking and Replaced

In this mode, the system will replace the user port's C-Tag to C'-Tag and add S-Tag before C'-Tag. Note that the mapping from C-Tag to S-Tag+C'-Tag is still one to one. So a user port's C-Tag can't be used for another translation rule, as well as an uplink port's S-Tag+C'-Tag.

Upstream:

C-Tag→(User port)------(Uplink port)→S-Tag+C'-Tag

Downstream:

S-Tag+C'-Tag→(Uplink port)------(User port)→C-Tag

#### Translation VLAN

1:1 User Mode   
  N:1 User Mode   
  C\_VLAN Stacking Replaced Mode

---

sTag ether type:

| 
  |

Port	Default VID	VLAN ID List					
ADSL Port1-PVC1	1	1					

<input type="button" value="Delete"/>	ADSL VID	UPLINK Port	UPLINK VID	New CVLAN ID	New CVLAN Priority	UPLINK Priority	VLAN MODE
	ADSL VID	G1/LA UPLINK VID	G2 UPLINK VID	New CVLAN ID	New CVLAN Priority	UPLINK Priority	VLAN MODE

| 
  | 
  | 
  | 
 [ 5 ] | 
  | 
  |

| 
  |

**N:1 VLAN (N:1 User Mode):**

N:1 can also be called shared VLAN, so in this mode MAC learning function of the bridge ports must not be disabled.

**1. Replaced N:1**

In this mode, the system will change the user port's C-Tag to the Uplink port's S-Tag. And the mapping is N to 1, so a user port's C-Tag can't be used for another VLAN translation rule. But an uplink port's S-Tag can be used for another N:1 VLAN translation rule.

So in this mode several bridge ports can have the same VLAN cross-connect rule.

Translation VLAN

1:1 User Mode  N:1 User Mode  C\_VLAN Stacking Replaced Mode

sTag ether type: 0x 8100

ADSL  PVC-1


Port	Default VID	VLAN ID List			
ADSL Port1-PVC1	1	1,5,8			
<input type="button" value="Delete"/>	ADSL VID	UPLINK Port	UPLINK VID	UPLINK Priority	VLAN MODE
<input type="checkbox"/>	5	GIGA1	1	RESERVED	REPLACED N:1
<input type="checkbox"/>	8	GIGA1	1	5	REPLACED N:1
ADSL VID	G1/LA UPLINK VID	G2 UPLINK VID	UPLINK Priority	VLAN MODE	
<input type="button" value="Create==&gt;"/>	1 <input type="button" value="Select"/>	<input type="button" value="Select"/>	<input type="button" value="Select"/>	<input type="button" value="Select"/>	REPLACED N:1 <input type="button" value="Select"/>

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) | [STATIC VLAN](#) ]

#### 4.2.2.4 Static Allowed IP

This option allows you to configure the Static Allowed IP table. From the *Bridge* menu, click on *VLAN Configuration* and then *Static Allowed IP*. The following page is displayed. To make bridge port work according to this Static Allowed IP table, the IP allowed function must be enabled.

#### Static Allowed IP

**CONFIG ALLOWED IP** 

Delete	Select	No	Port	VLAN ID	Allowed Source IP
<input type="checkbox"/>	<input type="checkbox"/>	1	ADSL Port1-PVC1	1	172.2.0.1
<input type="checkbox"/>	<input type="checkbox"/>	2	ADSL Port8-PVC1	8	172.2.0.1

ADSL  Port-1  PVC-1

VLAN ID:

Allowed IP:  .  .  .

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) ]

Click on the drop-down lists to select ADSL port and PVC number, then type in VID and allowed source IP that can pass through the VLAN.

### 4.2.2.5 MAC Spoofing

This option allows you to enable/disable anti-MAC Spoofing function and MAC-Spoofing detection log function. From the *Bridge* menu, click on *VLAN Configuration* and then *MAC Spoofing*. The following page is displayed.

#### MAC Spoofing

Spoofing <input type="button" value="ON"/> Log <input type="button" value="OFF"/> <input type="button" value="Set"/> <input type="button" value="Query"/>			
No	Port	VLAN ID	MAC
[ GIGA BRIDGE   ADSL BRIDGE ]			

#### MAC Spoofing Setup

Label	Description
Spoofing	Click on the drop-down list to select: <b>OFF:</b> The system is able to provide service to users with duplicate MAC addresses. <b>ON:</b> The system is able to deny service to users with duplicate MAC addresses.
Log	Click on the drop-down list to select: <b>OFF:</b> No log of MAC spoofing data when detected. <b>ON:</b> The system provides log when duplicated MAC addresses detected.
Set	Click on this button to apply the setting.
Query	Click on this button to get the MAC spoofing information (the Log function must be enabled).

### 4.2.3 Spanning Tree

Spanning Tree Protocol (STP) can detect and eliminate network loops and provide backup links between bridges or switches. It allows a device to interact with other STP-aware devices to ensure that only one path exists between any two stations on the network.

**BPDU:** STP-aware devices exchange Bridge Protocol Data Units (BPDUs) periodically. When the bridged LAN topology changes, a new spanning tree is constructed.

**Root Bridge:** the base of the spanning tree. It is the bridge with the lowest identifier value (Bridge ID, which is a field in the BPDU).

**Path Cost:** the transmission cost sum of transmitting a frame to the Root Bridge through that path. The transmission cost is assigned according to the speed of the link to which a port is attached. The slower the media is, the higher the cost become - see the following table.

Transmission Cost

Link	Recommended	Recommended Cost
4Mbps	250	100 to 1000
10Mbps	100	50 to 600
16Mbps	62	40 to 400
100Mbps	19	10 to 60
1Gbps	4	3 to 10
10Gbps	2	1 to 5

**Root Port:** On a Non-Root Bridge, the port having the lowest path cost to the Root Bridge.

**Designated Port:** Each LAN segment has a Designated Port. If one port is determined to have the lowest path cost, it becomes the Designated Port for that segment. If there is more than one port having the same path cost in a segment, the port having the lowest Bridge ID will be selected to be the Designated Port. For a Root Bridge, each port on it is a Designated Port for the connected segment.

After the STP determined the lowest cost-spanning tree, it enables all the root ports and designated ports and disables all other ports that participate in the spanning tree. Network packets are therefore only forwarded between enabled ports, eliminating any possible network loops.

Once a stable network topology has been established, all devices listen for Hello BPDUs transmitted from the Root Bridge. If a device does not get a Hello BPDU after a predefined interval (Max Age), the device assumes that the link to the root bridge is down. This device then will negotiate with other devices to re-establish a valid network topology.

STP assigns five port states (see the following table) to eliminate packet looping. A device port is not allowed to go directly from blocking state to forwarding state so as to eliminate transient loops.

Port States

Port State	Description
Disabled	STP is disabled (default).
Blocking	Only configuration and management BPDUs are received and processed.
Listening	All BPDUs are received and processed.
Learning	All BPDUs are received and processed. Information frames are submitted to the learning process but not forwarded.
Forwarding	All BPDUs are received and processed. All information frames are received and forwarded.



### 4.2.3.1 Protocol

This page allows you to setup the STP Bridge. From the *Bridge* menu, click on *Spanning Tree* and then *Protocol*. The following page is displayed:

#### Spanning Tree Protocol

STP: Disabled <input type="radio"/> Enabled <input checked="" type="radio"/>	
Version: RSTP <input checked="" type="radio"/> STP <input type="radio"/>	
Priority:	32768
HelloTime:	2
ForwardDelay:	15
MaxAge:	20
<input type="button" value="Modify"/>	
<b>STP Current Status</b>	Enabled
<b>Running Version</b>	RSTP
<b>Bridge ID</b>	8000000565711FF5
<b>The version of STP is being run</b>	IEEE802.1W(4)
<b>Time Since Last Topology Change</b>	85
<b>The total number of Topology changes</b>	6
<b>Designated Root</b>	8000000565711FF5
<b>Root Cost</b>	0
<b>Root Port(hex)</b>	N/A
<b>Hold Time</b>	3
<b>Bridge Priority(hex)</b>	0x8000
<b>Bridge Hello Time</b>	2
<b>Bridge Forward Delay</b>	15
<b>Bridge Max Age</b>	20
The maxage, hellotime and forwarddelay times are constrained as follows: $2 \times (\text{forwarddelay} - 1) \geq \text{maxage} \geq 2 \times (\text{hellotime} + 1)$	

#### STP Bridge Settings

Label	Description
Disable / Enable	Specify whether or not the system is to implement the spanning tree protocol.
Modify	Once you have modified the parameters, click on this button to submit the modification.
Version	Select RSTP (IEEE 802.1W) or STP (IEEE 802.1D).
Priority	Sets the spanning tree protocol priority. The lower the priority number, the more significant the bridge becomes in protocol terms. Where two bridges have the same priority, their MAC address is compared and the smaller MAC address is treated as the most significant. The priority can be any value between 0 and 61440 in step of 4096. Default value is 32768.
MaxAge	Sets the maximum age of received spanning tree protocol information before it is discarded. This is used when the bridge is or is attempting to become the root bridge.  This can be any value (in seconds) between 6 and 40. BUT it is constrained by the hellotime and forwarddelay times.

	Default value is 20.
Hello Time	<p>Sets the time after which the spanning tree process sends notification of topology changes to the root bridge. This is used when the bridge is or is attempting to become the root bridge. This can be any value (in seconds) between 1 and 2. BUT it is constrained by the maximum age and forwarddelay times.</p> <p>Default value is 2.</p>
Forwarding Delay	<p>Sets the time that the bridge spends in listening or learning states when the bridge is or is attempting to become the root bridge. This can be any value (in seconds) between 4 and 30. BUT it is constrained by the maxage and hellotimes.</p> <p>The maxage, hellotime and forwarddelay times are constrained as follows:</p> $2 \times (\text{forwarddelay} - 1) \geq \text{maxage}$ $\text{maxage} \geq 2 \times (\text{hellotime} + 1)$ <p>For example, the default settings are:</p> $2 \times (15 - 1) \geq 20$ $20 \geq 2 \times (2 + 1)$
Current Status	Current system STP setting and status are shown in the Current Status table.

### 4.2.3.2 Port Setting

This page allows you to setup the STP Port. From the *Bridge* menu, click on *Spanning Tree* and then *Port Settings*. The following page is displayed:

#### STP Port Settings

Priority	128	Edge Type	Edge-False	Path Cost	100	Modify					
Select	Port	Priority	Edge	Path Cost	State	Designated Root	Designated Cost	Designated Bridge	Designated Port	Transit Forward	
<input checked="" type="radio"/>	Giga1	0x80	False	100	FORWARDING	80000211223344AA	0	80000211223344AA	0x8001	1	
<input type="radio"/>	Giga2	0x80	False	100	FORWARDING	80000211223344AA	0	80000211223344AA	0x8002	1	
[ SPANNING TREE PROTOCOL ]											

#### STP Port Settings


Label	Description
Priority	Type in the priority level of the port (0 ~ 240 in step of 16).
Edge Type	Click on this drop-down list and select RSTP type: Edge-True or Edge-False.
Path Cost	Type in the Path Cost through the port (1 ~ 65535 integer number).
Modify	Select the trunk link in the table, type in or select new value for the above fields, and then click on this button to submit the modification.

## 4.2.4 Access Control

### 4.2.4.1 Filtering


This option allows you to setup the filter rule for the packets. From the *Bridge* menu, click on *Access Control* and then *Filtering*. The following page is displayed. Click on *Filtering Type* drop-down list to select a filtering type first.

#### Filtering



## Protocol Filtering

#### Protocol Filtering



#### Protocol Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
ADSL Port1-PVC1	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Protocol	Click on this drop-down list and select a protocol to deny: ICMP, IGMP, IP in IP, TCP, GRP, IGP, UDP, GRE, EIGRP, or OSPF.
Create	Click on this button to create a new filter rule in the table.

## Source MAC Filtering

### Source MAC Filtering

Filtering Type  No. From  To

No range from 1 to 256

No.	Port	Source MAC
1	GIGA1	03:ae:00:ee:00:ff

Next No:

Source MAC

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) | [STATIC VLAN](#) ]

### Source MAC Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Source MAC	Type in the MAC Address of the source.
Create	Click on this button to create a new filter rule in the table.

## IP Address Filtering

### Source IP Address Filtering

Filtering Type <input type="text" value="Source IP"/> No. From <input type="text" value="1"/> To <input type="text" value="2"/>			
No range from 1 to 256			
<input type="button" value="Query"/>		<input type="button" value="Delete"/>	
No.	Port	Source IP	Subnet Mask
1	GIGA1	172.16.100.77	255.255.255.0
2	ADSL Port1-PVC1	172.16.100.66	255.255.0.0
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>			
Next No: <input type="text" value="3"/>			
Source IP <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>		MASK <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	
<input type="button" value="Create"/>			
[ <a href="#">GIGA BRIDGE</a>   <a href="#">ADSL BRIDGE</a>   <a href="#">STATIC VLAN</a> ]			

### Source IP Address Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Source IP	Type in the IP Address of the source.
MASK	Type in the subnet mask.
Create	Click on this button to create a new filter rule in the table.

## Layer 4 Destination Port Filtering

### Layer 4 Destination Port Filtering

Filtering Type	<input type="text" value="L4 Dest Port"/>	No. From	<input type="text" value="1"/>	To	<input type="text" value="1"/>
No range from 1 to 256					
<input type="button" value="Query"/>		<input type="button" value="Delete"/>			
No.	Port	L4 Destination PORT			
1	ADSL Port1-PVC1	65535			
<input type="text" value="ADSL"/>		<input type="text" value="Port-1"/>		<input type="text" value="PVC-1"/>	
Next No:	<input type="text" value="2"/>	Destination Port	<input type="text" value="65535"/>	<input type="button" value="Create"/>	
[ <a href="#">GIGA BRIDGE</a>   <a href="#">ADSL BRIDGE</a>   <a href="#">STATIC VLAN</a> ]					

### Layer 4 Destination Port Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Destination Port	Type in the Destination Port number (1 ~ 65535).
Create	Click on this button to create a new filter rule in the table.

## Destination IP Filtering

### Destination IP Filtering

Filtering Type:  No. From:  To:   
 No range from 1 to 256

No.	Port	Destination IP	Subnet Mask
1	ADSL Port2-PVC1	172.16.100.25	255.255.0.0

Next No:   
 Destination IP:     MASK:

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) | [STATIC VLAN](#) ]

### Destination IP Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Destination IP	Type in the Destination IP address.
MASK	Type in the subnet mask.
Create	Click on this button to create a new filter rule in the table.



## Destination MAC Filtering

### Destination MAC Filtering

Filtering Type: Destination MAC No. From: 1 To: 5

No range from 1 to 256

Query Delete

No.	Port	Destination MAC
1	ADSL Port1-PVC1	11:22:33:44:55:66

ADSL Port-1 PVC-1

Next No: 2

Destination MAC: 00 00 00 00 00 00

Create

[ [GIGA BRIDGE](#) | [ADSL BRIDGE](#) | [STATIC VLAN](#) ]

### Destination IP Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<span style="border: 1px solid black; padding: 2px;">ADSL</span> <span style="border: 1px solid black; padding: 2px;">Port-1</span> <span style="border: 1px solid black; padding: 2px;">PVC-1</span>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Destination MAC	Type in the Destination MAC address.
Create	Click on this button to create a new filter rule in the table.

## Ether Type Filtering

### Ether Type Filtering

Filtering Type	<input type="text" value="Ether Type"/>	No. From	<input type="text" value="1"/>	To	<input type="text" value="5"/>
No range from 1 to 256					
<input type="button" value="Query"/> <input type="button" value="Delete"/>					
No.	Port	Ether Type			
1	ADSL Port1-PVC1	0x8100			
2	ADSL Port2-PVC1	0x8035			
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>					
Next No:	<input type="text" value="3"/>	Incoming EtherType	<input type="text" value="0x"/>	<input type="button" value="Create"/>	
<a href="#">[ GIGA BRIDGE   ADSL BRIDGE   STATIC VLAN ]</a>					

### Destination IP Filtering Setup

Label	Description
Filtering Type	You can also select the filtering type here.
No. From...To...	Type in the range of serial number in the filter rule table. Valid number value: 1 ~ 256.
Query	Once you have specified the serial number, click on this button to display the filter rules.
Delete	Once you have specified the serial number, click on this button to delete the filter rules in the table.
<input type="text" value="ADSL"/> <input type="text" value="Port-1"/> <input type="text" value="PVC-1"/>	Click on these drop-down lists to select an ADSL bridge port or GIGA bridge port.
Incoming Ether Type	Type in the EtherType value (hexadecimal).
Create	Click on this button to create a new filter rule in the table.

#### 4.2.4.2 VLAN Priority Remark

This option allows you to configure the VLAN priority. From the *Bridge* menu, click on *Access Control* and then *VLAN Priority Remark*. The following page is displayed:

#### VLAN Priority Remark

VPRI Remark [Select]
<b>VLAN Priority Remark Table</b>
(1) Type of Service(TOS) Remark
(2) IP Source Remark
(3) IP Destination Remark
(4) MAC Source Remark
(5) MAC Destination Remark
(6) VLAN ID Remark
(7) VLAN Priority Regen(Re-Generation)
(8) Differentiated Services (DSCP)
(9) Protocol Remark
(10) Ether Type Remark
[ <a href="#">GIGA BRIDGE</a>   <a href="#">ADSL BRIDGE</a>   <a href="#">STATIC VLAN</a> ]

Click on the *VPRI Remark* drop-down list and select a type of VLAN Priority Remark. Available options include Type of Service (TOS), IP Source, IP Destination, MAC Source, MAC Destination, VLAN ID, VLAN Priority Regeneration, Differentiated Services (DSCP), Protocol, and Ether Type.

✧ TOS

VLAN TOS Priority Remark

VPRI Remark (1)TOS No. From 1 To 1  
 No range from 1 to 256  
 Query Delete

No.	Port	Incoming TOS	Outgoing Vlan Priority
1	ADSL Port1-PVC1	1	3

ADSL Port-1 PVC-1

Next No: 2  
 TOS 0  
 Priority(Out) 0 Create

[ GIGA BRIDGE | ADSL BRIDGE | STATIC VLAN ]

VLAN Priority Remark Setup - TOS

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
ADSL Port-1 PVC-1	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
TOS	In order to provide basic support for classes of service to the Internet Protocol. The IP protocol header contains what is known as the ToS (Type of Service) bits. Click on the drop-down list and select incoming TOS (value range 0 ~ 7), then you can create the mapping between TOS and VLAN priority.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ IP Source

VLAN IP Source Priority Remark

VPRI Remark (2)IP Source No. From 1 To 1  
 No range from 1 to 256  
 Query Delete

No.	Port	IP Source ADDRESS	Subnet Mask	Outgoing Vlan Priority
1	ADSL Port1-PVC1	172.113.006.000	255.255.000.000	2

ADSL Port-1 PVC-1

Next No: 2  
 Source IP 0 0 0 0 MASK 0 0 0 0  
 Priority(Out) 0 Create

[ GIGA BRIDGE | ADSL BRIDGE | STATIC VLAN ]

VLAN Priority Remark Setup – IP Source

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
ADSL Port-1 PVC-1	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Source IP	Type in the IP address of the coming source.
MASK	Type in the subnet mask.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ IP Destination

VLAN IP Destination Priority Remark

VPRI Remark (3)IP Destination No. From 1 To 1  
 No range from 1 to 256  
 Query Delete

No.	Port	IP Destination ADDRESS	Subnet Mask	Outgoing Vlan Priority
1	GIGA1	172.023.002.002	255.255.000.000	7

GIGA GIGA1

Next No: 2  
 Destination IP 0 0 0 0 MASK 0 0 0 0  
 Priority(Out) 0 Create

[ GIGA BRIDGE | XDSL BRIDGE | STATIC VLAN ]

VLAN Priority Remark Setup – IP Destination

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
GIGA GIGA1	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Source IP	Type in the IP address of the coming source.
MASK	Type in the subnet mask.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ **MAC Source**

VLAN MAC Source Priority Remark

VPRI Remark: (4)MAC Source    No. From: 1    To: 1 No range from 1 to 256 <input type="button" value="Query"/> <input type="button" value="Delete"/>			
No.	Port	MAC Source ADDRESS	Outgoing Vlan Priority
1	GIGA1	10:ee:00:ff:00:25	1
<input type="button" value="GIGA"/> <input type="button" value="GIGA1"/>			
Next No: 2 Source MAC: <input type="text" value="00"/> <input type="text" value="00"/> <input type="text" value="00"/> <input type="text" value="00"/> <input type="text" value="00"/> <input type="text" value="00"/>			
Priority(Out): <input type="text" value="0"/> <input type="button" value="Create"/>			
<a href="#">[ GIGA BRIDGE   XDSL BRIDGE   STATIC VLAN ]</a>			

VLAN Priority Remark Setup – MAC Source

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
<input type="button" value="GIGA"/> <input type="button" value="GIGA1"/>	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Source MAC	Type in the MAC Address of the coming source.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ **MAC Destination**

VLAN MAC Destination Priority Remark

VPRI Remark (5)MAC Destination No. From 1 To 1  
 No range from 1 to 256  
 Query Delete

No.	Port	MAC Destination ADDRESS	Outgoing Vlan Priority
1	GIGA1	12:aa:00:bc:e1:00	7

GIGA GIGA1

Next No: 2

Destination MAC 00 00 00 00 00 00

Priority(Out) 0 Create

[ GIGA BRIDGE | XDSL BRIDGE | STATIC VLAN ]

VLAN Priority Remark Setup – MAC Destination

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
GIGA GIGA1	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Destination MAC	Type in the MAC Address of the destination.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.



✧ VLAN ID

VLAN ID Priority Remark

VPRI Remark (6))VLAN ID  No. From  To

No range from 1 to 256

No.	Port	VLAN ID	Outgoing Vlan Priority
1	GIGA1	1	2
2	GIGA1	5	0

GIGA  GIGA1

Next No:

VLAN ID:

Priority(Out)

[ [GIGA BRIDGE](#) | [XDSL BRIDGE](#) | [STATIC VLAN](#) ]

VLAN Priority Remark Setup – VLAN ID

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
<input type="button" value="GIGA v"/> <input type="button" value="GIGA1 v"/>	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
VLAN ID	Type in the VLAN ID (1 ~ 4094).
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

## ✧ VLAN Priority Regeneration

### VLAN Priority Re-Generation

VPRI Remark (7)VLAN Priority Regen  No. From  To

No range from 1 to 1024

No.	Port	Incoming Vlan Priority	Outgoing Vlan Priority
1	GIGA1	0	3
2	GIGA1	2	5

GIGA  GIGA1

Next No:

Priority(In)

Priority(Out)

[ [GIGA BRIDGE](#) | [XDSL BRIDGE](#) | [STATIC VLAN](#) ]

### VLAN Priority Remark Setup – VLAN Priority Regeneration

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
<input type="button" value="GIGA"/> <input type="button" value="▼"/> <input type="button" value="GIGA1"/> <input type="button" value="▼"/>	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Priority (In)	Click on the drop-down list and select the incoming VLAN Priority (0 ~ 7).
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ **Differentiated Services**

VLAN DSCP Priority Remark

VPRI Remark: (8)DiffServe No. From 1 To 2  
 No range from 1 to 256  
 Query Delete

No.	Port	Incoming DSCP	Outgoing Vlan Priority
1	GIGA1	DEFAULT	0
2	GIGA1	AF12 001100	1

GIGA GIGA1

Next No: 3  
 Incoming DS: (00)DEFAULT  
 Priority(Out): 0 Create

[ GIGA BRIDGE | XDSL BRIDGE | STATIC VLAN ]

VLAN Priority Remark Setup – Differentiated Services

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Incoming DS	Click on the drop-down list and select the incoming DSCP (Diffserv Code Points, which is a 6-bit number). The standardized combinations are listed below: default      Default value (bits:000000) af11      Assured Forwarding Class 1:Low Drop (bits:001010) af12      Assured Forwarding Class 1:Medium Drop (bits:001100) af13      Assured Forwarding Class 1:High Drop (bits:001110) af21      Assured Forwarding Class 2:Low Drop (bits:010010) af22      Assured Forwarding Class 2:Medium Drop (bits:010100) af23      Assured Forwarding Class 2:High Drop (bits:010110)

	af31 Assured Forwarding Class 3:Low Drop (bits:011010) af32 Assured Forwarding Class 3:Medium Drop (bits:011100) af33 Assured Forwarding Class 3:High Drop (bits:011110) af41 Assured Forwarding Class 4:Low Drop (bits:100010) af42 Assured Forwarding Class 4:Medium Drop (bits:100100) af43 Assured Forwarding Class 4:High Drop (bits:100110) ef Expedited Forwarding (bits:101110)
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

✧ Protocol

VLAN Protocol Priority Remark

VPRI Remark (9) Protocol Remark  No. From 1 To 1  
 No range from 1 to 256

No.	Port	Incoming Protocol	Outgoing Vlan Priority
1	GIGA1	ICMP	0

GIGA

Next No: 2  
 Incoming Protocol (01) ICMP

[ [GIGA BRIDGE](#) | [XDSL BRIDGE](#) | [STATIC VLAN](#) ]

VLAN Priority Remark Setup – Protocol

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
<input type="button" value="GIGA"/> <input type="button" value="GIGA1"/>	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Incoming Protocol	Click on the drop-down list and select the incoming protocol. Available options are: ICMP, IGMP, IP in IP, TCP, GRP, IGP, UDP, GRE, IGRP, or OSPF.
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

## ✧ Ether Type

### VLAN Priority Remark

VPRI Remark (10) Ether Type Remark  No. From  To

No range from 1 to 256

No.	Port	Incoming EtherType	Outgoing Vlan Priority
1	GIGA1	0x8100	0

GIGA  GIGA1

Next No:

Incoming EtherType 0x

Priority(Out)

[ [GIGA BRIDGE](#) | [XDSL BRIDGE](#) | [STATIC VLAN](#) ]

### VLAN Priority Remark Setup – Ether Type

Label	Description
VPRI Remark	You can also select the priority remark type here.
No. From ...To...	Type in the range of entry number in the table you want to view (value range is 1~256).
Query	To query entries, type in the entry number range and then click on this button to retrieve.
Delete	To delete entries, type in the entry number range and then click on this button to delete.
<input type="text" value="GIGA"/> <input type="text" value="GIGA1"/>	Click on these drop-down list to select an ADSL bridge port or GIGA bridge port.
Incoming EtherType	Type in the EtherType value (hexadecimal).
Priority (Out)	Click on the drop-down list and select the outgoing VLAN priority (0 ~ 7).
Create	Click on this button to create a new entry in the table.

### 4.2.4.3 Rate Limit

This option allows you to limit the rate of broadcast/multicast packets that are received on a VLAN, and configure the Three Color Marking (TCM) Policer profile. From the *Bridge* menu, click on *Access Control* and then *Rate Limit*. The following page is displayed. Click on the *Rate Limit Type* drop-down list and select the item you want to setup.

#### Rate Limit [Select]

### ✧ Rate Limit Broadcast

#### Rate Limit Broadcast

#### Rate Limit Broadcast Setup

Label	Description
Rate Limit Type	Click on this drop-down list and select the item you want to setup.
Committed Information Rate	Committed Information Rate (1536 ~ 1G bits per second). The threshold rate to turn on the rate-limit mechanism.
Leaky Bucket	Leaky bucket size. The unit is millisecond. This parameter ranges from 1 to 1024. The bucket depth is the product of CIR and this parameter.
Modify	Click on this button to modify data in the table.
Query	Click on this button to get most recent status.

## ✧ Rate Limit Flooding

### Rate Limit Flooding

Rate Limit Type: <input type="text" value="Flooding"/>		
Flooding VID: <input type="text" value="1"/>	Committed Information Rate: <input type="text" value="80000"/>	1536~1000000000(Bits/sec)
Leaky Bucket: <input type="text" value="40"/>	1~1024 (Milli-sec)	
<input type="button" value="Modify"/>	<input type="button" value="Query"/>	
Flooding VID: <input type="text" value="1"/>	<input type="button" value="Delete"/>	
<b>VID</b>	<b>Committed Information Rate (Bits/sec)</b>	<b>Leaky Bucket (Milli-sec)</b>

### Rate Limit Flooding Setup

Label	Description
Rate Limit Type	Click on this drop-down list and select the item you want to setup.
Flooding VID	Type in VLAN ID (1 ~ 4094). The VLAN must have been created in the static VLAN table.
Committed Information Rate	Committed Information Rate (1536 ~ 1G bits per second). The threshold rate to turn on the rate-limit mechanism.
Leaky Bucket	Leaky bucket size. The unit is millisecond. This parameter ranges from 1 to 1024. The bucket depth is the product of CIR and this parameter.
Modify	Click on this button to modify data in the table.
Query	Click on this button to get most recent status.



✧ **Rate Limit Policer profile**

The IDL-4802 supports two kinds of TCM Policer: two-rate TCM (with dual leaky buckets) and single-rate TCM (with single leaky bucket).


The single-rate TCM meters a traffic stream and marks its packets according to Committed Information Rate (CIR) and Committed Burst Size (CBS) to be either green, or red. The single-rate TCM operates with a single leaky bucket that is updated according to only one rate, the committed information rate - CIR. A packet is marked green if the leaky bucket is not full and red otherwise.

The two-rate TCM meters a traffic stream and marks its packets based on two rates, Committed Information Rate (CIR) and Excess Information Rate (EIR), and their associated burst sizes, Committed Burst Size (CBS) and Excess Burst Size (EBS), to be either green, yellow, or red. The two-rate TCM operates with dual leaky bucket, where each bucket is updated according to a different rate. The first bucket is updated according to the CIR, the second bucket is updated according to the EIR. A packet is marked red if it exceeds the PIR. Otherwise it is marked either yellow or green depending on whether it exceeds or doesn't exceed the EIR.

Rate Limit Policer Profile

Rate Limit Type: Policer Profile								
Page (01) of 4 <input type="button" value="Modify"/> <input type="button" value="Delete"/> <input type="button" value="Query"/>								
CIR(Committed Info Rate),EIR(Excess Info Rate),LBS(Leaky Bucket Size) DLB(Dual Leaky Bucket),SLB(Single Leaky Bucket) CIR & 1st LBS are supported in both SLB and DLB mode EIR & 2nd LBS only in DLB mode								
Select	No	Share Mode	LB Mode	CIR (1536..1G bps)	EIR (1536..1G bps)	1st LBS (1..1K ms)	2nd LBS (1..1K ms)	Status
<input type="checkbox"/>	1	Share	Single	20000	--	50	--	Complete
<input checked="" type="checkbox"/>	2	NO Share	Dual	80000	80000	20	200	Complete
<input type="checkbox"/>	3	Select	Select					Non-Complete
<input type="checkbox"/>	4	Select	Select					Non-Complete
<input type="checkbox"/>	5	Select	Select					Non-Complete
<input type="checkbox"/>	6	Select	Select					Non-Complete
<input type="checkbox"/>	7	Select	Select					Non-Complete
<input type="checkbox"/>	8	Select	Select					Non-Complete
<input type="checkbox"/>	9	Select	Select					Non-Complete
<input type="checkbox"/>	10	Select	Select					Non-Complete
<input type="checkbox"/>	11	Select	Select					Non-Complete
<input type="checkbox"/>	12	Select	Select					Non-Complete

## Rate Limit Poicer Setup

Label	Description
Rate Limit Type	Click on this drop-down list and select the item you want to setup.
	Click on this drop-down list and select a page to be displayed.
Select	Select the checkbox when you want to create/modify/delete this entry.
Share Mode	<p><b>Share</b> mode: All the bridge ports which bind to the share mode policer profile will share the same Leaky Bucket defined by the CIR, EIR...parameters. So in Share mode, system only creates one Leaky Bucket for all the binding bridge ports.</p> <p><b>No Share</b> mode: Every bridge port which bind to the non-share policer profile will have its own Leaky Bucket.</p>
LB Mode	<p><b>Single</b>: Single Leaky Bucket. For SLB, there is one controlling parameter: CIR.</p> <p><b>Dual</b>: Dual Leaky Bucket. For DLB, there are two controlling parameters: CIR and EIR.</p>
CIR	Committed Information Rate (1536 ~ 1G bits per second) controls the number of tokens in the first bucket (CBS bucket).
EIR	Excess Information Rate (1536 ~ 1G bits per second) controls the number of tokens in the second bucket (EBS bucket).
1 <sup>st</sup> LBS	1 <sup>st</sup> Leaky Bucket Size. The unit is millisecond. This parameter ranges from 1 to 1024. The first bucket depth is the product of CIR and this parameter.
2 <sup>nd</sup> LBS	2 <sup>nd</sup> Leaky Bucket Size. The unit is millisecond. This parameter ranges from 1 to 1024. The second bucket depth is the product of EIR and this parameter.
Create	Click on this button to create a new entry in the rate limit table.
Query	Click on this button to retrieve the entries in the table.
Delete	Click on this button to delete the entries in the table.

## ✧ Rate Limit Policer Binding Table

The Rate Limit Policer Binding Table allows you to specify which Policer profile to bind and the binding status for a trunk or line bridge port.

Rate Limit Policer Binding Table

Rate Limit Type Policer Binding Table			
GIGA			
Modify Query			
Select	Port	Policer No.	Binding Status
<input type="checkbox"/>	GIGA1	1	ON
<input checked="" type="checkbox"/>	GIGA2	2	ON
<input type="checkbox"/>	LA	1	OFF

### Rate Limit Policer Binding Setup

Label	Description
Rate Limit Type	Click on this drop-down list and select the item you want to setup.
GIGA	Click on the drop-down list to select a line or trunk bridge port.
Modify	Once you have finished setting the parameter values, click on this button to submit the modification.
Query	Click on this button to get most recent data.
Select	Remember to select the checkbox when you want to modify this entry.
Policer No.	Click on the drop-down list and select the Policer profile you want to bind with this port.
Binding Status	Select to bind (ON) or unbind (OFF) the Policer profile.

### ❖ Three Color Marking Policer

The IDL-4802 supports TCM Policer in accordance with the Metro Ethernet Forum (MEF) Bandwidth Profile and RFCs 2697 & 2698. Our TCM Policer supports both Color Aware and Color Blind modes. The “color” is used for determining whether a packet will proceed to the policer when TCM Policer works in Color Aware mode; also in the policer the packet may be remarked with new color according to the packet’s conformance to the policer rules. A packet is considered green when it enters the TCM Policer only if its input color field, VLAN priority bits or DSCP field, has the same value with the green value configured in this page (see the following figure and parameter description). Likewise, a packet is considered yellow only if its input color field has the same value with the yellow value configured in this page. All other values are considered red.

Once a packet has passed through the TCM Policer, it will be directed to the class queues for scheduling.

Rate Limit Three Color Marking

Color Aware	Color Field	Packet Mode	Green Value	Yellow Value	Red Value
Aware	(1)VLAN Priority	TAG	1	3	7

Rate Limit Policer Binding Setup

Label	Description
Rate Limit Type	Click on this drop-down list and select the item you want to setup.
Modify	Once you have finished setting the parameter values, click on this button to submit the modification.
Query	Click on this button to get most recent data.
Color Aware	<b>Color aware</b> mode: the packets are classified before they’re sent through the policer. <b>Color blind</b> mode: the packets are directed through the entire policer regardless of their color.
Color Field	There are two fields you can select for determining the packet’s input color: the VLAN priority bits within the Ethernet header or the DSCP field within the IP header.
Packet Mode	This parameter defines the action for non-conforming packets. You can choose Tag or Discard. If Tag is chosen, then all the packets will be marked as red in the Color field rather than be discarded.
Green Value	Type in the green color value that is used when determining a packet’s input color (for Color Aware mode) or remarking a packet’s output color as green. Valid value is 0 ~ 7 for VLAN Priority color field or 0 ~ 63 for DSCP color field.
Yellow Value	Type in the yellow color value that is used when determining a packet’s input color (for Color Aware mode) or remarking a packet’s output color as yellow. Valid value is 0 ~ 7 for VLAN Priority color field or 0 ~ 63 for DSCP color field.
Red Value	Type in the red color value that is used when remarking a packet’s output color as red. Valid value is 0 ~ 7 for VLAN Priority color field or 0 ~ 63 for DSCP color field.

#### 4.2.4.4 Priority Queue Mapping

This web page is used to select SPQ/WFQ/WRR queuing mechanism and to setup the mapping between VLAN priority levels and system internal queues. From the *Bridge* menu, click on *Access Control* and then *Priority Queue Mapping*. The following page is displayed:

Priority Queue Mapping

Modify		Query		Weighted range from 1..255			
GIGA Queue Scheduling	ATM Queue Scheduling	Queue#3 Weighted	Queue#2 Weighted	Queue#1 Weighted	Queue#0		
SPQ	SPQ	40	30	20	10		
GIGA Priority#7	GIGA Priority#6	GIGA Priority#5	GIGA Priority#4	GIGA Priority#3	GIGA Priority#2	GIGA Priority#1	GIGA Priority#0
Queue#3	Queue#3	Queue#2	Queue#2	Queue#1	Queue#1	Queue#0	Queue#0
ATM Priority#7	ATM Priority#6	ATM Priority#5	ATM Priority#4	ATM Priority#3	ATM Priority#2	ATM Priority#1	ATM Priority#0
Queue#7	Queue#6	Queue#5	Queue#4	Queue#3	Queue#2	Queue#0	Queue#1

The queues for Giga and ATM interfaces are different.

#### Giga:

Each Giga interface has 4 Queues and these queues can only work on Strict Priority Queuing (SPQ) scheduling. The priorities of these queues are: Q3 > Q2 > Q1 > Q0.

#### ATM:

Each ATM PVC bridge interface on each ADSL port has 8 Queues and can work in SPQ or SPQ/WFQ mix mode.

For SPQ, the priorities of these queues are: Q7 > Q6 > Q5 > Q4 > Q3 > Q2 > Q1 > Q0.

For SPQ/WFQ mixed, the priority of SPQ queues (Q7~Q4) is higher than WFQ queues (Q3~Q0).

And:

Q7 ~ Q4 are for SPQ and the priorities are Q7 > Q6 > Q5 > Q4.

Q3 ~ Q0 are for WFQ (Weighted Fair Queuing) and you can define the weight value for Q3 ~ Q0.

Note that if each queue has different weight value, the system will work as WFQ mode. If all queues have the same weight value, the system will work as Weighted Round Robin (WRR) mode.

The system allows 8 priority levels fully work as WFQ or WRR mode, via using queues of Q3 ~ Q0 only in the Priority Queue Mapping table.

## 4.2.5 Forwarding

### 4.2.5.1 TP Forwarding DB

This option allows you to retrieve the status of the transparent forwarding database. The forwarding table will reveal the information of MAC addresses that are learned or statically configured on a specific bridge port. From the *Bridge* menu, click on *Forwarding* and then *TP Forwarding DB*. The following page is displayed.

Forward Table

Aging Time(10..1000000 Sec):		<input type="text" value="300"/>	<input type="button" value="Modify"/>					
No. From	<input type="text" value="1"/>	To	<input type="text" value="15"/>					
No range from 1 to 6144		<input type="button" value="Query"/>						
No.	Source MAC	IFC	Port	Status	VID	Aging Bit	Process Mode	Unknown Mac Mode
1	02:11:22:33:44:AA	1	Giga:1	Dynamic	100	True	PASS	Disabled
2	66:00:00:00:00:33	4	Port-PVC:1-1	Static	1	False	PASS	Disabled

TP Forwarding DB

Label	Description
Aging Time	Type in the aging time in seconds. An entry will be removed from the FDB (aged-out) if the device does not transmit for a specified period of time (the aging time).
Modify	Click on this button to submit the modification of Aging Time.
No. From...To...	Select the range of entry number in the forwarding database to be displayed.
Query	Once you have selected the entry number, click on this button to get most recent status of MAC addresses forwarding.

### 4.2.5.2 Forwarding Static

This option allows you to configure the static MAC address forwarding entries on a specific bridge port. The setting of static MAC address takes effect on egress direction of bridge port. From the *Bridge* menu, click on *Forwarding* and then *Forwarding Static*. The following page is displayed.

#### Forwarding Static

The screenshot shows the 'Forwarding Static' configuration interface. At the top, there are input fields for 'No. From' (1) and 'To' (1), with a note 'No. range form 1 to 512'. Below these are 'Query' and 'Delete' buttons. A table displays the current configuration:

No.	Source MAC	Output Port	VID	Process mode
1	ee:00:ff:00:00:33	ADSL Port1-PVC1	1	PASS

Below the table, there are three dropdown menus showing 'ADSL', 'Port-1', and 'PVC-1'. Further down, there are input fields for 'Next No:' (2), 'Source MAC' (00 00 00 00 00 00), 'VID:' (1), and 'Process:' (Pass). A 'Create' button is located at the bottom right of the form area.

#### Forwarding Static

Label	Description
No. From...To...	Select the range of entry number in the FDB to be retrieved. Valid number value: 1 ~ 512.
Query	Click on this button to display the static MAC forwarding entries.
Delete	Delete the entries according to the entry number range you type in.
GIGA GIGA1	Click on these drop-down list to select a bridge port (ADSL bridge port or GIGA bridge port) where the static forwarding entries to be configured.
Source MAC	Type in the MAC address for the static entry.
VID	Type in the VID for the static entry (1 ~ 4094).
Process	Click on the drop-down list and select "Deny" or "Pass". "Pass" means to forward the packets with destination MAC address matching one of the static forwarding MAC addresses to a specified output bridge port. "Deny" means to drop the packets.
Create	Click on this button to create a new entry.

## 4.2.6 Relay

### 4.2.6.1 DSL Line Identify

This option allows you to configure the DHCP option 82 and PPPoE relay function. From the *Bridge* menu, click on *Relay* and then *DSL Line Identify*. The following page is displayed:

#### DSL Line Identify

**DSL Global Configuration**  
 PPP Service Name:  PPP Service Name Check mode: Disabled   
 DSLAM Name:  DSLAM Name mode: Customer   
 Dhcp Mode: Relay OFF  ID Select: Circuit ID   
 Circuit ID Type: DEFAULT  Remote ID Type: DEFAULT


**DSL Line ID Configuration**  
Port 01~12  PVC-1

Select	Port	Circuit ID	Remote ID	Trusted
<input type="checkbox"/>	01	IPDSLAM:001:000:00035	IPDSLAM:001/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	02	IPDSLAM:002:000:00035	IPDSLAM:002/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	03	IPDSLAM:003:000:00035	IPDSLAM:003/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	04	IPDSLAM:004:000:00035	IPDSLAM:004/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	05	IPDSLAM:005:000:00035	IPDSLAM:005/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	06	IPDSLAM:006:000:00035	IPDSLAM:006/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	07	IPDSLAM:007:000:00035	IPDSLAM:007/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	08	IPDSLAM:008:000:00035	IPDSLAM:008/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	09	IPDSLAM:009:000:00035	IPDSLAM:009/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	10	IPDSLAM:010:000:00035	IPDSLAM:010/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	11	IPDSLAM:011:000:00035	IPDSLAM:011/1	<span>FALSE</span> <input type="button" value="v"/>
<input type="checkbox"/>	12	IPDSLAM:012:000:00035	IPDSLAM:012/1	<span>FALSE</span> <input type="button" value="v"/>

#### DSL Line Identify Setup

Label	Description
<b>DSL Global Configuration</b>	
PPP Service Name	Type in the PPPoE service name to add.
PPP Service Name Check mode	Enable: the system will check whether the PPPoE service names from the PPPoE server and client are the same. If not the same, the PPP connection between server and client will not be established. Disable: the system will not check the PPPoE service name.
DSLAM Name	Type in name of the DSLAM when DSLAM Name mode is set to 'Customer'.
DSLAM Name mode:	Select the DSLAM name to be customer-defined or cluster name (Domain name:NE name).
DHCP Mode	Click on this drop-down list and select OFF/ON to disable/enable DHCP relay function.
ID Select	Click on this drop-down list and select the Relay Agent Information that is inserted to the forwarding packets. Options are: Circuit ID, Remote ID, or Both.



Circuit ID Type	Click on this drop-down list and select the type of Circuit ID. Options are: DEFAULT, CUSTOMER. DEFAULT means our system-defined default type (<DSLAM name>:<circuit number>:<vpi>:<vci>); CUSTOMER means the customer-defined type.
Remote ID Type	Click on this drop-down list and select the format of Remote ID. Options are: DEFAULT, Line ID (ADSL line identifier), Line Desc (description for the line), Line Phone (phone number), CUSTOMER.  <b>DEFAULT</b> means our system default format, which is DSLAM name:port_id/bridge_id. <b>CUSTOMER</b> means the customer-defined format; customer can type in any word not exceeding 48 characters. For <b>Line ID</b> , the format is port_id/bridge_id:Port Identifier. For <b>Line Desc</b> , the format is port_id/bridge_id:Port Description. For <b>Line Phone</b> , the format is port_id/bridge_id:Port Phone Number. The Port Identifier, Description, and Phone Number are set in the ADSL line information table.
Set	Once you have changed the setting of any one of the parameters (DHCP Mode, ID Select, CKT Type, Remote Type, DLSAM Name, Service Name), remember to click on Set to submit the modification.
<b>DSL Line ID Configuration</b>	
	Click on these drop-down lists to select the bridge ports to be displayed (these bridge ports must have been created in previous web page).
Query	Click on this button to display table.
Modify	Click on this button to submit the modification of DSL line identify table.
Select Port	Bridge port index. Select the checkbox(s) corresponding to the circuit(s) of which you want to modify the setting.
Circuit ID	Type in the Circuit ID when CUSTOMER is selected for the CKT Type.
Remote ID	Type in the Remote ID when CUSTOMER is selected for the Remote Type.
Trusted	Click on this drop-down list and specify the circuit to be trusted (TRUE), or untrusted (FALSE; the relay agent will discard the DHCP packets from an untrusted circuit).

## 4.2.7 IGMP

### 4.2.7.1 Protocol & Router Port

This option allows you to setup the IGMP protocol and router port. From the *Bridge* menu, click on *IGMP* and then *Protocol & Router Port*. The following page is displayed:

#### IGMP Protocol & Router Port

**IGMP Protocol Settings**

All of the interval from 1 to 500  
 Query(Query Interval),URI(Unsolicited Report Interval),BC(Older host present interval)  
 MRT(Max Response Time),LMQT(Last Member Query Time),GMT(Group Membership Time) readonly

IGMP Version	IGMP Mode	IGMP ACL Mode	Deny NO Alert	Max Groups Limit
IGMP V2	Snooping	Disabled	Disabled	Disabled

Query	URI	BC	MRT	LMQT	GMT
125	1	400	10	1	260

**Router Port Settings**

GIGA1  GIGA2  Router Port VID:  Router IP:

The IGMP Router's IP is available while IGMP in Proxy mode.  
 "0.0.0.0" means an operator is needless IGMP Router's IP.

Delete Select	VID	Router Port	Router IP
<input type="checkbox"/>	1	GIGA 1	172.002.002.002

#### IGMP Router Port Setup

Label	Description
Modify	Click on this button to modify the IGMP configuration once you have set new values for the parameters.
IGMP Version	Select the IGMP version. Options are: IGMP OFF, IGMP V1, IGMP V2, and IGMP V3.
IGMP Mode	Select the IGMP mode. Options are: Snooping and Proxy.
IGMP ACL Mode	Disable or enable ACL mode. IGMP ACL profile will be effective only when ACL mode is enabled.
Deny No Alert	Enabled: the system will deny IGMP packets that have no router alert option in their IP header. Disabled: default value; the system will not care router alert option.
Max Groups Limit	Enabled: the system will limit the maximum active counter of IGMP groups can be joined (concurrently) for every bridge port. Disabled: the system will not limit the counter of IGMP groups can be joined for the bridge port.
Query 1~500(s)	The Query Interval is the interval between General Queries sent by the Querier. By varying this value, an administrator may tune the number of IGMP messages on the network; larger values cause IGMP Queries to be sent less often. Value range is 1 ~ 500. Default is 125 seconds.
URI 1~500(s)	The Unsolicited Report Interval is the time between repetitions of a host's initial report of membership in a group. Value range is 1 ~ 500. Default: 1

	second.
BC 1~500(s)	The Older Host Present Interval. It represents how long a host must wait after hearing a Version 1 Query before it may send any IGMPv2 messages. Default is 400 (sec).
MRT 1~500(s)	The burstiness of IGMP traffic is inversely proportional to the Max Response Time. A longer Max Response Time will spread Report messages over a longer interval. However, a longer Max Response Time in Group-Specific and Source-and-Group-Specific Queries extends the leave latency. (The leave latency is the time between when the last member stops listening to a source or group and when the traffic stops flowing.). Value range is 1 ~ 500. Default is 10.
LMQT 1~500(s)	The Last Member Query Interval is the Max Response Time used to calculate the Max Resp Code inserted into Group-Specific Queries sent in response to Leave Group messages. It is also the Max Response Time used in calculating the Max Resp Code for Group-and-Source-Specific Query messages. Value range is 1 ~ 500. Default is 1.
GMT 1~500(s)	Read-only value. The Group Membership Interval is the amount of time that must pass before a multicast router decides there are no more members of a group or a particular source on a network. This value MUST be ((the Robustness Variable) times (the Query Interval)) plus (one Query Response Interval).
Giga1/Giga2/LA	Click on this radio button to select GBE1/GBE2/LA as the IGMP router port.
Route Port VID	Type in the VID you want to setup/delete the router port for. Valid VID value is 1 ~ 4094.
Router IP	Type in IGMP router IP address. When working in IGMP proxy mode, DSLAM will send IGMP general query whose source IP address is 0.0.0.0. But PCs with Windows OS do not receive this kind of packets. So user can assign an IP address here for proxy mode IGMP general query packet reference.
Create	Click on this button to create a new entry.
Delete	To delete an entry, select the checkbox of the entry and then click on Delete button.

#### 4.2.7.2 IGMP Profile

This option allows you to configure the IGMP ACL (Access Control List) profile. This profile defines the IGMP multicast channels, which are allowed to join for each ADSL port. That is, a multicast stream will be copied to an ADSL port only if that multicast stream is registered in the ACL profile that is bound to this ADSL port. The maximum number of IGMP multicast channels in an ACL profile is 256. Note that the same multicast channel can be existed concurrently in two or more ACL profiles.

The ACL profile will be referred to only when ACL mode is enabled in the IGMP Configuration page. From the *Bridge* menu, click on *IGMP* and then *IGMP Profile*. The following page is displayed:

IGMP Profile page = >

#### IGMP ACL Profile

Select	Channel	IP Address	VID	Select	Channel	IP Address	VID
<input type="checkbox"/>	1	224 . 2 . 5 . 1	1	<input type="checkbox"/>	2	224 . 1 . 1 . 1	1
<input type="checkbox"/>	3	224 . 1 . 1 . 1	1	<input type="checkbox"/>	4	224 . 1 . 1 . 1	1
<input type="checkbox"/>	5	224 . 1 . 1 . 1	1	<input type="checkbox"/>	6	224 . 1 . 1 . 1	1
<input type="checkbox"/>	7	224 . 1 . 1 . 1	1	<input type="checkbox"/>	8	224 . 1 . 1 . 1	1
<input type="checkbox"/>	9	224 . 1 . 1 . 1	1	<input type="checkbox"/>	10	224 . 1 . 1 . 1	1
<input type="checkbox"/>	11	224 . 1 . 1 . 1	1	<input type="checkbox"/>	12	224 . 1 . 1 . 1	1
<input type="checkbox"/>	13	224 . 1 . 1 . 1	1	<input type="checkbox"/>	14	224 . 1 . 1 . 1	1
<input type="checkbox"/>	15	224 . 1 . 1 . 1	1	<input type="checkbox"/>	16	224 . 1 . 1 . 1	1

#### IGMP ACL Profile Configuration

Label	Description
Profile ID	Click on this drop-down list and specify the profile ID. Valid value is 01 ~ 48.
IP CHANNEL MAP	Click on this drop-down list and select the channel index range. Options are: Channel 001~032, Channel 033~064, ..., Channel 225~256.
All select	Click on this checkbox to select all channels in this page at one time. This is convenient for quick value assignment.
Quickly IP Assign	Type the IGMP group IP address here for quick assignment. Click on <b>Assign</b> button to put the value into the table. Then you can modify parts of the IP addresses directly in the table.
Quickly VID Assign	Type the IGMP group IP address here for quick assignment. Click on <b>Assign</b> button to put the value into the table.
Assign	Click on this button to apply the parameter values you have just entered. But these values haven't been really saved in the database. You must click on Create to save the values. Once the setting has been saved, you cannot modify the values. You must delete the channel and then create again.

Select	Click on this checkbox to select the channel you want to create, delete, or assign values.
IP Address	You can type the IGMP group address here and then click on Create button to save. Valid values: 224.0.0.0 ~ 239.255.255.255. The range of addresses from 224.0.0.0 to 224.0.0.255 is reserved for the use of routing protocols and other low-level topology discovery or maintenance protocols.
Query	Click on this button to display current channels in the profile.
Create	Click on this button to create new channels (IGMP group address).
Delete	Click on this button to delete channel(s) (IGMP group address).

**Binding Profile page = >**

[IGMP ACL Profile](#)

IGMP PROFILE
BINDING PROFILE

ADSL ▾
Port 01~12 ▾
PVC-1 ▾

Max Groups range form 1 to 128

Modify

All select:  Quickly Max Group Assign:

Quickly Profile ID Assign: (01) ▾ Quickly Binding Assign: off ▾ Assign

Port	Max Groups	Profile ID	Binding Status	Port	Max Groups	Profile ID	Binding Status	Port	Max Groups	Profile ID	Binding Status			
Port01	<input checked="" type="checkbox"/>	9	(01) ▾	off ▾	Port02	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port03	<input checked="" type="checkbox"/>	118	(02) ▾	on ▾
Port04	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port05	<input checked="" type="checkbox"/>	128	(01) ▾	on ▾	Port06	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾
Port07	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port08	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port09	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾
Port10	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port11	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾	Port12	<input checked="" type="checkbox"/>	8	(01) ▾	off ▾

IGMP ACL Profile Binding

Label	Description
ADSL ▾ Port 01~12 ▾ PVC-1 ▾	Click on these drop-down lists to select a line bridge port.
All select	Click on this checkbox to select all ports in this page at one time. This is convenient for quickly value assignment.
Quickly Max Group Assign	This field is for quick value assignment (assign the same value to all the ports in current page at one time). Type in the maximum IGMP groups can be joined simultaneously per line port, and then click on Assign to put the value into the table.
Quickly Profile ID Assign	Click on this drop-down list to select the profile ID you want to bind. This is for quick value assignment.
Quickly Binding Assign	Click on this drop-down list to select the binding action. This is for quick value assignment. Options are: off -- unbind the profile, on -- bind the profile, reset -- rebind the profile.
Assign	Click on this button to apply the parameter values you have just entered (or selected). But these values haven't been really saved in the database. You must click on Modify to save the values.
Modify	Click on this button to submit the modification.

Port	Click on the checkbox to select the port you want to modify or assign values.
Max Groups	You can type in the maximum IGMP groups can be joined simultaneously to limit the concurrent multicast channels for a bridge port. This value is effective only when the limit maximum IGMP groups function is enabled.
Profile ID	You can select the profile ID you want to bind here.
Binding Status	You can select the binding action here.

### 4.2.7.3 IGMP Multicast

This option allows you to query the IGMP multicast status. From the *Bridge* menu, click on *IGMP* and then *IGMP Multicast*. The *IGMP Group* page is displayed. Click on the *IGMP Type* drop-down list and select *Group* or *Source*.

**IGMP Type > Group:** Click on *List by* drop-down list to select listing by entry number or listing by VID & IGMP group IP.

#### List by Number:

#### IGMP Group

IGMP Type: Group						
List by: Number No. From 1 To 5 Query						
No.	VID	Group IP	AddActions	IGMP Mode	Number of sources	Port
1	1	224.1.10.2	1	Exclude	1	GIGA2,
2	1	224.1.1.2	1	Exclude	1	GIGA2,
3	1	224.1.10.1	0	Exclude	0	GIGA2,
4	1	224.1.1.1	1	Exclude	4	GIGA2,

#### IGMP Group – List by Number

Label	Description
No. From...To...	Type in the entry number range in the table.
Query	Click on this button to display the table entries.

#### List by VID & Group IP:

#### IGMP Group

IGMP Type: Group						
List by: VID & Group IP VID: 1 Group IP: 224.1.1.2 Query						
VID	Group IP	AddActions	IGMP Mode	Number of sources	Port	
1	224.1.1.2	1	Exclude	1	GIGA2,	

#### IGMP Group – List by VID & Group IP

Label	Description
VID	Type in the VLAN ID (1~ 4094).
Group IP	Type in the IGMP group IP address.
Query	Click on this button to display the table entries.

**IGMP Type > Source:** This option allows you to query the *Source IP*, which is the IP address of the source that is joining a multicast group on an interface. This option is available only when IGMP version 3 is selected for the system's IGMP configuration.

### IGMP Source

IGMP Type: <span style="border: 1px solid black; padding: 2px;">Source</span> ▼					
VID: <span style="border: 1px solid black; padding: 2px;">1</span>	Group IP: <span style="border: 1px solid black; padding: 2px;">224.1.1.2</span>	No. From: <span style="border: 1px solid black; padding: 2px;">1</span>	To: <span style="border: 1px solid black; padding: 2px;">5</span>	<span style="border: 1px solid black; padding: 2px;">Query</span>	
No	VID	Group IP	Source IP	Timer On	Port
1	1	224.1.1.2	192.168.1.1	0	GIGA2,

### IGMP Source

Label	Description
VID	Type in the VLAN ID (1~ 4094).
Group IP	Type in the IGMP group IP address.
No. From...To...	Type in the entry number range in the table.
Query	Click on this button to display the table entries.



## 4.2.8 IPOA

### 4.2.8.1 BRAS MAC

The IDL-4802 supports an IPOA/IPOE IWF (Interworking Function). This option allows you to setup the BRAS MAC address that is used by the IPOA/IPOE IWF. From the *Bridge* menu, click on *IPOA* and then *BRAS MAC*. The following page is displayed.

#### To add/modify a MAC:

Select a checkbox beside an index and type in BRAS MAC address, and then click on **Modify** button.

#### To delete a MAC:

Select a checkbox (checkboxes) beside the index and then click on **Delete** button.

#### IPoA BRAS MAC

Select	Index	BRAS MAC(xx:xx:xx:xx:xx:xx)
<input type="checkbox"/>	1	: : : : :
<input type="checkbox"/>	2	: : : : :
<input type="checkbox"/>	3	: : : : :
<input type="checkbox"/>	4	: : : : :
<input type="checkbox"/>	5	: : : : :
<input type="checkbox"/>	6	: : : : :
<input type="checkbox"/>	7	: : : : :
<input type="checkbox"/>	8	: : : : :
<input type="checkbox"/>	9	: : : : :
<input type="checkbox"/>	10	: : : : :
<input type="checkbox"/>	11	: : : : :
<input type="checkbox"/>	12	: : : : :

### 4.2.8.2 Interface Setup

This option allows you to setup the interface for IPoA/IPoE IWF. From the *Bridge* menu, click on *IPOA* and then *Interface Setup*. The following page is displayed.

Click on the radio button to select a circuit, set values for the parameters, and then click on **Modify** button.

IPoA Interface Setup

Select Port	VPI	VCI	MAX MAC	C-VLAN ID	C-VLAN Priority	Traffic Rx/Tx	BRAS Macldx	Uplink Index	AAL5 Encap	IPoA Status
<input checked="" type="radio"/>	1	0	4	1001	0	Def / Def	1	Giga1	LLC	Disabled
<input type="radio"/>	2	0	4	1002	0	Def / Def	1	Giga1	LLC	Disabled
<input type="radio"/>	3	0	4	1003	0	Def / Def	1	Giga1	LLC	Disabled
<input type="radio"/>	4	0	4	1004	0	Def / Def	1	Giga1	LLC	Disabled
<input type="radio"/>	5	0	4	1005	0	Def / Def	1	Giga1	LLC	Disabled

IPoA Interface Setup

Label	Description
	Click on the drop-down list and select the line ports to be listed.
VPI	Type in the VPI. Value range is 0 ~ 255.
VCI	Type in the VCI. Value range is 21, 32 ~ 65535.
MaxMAC	Type in the maximum number of MAC addresses that can be learned by the bridge port (for GBE interface: 1 ~ 4096, for DSL interface: 1 ~ 128).
CVID	Type in the VID value of C-Tag (the innermost VLAN tag as defined in IEEE 802.1ad and having an EtherType value of 0x8100). The C-VID indicates the access loop.
CVPRI	Click on the drop-down list and select the VLAN priority level of C-Tag (Pri-0 ~ 7).
Traffic (Rx/Tx)	Click on the drop-down lists and select a traffic type for transmit and receive direction respectively. Available options are created in the ATM Traffic Descriptor page.
BRAS	Click on the drop-down list and select a BRAS MAC. Available options are created in the <i>IPoA BRAS MAC</i> page.
Uplink	Click on the drop-down list and select the uplink interface.
Encap	Select AAL5 Encapsulation Type: VCMUX/LLC
Status	Enable/Disable IPoA IWF.
Modify	Click on this button to submit the modification.
Query	Click on this button to query most recent data.

## 4.3 ADSL

### 4.3.1 Profile

#### 4.3.1.1 Service Main Profile

This option allows you to configure the ADSL line service profile. From the *ADSL* menu, click on *Profile* and then *Service Profile(main)*. The following page is displayed.

ADSL Service Profile

Index	Name	Rate Mode DownStream	Rate Mode UpStream
Next → 3	Test	(3)Dynamic	(3)Dynamic
<input type="radio"/> 1	default	Init	Init
<input type="radio"/> 2	Name2	Manual	Manual
<input checked="" type="radio"/> 3	Test	Dynamic	Dynamic
<input type="radio"/> 4	----	----	----
<input type="radio"/> 5	----	----	----
<input type="radio"/> 6	----	----	----
<input type="radio"/> 7	----	----	----
<input type="radio"/> 8	----	----	----
<input type="radio"/> 9	----	----	----
<input type="radio"/> 10	----	----	----

ADSL Line Service Profile setup

Label	Description
Select Index	Click on the drop-down list and select the range of profile index. Options are: 0~10, 11~20, ..., 111~120.
Index	This field shows the profile index. Click on the radio button beside the profile index to select the profile you want to modify or delete. Note that profile 1 (default) cannot be modified or deleted.
Name	Type in the name of the profile.
Rate Mode Downstream	Click on the drop-down list and select the Downstream Rate Adaptive Mode. Valid options are: Manual – Rate changed manually Init – Rate automatically selected at start up only and does not change after that Dynamic – Rate automatically selected at initialization and is continuously adapted during operation (show time).
Rate Mode Upstream	Click on the drop-down list and select the Upstream Rate Adaptive Mode. Valid options are: Manual – Rate changed manually Init – Rate automatically selected at start up only and does not change after that Dynamic - Rate automatically selected at initialization and is continuously adapted during operation (show time).

### 4.3.1.2 Service Channel Profile

This option allows you to configure the ADSL service channel profile. From the *ADSL* menu, click on *Profile* and then *Service Profile(Channel)*. The following page is displayed.

ADSL Service Channel Profile

Select Index: (1)1~5 <input type="button" value="Modify"/> <input type="button" value="Query"/>													
The First Index is default profile can't modify & delete. To modify a service channel profile, please create service main profile first.													
Index	L2 Packet	Direction	BitRate (kbit/s)0~65535				DownShift		UpShift		InterLeave MaxDelay 1~63 (ms)	Min INP 0~8 (symbols)	
			Min	Planned	Max	L2 Min	Noise Margin (db)	Min Interval (sec)	Noise Margin (db)	Min Interval (sec)			
Next → 1	23	DS	128	1024	65535	128	3.0	10	9.0	10	1	0.0	
		US	4	128	65535	N/A	3.0	10	9.0	10	1	0.0	
<input checked="" type="radio"/> 1	23	DS	128	1024	65535	128	3.0	10	9.0	10	1	0.0	
		US	4	128	65535	---	3.0	10	9.0	10	1	0.0	
<input type="radio"/> 2	23	DS	128	1024	65535	128	3.0	10	9.0	10	1	0.0	
		US	4	128	65535	---	3.0	10	9.0	10	1	0.0	
<input type="radio"/> 3	23	DS	128	1024	65535	128	3.0	10	9.0	10	1	0.0	
		US	4	128	65535	---	3.0	10	9.0	10	1	0.0	
<input type="radio"/> 4	0	DS	0	0	0	0	0.0	0	0.0	0	0	0.0	
		US	0	0	0	---	0.0	0	0.0	0	0	0.0	
<input type="radio"/> 5	0	DS	0	0	0	0	0.0	0	0.0	0	0	0.0	
		US	0	0	0	---	0.0	0	0.0	0	0	0.0	

ADSL Service Channel Profile setup

Label	Description
Select Index	Click on the drop-down list and select the range of profile index. Options are: 1~5, 6~10, ..., 116~120.
Index	This field shows the profile index. Click on the radio button beside the profile index to select the profile you want to modify. Note that profile 1 (default) cannot be modified.
L2 Packet	This is a threshold value that is the minimum packet size before the system leaving the L2 low power state. Valid value is 0~32.
Direction	DS: downstream. US: upstream.
BitRate	Min: Minimum bit rate during show time Planned: Planned bit rate during setup Max: Maximum bit rate during show time L2 Min: Minimum bit rate during L2 low power state
DownShift Noise Margin (dB)/ Min Interval (sec)	Decrease net data rate if Noise Margin is below the Downshift Noise Margin for DownShift Min Interval.
UpShift Noise Margin (dB)/Min Interval (sec)	Increase net data rate if Noise Margin is above the Upshift Noise Margin for Upshift Min Interval.
Interleaving MaxDelay	Maximum interleaving delay (1~63 ms)
IMP 0~8 (symbols)	Minimum impulse noise protection (0.0~8.0 dB)

### 4.3.1.3 Spectrum Main Profile

This option allows you to configure the ADSL spectrum profile. From the *ADSL* menu, click on *Profile* and then *Spectrum Profile(main)*. The following page is displayed.

ADSL Spectrum Profile

Select Index: (1)1~4 <input type="button" value="Query"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/>										
The First Index is default profile can't modify & delete.										
OP Mode-1 <input type="button" value="Carrier Mask-1"/> <input type="button" value="RFI-1"/>										
Index	Name	Power Mode	Pwr Management		Direction	Message		Noise Margin 0~31.0,51.1(db)		
			L0 Time	L2 ATPR		ds min				
			L2 Time	L2 ATPRT		us min	Min	Tar	Max	
Next → 1	default	Disable L2 L2L3 <input type="radio"/> <input type="radio"/> <input type="radio"/>	30	1	DS	4	0.0	6.0	51.1	
			30	6	US	4	0.0	6.0	51.1	
<input checked="" type="radio"/> 1 complete	default	Disable	30	1	DS	4	0.0	6.0	51.1	
			30	6	US	4	0.0	6.0	51.1	
<input type="radio"/> 2 complete	Name2	Disable	30	1	DS	4	0.0	6.0	51.1	
			30	6	US	4	0.0	6.0	51.1	
<input type="radio"/> 3	----	----	--	--	DS	--	---	---	---	
			--	--	US	--	---	---	---	
<input type="radio"/> 4	----	----	--	--	DS	--	---	---	---	
			--	--	US	--	---	---	---	

### ADSL Spectrum Profile setup

Label	Description
Select Index	Click on the drop-down list and select the range of profile index. Options are: 1~4, 5~8, ..., 117~120.
Index	This field shows the profile index. Click on the radio button beside the profile index to select the profile you want to modify or delete. Note that profile 1 (default) cannot be modified or deleted.
Name	Type in the name of the profile.
Power Mode	Click on the radio button to select allowed power management mode. Options are Disable (only L0 state allowed), L2 (L0 and L2 states allowed), L2L3 (L0, L2, and L3 states allowed).
L0 Time	Type in the minimum time (in seconds) between Exit from L2 low power state and the next Entry into the L2 low power state. Value range is 0 ~ 255.
L2 Time	Type in the minimum time (in seconds) between an Entry into L2 low power state and the first L2 low power trim request, and between two consecutive L2 power trim requests. Value range is 0 ~ 255.
L2 ATPR	Type in the maximum aggregate transmit power reduction (in dB) that is allowed at transition of L0 to L2 state or an L2 low power trim request. Value range is 0 ~ the value of L2 ATPRT (dB).
L2 ATPRT	Type in the total maximum aggregate transmit power reduction (in dB) that is allowed in the L2 state; the total reduction is the sum of all reductions of L2 Request (i.e., at transition of L0 to L2 state) and L2 power trims. Value range is 0 ~ 15 (dB).
Direction	DS: downstream. US: upstream.
Message	Type in the minimum rate of the message-based overhead that shall be

	maintained by the ATU in upstream/downstream direction. Value range is 4 ~ 28k bit/s.																										
Noise Margin	Type in the Noise Margin values. Min: Minimum noise margin (0.0~31.0,51.1db, default 0.0) Tar: Target noise margin (0.0~31.0,51.1db, default 6.0) Max: Maximum noise margin (0.0~31.0,51.1db, default 51.1)																										
Modify	Click on this button to submit the modification																										
Delete	Click on this button to delete a profile																										
Query	Click on this button to display the profiles.																										
OP Mode-N	<p>Click on this button to view/modify allowed ADSL modes of operation for the profile. The following page is displayed.</p> <p>An OP Mode is supported if the check box is selected.</p> <p><i>Modify Status:</i></p> <p style="text-align: center;">Complete – modems will re-train after you click on Apply button</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center; color: blue; font-weight: bold;">ADSL Spectrum Profile[2] OP Mode</p> <p style="text-align: center;">Modify Status: Complete  <span style="border: 1px solid gray; padding: 2px 5px;">Apply</span> <span style="border: 1px solid gray; padding: 2px 5px;">BACK</span></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td><input checked="" type="checkbox"/> 0(bit00)ANSI_T1413</td><td><input checked="" type="checkbox"/> 1(bit01)ETSI_DTS_TM06006</td></tr> <tr><td><input checked="" type="checkbox"/> 2(bit02)992.1_A_Pots_NonOverlapped</td><td><input checked="" type="checkbox"/> 3(bit04)992.1_B_Isdn_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 4(bit06)992.1_C_TcmIsdn_NonOverlapped</td><td><input checked="" type="checkbox"/> 5(bit08)992.2_A_Pots_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 6(bit10)992.2_C_TcmIsdn_NonOverlapped</td><td><input checked="" type="checkbox"/> 7(bit18)992.3_A_Pots_NonOverlapped</td></tr> <tr><td><input checked="" type="checkbox"/> 8(bit20)992.3_B_Isdn_NonOverlapped</td><td><input type="checkbox"/> 9(bit24)992.4_A_Pots_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 10(bit28)992.3_I_AllDigital_NonOverlapped</td><td><input type="checkbox"/> 11(bit30)992.3_J_AllDigital_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 12(bit32)992.4_I_AllDigital_NonOverlapped</td><td><input checked="" type="checkbox"/> 13(bit34)992.3_L_Pots_NonOverlapped_Mode1</td></tr> <tr><td><input checked="" type="checkbox"/> 14(bit35)992.3_L_Pots_NonOverlapped_Mode2</td><td><input type="checkbox"/> 15(bit39)992.3_M_Pots_Extend_US_NonOverlapped</td></tr> <tr><td><input checked="" type="checkbox"/> 16(bit40)992.5_A_Pots_NonOverlapped</td><td><input checked="" type="checkbox"/> 17(bit42)992.5_B_Isdn_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 18(bit46)992.5_I_AllDigital_NonOverlapped</td><td><input type="checkbox"/> 19(bit48)ANSI_T1424</td></tr> <tr><td><input type="checkbox"/> 20(bit49)ETSI_TS_101_270</td><td><input type="checkbox"/> 21(bit50)993.1</td></tr> <tr><td><input type="checkbox"/> 22(bit51)IEEE_8023ah</td><td><input type="checkbox"/> 23(bit56)992.5_J_AllDigital_NonOverlapped</td></tr> <tr><td><input type="checkbox"/> 24(bit58)992.5_M_Pots_Extend_US_NonOverlapped</td><td></td></tr> </table> <p style="text-align: center; color: blue;">[ <a href="#">ADSL Spectrum RFI</a>   <a href="#">ADSL Spectrum Carrier Mask</a> ]</p> </div>	<input checked="" type="checkbox"/> 0(bit00)ANSI_T1413	<input checked="" type="checkbox"/> 1(bit01)ETSI_DTS_TM06006	<input checked="" type="checkbox"/> 2(bit02)992.1_A_Pots_NonOverlapped	<input checked="" type="checkbox"/> 3(bit04)992.1_B_Isdn_NonOverlapped	<input type="checkbox"/> 4(bit06)992.1_C_TcmIsdn_NonOverlapped	<input checked="" type="checkbox"/> 5(bit08)992.2_A_Pots_NonOverlapped	<input type="checkbox"/> 6(bit10)992.2_C_TcmIsdn_NonOverlapped	<input checked="" type="checkbox"/> 7(bit18)992.3_A_Pots_NonOverlapped	<input checked="" type="checkbox"/> 8(bit20)992.3_B_Isdn_NonOverlapped	<input type="checkbox"/> 9(bit24)992.4_A_Pots_NonOverlapped	<input type="checkbox"/> 10(bit28)992.3_I_AllDigital_NonOverlapped	<input type="checkbox"/> 11(bit30)992.3_J_AllDigital_NonOverlapped	<input type="checkbox"/> 12(bit32)992.4_I_AllDigital_NonOverlapped	<input checked="" type="checkbox"/> 13(bit34)992.3_L_Pots_NonOverlapped_Mode1	<input checked="" type="checkbox"/> 14(bit35)992.3_L_Pots_NonOverlapped_Mode2	<input type="checkbox"/> 15(bit39)992.3_M_Pots_Extend_US_NonOverlapped	<input checked="" type="checkbox"/> 16(bit40)992.5_A_Pots_NonOverlapped	<input checked="" type="checkbox"/> 17(bit42)992.5_B_Isdn_NonOverlapped	<input type="checkbox"/> 18(bit46)992.5_I_AllDigital_NonOverlapped	<input type="checkbox"/> 19(bit48)ANSI_T1424	<input type="checkbox"/> 20(bit49)ETSI_TS_101_270	<input type="checkbox"/> 21(bit50)993.1	<input type="checkbox"/> 22(bit51)IEEE_8023ah	<input type="checkbox"/> 23(bit56)992.5_J_AllDigital_NonOverlapped	<input type="checkbox"/> 24(bit58)992.5_M_Pots_Extend_US_NonOverlapped	
<input checked="" type="checkbox"/> 0(bit00)ANSI_T1413	<input checked="" type="checkbox"/> 1(bit01)ETSI_DTS_TM06006																										
<input checked="" type="checkbox"/> 2(bit02)992.1_A_Pots_NonOverlapped	<input checked="" type="checkbox"/> 3(bit04)992.1_B_Isdn_NonOverlapped																										
<input type="checkbox"/> 4(bit06)992.1_C_TcmIsdn_NonOverlapped	<input checked="" type="checkbox"/> 5(bit08)992.2_A_Pots_NonOverlapped																										
<input type="checkbox"/> 6(bit10)992.2_C_TcmIsdn_NonOverlapped	<input checked="" type="checkbox"/> 7(bit18)992.3_A_Pots_NonOverlapped																										
<input checked="" type="checkbox"/> 8(bit20)992.3_B_Isdn_NonOverlapped	<input type="checkbox"/> 9(bit24)992.4_A_Pots_NonOverlapped																										
<input type="checkbox"/> 10(bit28)992.3_I_AllDigital_NonOverlapped	<input type="checkbox"/> 11(bit30)992.3_J_AllDigital_NonOverlapped																										
<input type="checkbox"/> 12(bit32)992.4_I_AllDigital_NonOverlapped	<input checked="" type="checkbox"/> 13(bit34)992.3_L_Pots_NonOverlapped_Mode1																										
<input checked="" type="checkbox"/> 14(bit35)992.3_L_Pots_NonOverlapped_Mode2	<input type="checkbox"/> 15(bit39)992.3_M_Pots_Extend_US_NonOverlapped																										
<input checked="" type="checkbox"/> 16(bit40)992.5_A_Pots_NonOverlapped	<input checked="" type="checkbox"/> 17(bit42)992.5_B_Isdn_NonOverlapped																										
<input type="checkbox"/> 18(bit46)992.5_I_AllDigital_NonOverlapped	<input type="checkbox"/> 19(bit48)ANSI_T1424																										
<input type="checkbox"/> 20(bit49)ETSI_TS_101_270	<input type="checkbox"/> 21(bit50)993.1																										
<input type="checkbox"/> 22(bit51)IEEE_8023ah	<input type="checkbox"/> 23(bit56)992.5_J_AllDigital_NonOverlapped																										
<input type="checkbox"/> 24(bit58)992.5_M_Pots_Extend_US_NonOverlapped																											

(To be continued)

Carrier Mask-N

Click on this button to view/modify the current downstream/upstream Carrier Mask parameters. Input Carrier bit value and then click **Apply**.

*Modify Status:*

Complete – modems will re-train after you click on Apply button

[ADSL Spectrum Profile# 1 Carrier MASK](#)

BACK

DownStream Carrier Mask 0x[00]~0x[FF]								
Carrier[0~63]	00	00	00	00	00	00	00	00
Carrier[64~127]	00	00	00	00	00	00	00	00
Carrier[128~191]	00	00	00	00	00	00	00	00
Carrier[192~255]	00	00	00	00	00	00	00	00
Carrier[256~319]	00	00	00	00	00	00	00	00
Carrier[320~383]	00	00	00	00	00	00	00	00
Carrier[384~447]	00	00	00	00	00	00	00	00
Carrier[448~511]	00	00	00	00	00	00	00	00
UpStream Carrier Mask 0x[00]~0x[FF]								
Carrier[0~63]	00	00	00	00	00	00	00	00

Carriers 0 to 255 are used for all ADSL/ADSL2 operational modes except for ADSL2 Plus which uses carriers 0 to 511.

[ [ADSL Spectrum RFI](#) | [ADSL Spectrum OP Mode](#) ]

(To be continued)

Click on this button to view/modify Radio Frequency Interference (RFI) Bands data. Input the Start/Stop frequency, select the Ingress Level, Egress Control, Signal Type, and then click on the **Apply** button.

*Modify Status:*

Complete – modems will re-train after you click on Apply button

[ADSL Spectrum Profile# 1 RFI](#)

BACK

RFI-N

NO.	Start Frequency 0~12000 (kHz)	Stop Frequency 0~12000 (kHz)	Ingress Level	Egress Control	Signal Type
0	0	0	Low ▾	NoControl ▾	HAM ▾
1	0	0	Low ▾	NoControl ▾	HAM ▾
2	0	0	Low ▾	NoControl ▾	HAM ▾
3	0	0	Low ▾	NoControl ▾	HAM ▾
4	0	0	Low ▾	NoControl ▾	HAM ▾
5	0	0	Low ▾	NoControl ▾	HAM ▾
6	0	0	Low ▾	NoControl ▾	HAM ▾
7	0	0	Low ▾	NoControl ▾	HAM ▾

[ | [ADSL Spectrum Carrier Mask](#) | [ADSL Spectrum OP Mode](#) ]



#### 4.3.1.4 Spectrum ADSLx Profile

This option allows you to configure the ADSL2/2<sup>+</sup>/REDSL spectrum profile. From the ADSL menu, click on *Profile* and then *Spectrum Profile(ADSLx)*. The following page is displayed.

ADSL Spectrum Profile - ADSL2

Select Index: (1)1~4 <input type="button" value="Modify"/> <input type="button" value="Query"/> The First Index is default profile can't modify & delete. To modify Spectrum Adsl2,ReAdsl or Adsl2plus profile , please create spectrum main profile first.							
	Index	Modem Features	Direction	Aggregate Power	PSD Level	PBO	Max Rx Aggr. Allowed PWR
Next →	2	ADSL2	DS	10.0	-40.0	NA	NA
		Enabled	US	10.0	-38.0	OFF	25.5
<input type="radio"/>	1	ADSL2	DS	25.5	-40.0	----	----
		Disabled	US	25.5	-38.0	OFF	25.5
<input type="radio"/>	2	ADSL2	DS	25.5	-40.0	----	----
		Disabled	US	25.5	-38.0	OFF	25.5
<input type="radio"/>	3	----	DS	0.0	0.0	----	----
		----	US	0.0	0.0	----	0.0
<input type="radio"/>	4	----	DS	0.0	0.0	----	----
		----	US	0.0	0.0	----	0.0

ADSL2/ReADSL/ADSL2<sup>+</sup> Spectrum Profile

Label	Description
Select Index	Click on the drop-down list to select the range of profile index. Options are: 1~4, 5~8, ..., 117~120.
Index	This field shows the profile index.
Modem Features	Select ADSL2/ReADSL2/ADSL2+ and Enable/Disable special modem functions for better performance.
Direction	DS: downstream. US: upstream
Aggregate Power	Maximum nominal aggregate transmit power (0~25.5dB)
PSD Level	Maximum PSD level. Valid values are: ADSL2: -60 ~ -40 dB/Hz DS, -60 ~ -38 dB/Hz US ReADSL2: -60 ~ -37 dB/Hz DS, -60 ~ -32.9 dB/Hz US ADSL2+: -60 ~ -40 dB/Hz DS, -60 ~ -38 dB/Hz US
PSD Shape	Only for ADSL2+. Valid options are: Standard/CA100/CA110/CA120/CA130/CA140/CA150/ CA160CA170/CA180/CA190/CA200/CA210/CA220/CA230/ CA240/CA250/CA260/CA270/CA280
PBO	Power backoff operation mode (OFF/ON).
Max Rx Aggr. Allowed PWR	Maximum aggregate receive power over a set of subcarriers. It ranges from -25.5 to +25.5 dBm, with 0.1 dB steps.

### 4.3.1.5 TCA Profile

This option allows you to setup the PM counter threshold for TCA (threshold crossing alert). From the ADSL menu, click on *Profile* and then *TCA Profile*. The following page is displayed.

#### ADSL TCA Profile

(1)Page1 of 16 Modify Delete

The First Index is default profile can't modify & delete.  
 An Interval\_TCA's value range from 0 to 900 (sec)  
 A Day\_TCA's value range from 0 to 86400(Sec)  
 The int for Interval's(15Minute) TCA and the day for Day's TCA  
 The NE for Near\_End and the FE for Far\_End

Select No	Enable		int ESs	int SESs	int UASs	day ESs	day SESs	day UASs	int LOS	int LOF	int LOPWR	int LOL	int ErrFrm
<input type="checkbox"/>	1	Disabled	NE	0	0	0	0	0	0	0	NA	0	0
			FE	0	0	0	0	0	0	0	0	NA	0
<input type="checkbox"/>	2	Select	NE								NA		
			FE									NA	
<input type="checkbox"/>	3	Select	NE								NA		
			FE									NA	
<input type="checkbox"/>	4	Select	NE								NA		
			FE									NA	

#### ADSL TCA Threshold setup

Label	Description
<span>(1)Page1 of 16</span>	Click on this drop-down list to select the page to be displayed.
Modify	Once you have typed in new threshold values, click on this button to submit the modification.
Delete	Click on this button to delete a selected profile (or profiles).
Select	Click on the checkbox to select the profile you want to modify or delete.
Enable	To issue TCA when the PM statistics exceed thresholds, this profile must be enabled.
int/day ESs-NE/FE	Interval/Day Errored Seconds – near end/far end
int/day SESs-NE/FE	Interval/Day Severely Errored Seconds – near end/far end
int/day UASs-NE/FE	Interval/Day Unavailable Seconds – near end/far end
int LOS-NE/FE	Interval Loss of Signal – near end/far end
int LOF-NE/FE	Interval Loss of Frame – near end/far end
int LOPWR-FE	Interval Loss of Power – far end
int LOL-NE	Interval Loss of Link – near end
int ErrFrm-NE/FE	Interval Error Frame – near end/far end

## 4.3.2 Data & Inventory

### 4.3.2.1 Inventory

This option allows you to view the inventory of the ATUC and ATUR. From the *ADSL* menu, click on *Data & Inventory* and then *Inventory*. The following page is displayed.

#### ADSL Inventory

Port(ATUC)	Serial Number	Version Number	System Vendor ID	Modem Vendor ID
1	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
2	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
3	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
4	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
5	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
6	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
7	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
8	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
9	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
10	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
11	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM
12	Broadcom 6411/6510 A0	VE_6_4_7	0x4d54	BDCM


[ [Circuit Setup](#) | [System Inventory](#) ]

#### ADSL Inventory

Label	Description
Port 01~12	Click on this drop-down list and select the ports to be displayed.
Atux	Select ATUC or ATUR inventory to be displayed.
Query	To view inventory, click on this button once you have selected the port and ATUx.


### 4.3.2.2 Loop Test

This option allows you to do the ADSL Dual End Loop Test. From the *ADSL* menu, click on *Data & Inventory* and then *Loop Test*. The following page is displayed.



Click on the drop-down list and select the line port you want to test. Then click on **Diagnostics Run** to start a DELT. If you want to discontinue the test or make the loop go back to the normal state when the test has finished, just click on **Diagnostics Abort**.

**Test in progress:** Click on **Diagnostics Run** and then the following page is displayed.



**Test completed:** When the test has completed successfully, test result is displayed as follows.

ADSL Dual End Loop Test

Port-2 Diagnostics Run Diagnostics Abort

Dual	Attainable BitRate		Loop Attn		Signal Attn		SNR Margin		Actual Tx Power FE	
Port	DS(kbps)	US(kbps)	DS(db)	US(db)	DS(db)	US(db)	DS(db)	US(db)	DS(db)	US(db)
2	23039	1242	1.0	0.7	1.0	0.0	7.9	6.0	-3.4	12.3

LOOP DIAGNOSTICS COMPLETED...

Carrier Type: TSS  SNR  QLN  HLIN  HLOG

**The TSS formula:  $tss=value*(1/32768)$ .The Transmit Spectrum Shaping for the Downstream direction as exchanged at init.(Near-END)**

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	
0-31	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3275	3492	3723	3967	4265	4552	4857	5183	5545	5916	6310	6747	7193	7666
32-63	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
64-95	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
96-127	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
128-159	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
160-191	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
192-223	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
224-255	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
256-287	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
288-319	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
320-351	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
352-383	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
384-415	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
416-447	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
448-479	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768
480-511	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

**The TSS formula:  $tss=value*(1/32768)$ .The Transmit Spectrum Shaping for the Upstream direction as exchanged at init.(Far-END)**

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	
0-31	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	
32-63	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768	32768

Carrier Type: TSS  SNR  QLN  HLIN  HLOG

**The SNR formula:  $snr=-32+(value/2)$  (dB).The Signal to Noise Ratio per carrier over the Upstream passband.(Near-END)**

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
0-31	255	255	255	255	255	255	255	122	132	143	149	158	162	164	166	169	171	174	175	175	174	175	175	175	174	171	166	164	160	153	142	133
32-63	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255	255

**The SNR formula:  $snr=-32+(value/2)$  (dB).The Signal to Noise Ratio per carrier over the Downstream passband.(Far-END)**

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	
0-31	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	64	
32-63	64	142	144	148	151	153	157	160	162	163	166	169	170	172	173	174	176	177	178	179	179	180	180	181	182	181	182	183	183	183	183	183	
64-95	181	172	184	184	184	184	184	183	184	184	183	182	184	184	183	183	183	183	183	183	183	183	180	163	175	182	182	183	182	182	183	182	
96-127	182	182	182	182	181	182	181	181	181	181	181	181	181	181	181	181	180	181	181	180	181	180	180	180	180	180	180	180	180	180	180	179	179
128-159	179	179	178	179	179	179	177	176	179	179	179	179	178	179	178	179	179	178	178	179	179	178	178	179	178	178	178	179	178	178	178	178	178
160-191	178	177	178	178	178	177	177	177	177	177	177	177	177	177	177	177	177	177	177	177	176	177	176	176	177	175	176	176	176	176	176	176	176
192-223	175	176	176	176	175	176	175	175	175	175	175	174	173	174	175	174	174	174	174	174	174	174	174	174	174	174	174	174	174	174	174	173	174
224-255	174	174	174	174	174	174	175	174	174	174	174	175	174	173	173	172	174	173	172	174	173	174	174	174	174	174	174	174	174	174	174	170	170
256-287	171	171	174	174	174	173	173	173	173	172	172	172	171	172	172	172	171	172	171	169	170	170	169	171	171	170	170	170	172	170	170	171	171
288-319	170	171	170	171	170	171	170	172	172	172	172	172	171	172	171	173	171	172	171	172	172	172	171	171	172	171	172	171	171	172	169	171	171
320-351	170	170	170	170	169	169	169	169	169	169	167	167	167	166	169	166	166	165	166	164	164	164	163	162	162	163	161	161	161	161	162	163	163
352-383	162	162	161	161	161	163	161	161	161	164	165	163	162	165	165	163	164	164	163	165	164	164	166	166	167	166	165	165	165	164	167	165	165
384-415	167	164	165	163	163	164	164	162	164	161	161	162	161	162	161	161	159	165	164	163	161	161	163	162	161	160	160	161	155	155	157	153	153
416-447	152	159	157	160	160	158	160	160	160	159	161	161	160	162	156	157	158</																

Carrier Type: TSS  SNR  QLN  HLIN  HLOG

The QLN formula:  $qln = -23 - (\text{value}/2)$  (dBm/Hz). The Quiet Line Noise measurement per carrier over the Upstream passband. (Near-END)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	
0-31	255	195	190	191	190	190	194	179	170	166	175	173	173	172	174	180	176	180	174	181	178	178	185	182	182	183	182	181	184	186	188	191	
32-63	194	193	192	191	190	190	189	191	190	191	189	190	191	190	192	193	190	189	189	191	190	190	190	190	190	195	190	191	192	194	191	191	191

The QLN formula:  $qln = -23 - (\text{value}/2)$  (dBm/Hz). The Quiet Line Noise measurement per carrier over the Downstream passband. (Far-END)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
0-31	146	230	230	228	220	224	226	226	226	226	224	226	226	226	226	214	216	224	222	208	210	222	224	222	220	220	218	216	214	212	210	208
32-63	206	204	200	196	198	188	192	192	192	192	190	190	190	186	190	188	190	188	188	186	186	188	186	186	186	188	186	186	186	186	186	184
64-95	182	174	184	184	184	186	184	184	184	184	184	182	182	182	182	182	182	182	182	182	180	162	174	180	180	180	180	180	180	180	180	180
96-127	182	180	180	180	180	182	180	178	182	180	178	178	180	180	178	178	178	178	178	178	178	178	178	178	178	180	178	180	178	178	178	178
128-159	178	178	178	178	178	178	176	176	176	178	178	178	178	178	178	176	178	178	178	178	178	178	178	178	176	176	176	178	178	178	178	178
160-191	176	176	178	176	176	178	178	176	178	176	178	176	176	176	176	178	176	178	176	176	176	176	176	176	176	176	176	176	176	176	176	176
192-223	176	176	176	176	174	176	176	176	176	176	176	176	176	174	178	176	176	176	176	176	176	176	176	176	176	176	176	176	176	176	176	178
224-255	176	176	178	176	176	174	178	176	178	176	176	176	176	174	178	176	176	178	176	178	178	178	178	176	176	178	178	176	178	178	178	176
256-287	178	178	180	180	180	178	180	180	182	180	182	180	180	180	182	180	182	180	182	182	180	180	180	180	180	180	180	182	180	180	182	180
288-319	182	182	180	182	182	182	182	182	182	180	182	182	182	182	182	182	182	182	182	182	182	182	182	184	180	182	180	182	180	182	182	182
320-351	182	182	182	180	182	182	182	182	182	180	182	184	180	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182
352-383	182	182	182	182	182	182	182	182	182	180	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182	182

HlinUpstream Scale=48854

HlinDownstream Scale=38568

Carrier Type: TSS  SNR  QLN  HLIN  HLOG

The HLIN formula:  $hlin = (hlin.scale/32768) * (hlin.real + j * hlin.imag) / 32768$ . Complex values in linear scale for each carrier over the Upstream passband. (Near-End)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25					
0-31	=0 =1729	=3 =3	=5 =1	=8 =1	=8 =1	=19 =1	=1622 =1422	=8244 =3535	=20661 =19138	=16623 =22422	=14752 =25303	=32801 =1128	=15907 =28838	=16156 =29648	=32766 =4604	=23160 =21524	=833 =29757	=20699 =18309	=25652 =1596	=19221 =17544	=245 =21619	=13220 =14460	=17985 =2269	=13546 =4865	=4690 =13720	=4156 =12447					
32-63	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768	=-32768 =32768

The HLIN formula:  $hlin = (hlin.scale/32768) * (hlin.real + j * hlin.imag) / 32768$ . Complex values in linear scale for each carrier over the Downstream passband. (Far-End)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25					
0-31	=0 =1	=230 =230	=165 =165	=165 =100	=100 =100	=100 =100	=100 =100	=100 =100	=68 =68	=68 =68	=68 =68	=100 =100	=68 =68	=68 =68	=68 =68	=68 =68	=68 =68	=68 =68	=68 =68	=35 =35	=32 =32	=64 =64	=58 =58	=162 =162	=178 =178	=22 =22	=224 =224	=454 =454			
32-63	=-2198 =1827	=970 =3321	=1253 =4038	=3625 =3249	=6012 =714	=6369 =3110	=4239 =6973	=243 =9242	=5830 =9499	=10489 =4288	=12067 =2438	=9265 =9427	=2421 =13855	=6314 =13456	=16696 =7665	=16213 =1844	=12463 =11541	=3236 =17333	=8116 =16323	=16985 =8394	=19034 =3801	=13083 =15102	=1025 =20491	=12200 =17174	=20741 =6022	=20436 =4943					
64-95	=11476 =22845	=23832 =10469	=25465 =7291	=15135 =22271	=2704 =27228	=19839 =19430	=28985 =2155	=23199 =16667	=7077 =28049	=12885 =26319	=27150 =11891	=28702 =4837	=16446 =25407	=4015 =30293	=22939 =20395	=31072 =736	=24261 =31085	=5522 =27319	=16177 =10161	=30283 =12184	=29721 =28780	=14573 =31422	=7918 =18612	=26683 =3486	=32406 =24004	=22219 =24004					
96-127	=-30156 =13320	=31390 =9989	=16988 =28286	=6126 =32344	=26001 =20125	=-32754 =2236	=22946 =23407	=-1548 =23407	=-20379 =5200	=32166 =17547	=-27390 =31257	=8981 =29020	=14365 =11927	=-29984 =11158	=30215 =28426	=-14953 =31030	=-7901 =17716	=26566 =4652	=-31500 =24481	=20196 =31617	=1444 =22328	=-22328 =31396	=13196 =19787	=-24293 =1652	=4652 =19787	=17268 =30871	=-29910 =19787				
128-159	=15138 =26364	=6596 =29698	=24780 =17300	=28874 =3921	=18303 =22985	=1292 =29900	=21099 =21092	=-29738 =1279	=22670 =19079	=-3769 =29293	=16942 =24046	=20985 =6171	=-25225 =14949	=9489 =27923	=12628 =26173	=-26952 =10568	=26988 =10401	=-12742 =27556	=8116 =14706	=24282 =5989	=-27832 =23193	=16505 =23193	=3616 =28153	=-21696 =18177	=28179 =1385	=19688 =20102					
160-191	=26683 =7035	=24277 =12947	=8970 =29306	=11044 =29069	=25059 =10827	=25699 =9119	=12596 =24085	=7142 =26140	=22972 =14258	=-26478 =5174	=15816 =21764	=3227 =26534	=-20452 =17277	=26683 =1275	=18921 =19056	=642 =26598	=17802 =18036	=-26332 =2529	=20949 =16073	=-4389 =25978	=-14466 =21933	=25475 =6171	=-22793 =12826	=7944 =24965	=11138 =23540	=-24166 =9609					
192-223	=4184 =25280	=-20280 =15396	=25390 =2451	=-16881 =19069	=-678 =25416	=17810 =19063	=-25306 =1061	=19180 =16485	=-2743 =25079	=-15076 =20173	=24757 =4428	=-21073 =13638	=6074 =24313	=12167 =21855	=-23770 =7655	=22566 =10612	=-9197 =23124	=-9077 =23121	=22284 =10697	=-23605 =7476	=12115 =21536	=-20644 =23975	=24238 =13482	=-14768 =4246	=-2642 =19657	=24394 =24394					
224-255	=-19147 =14946	=3756 =23975	=13632 =20021	=-23598 =5288	=20906 =12255	=-6794 =23163	=-10859 =21514	=22805 =4062	=-9631 =21959	=9687 =22628	=7940 =11064	=-21238 =6454	=23030 =20440	=-12382 =23339	=-4950 =13641	=19543 =3418	=-23566 =18883	=14836 =23673	=1895 =19792	=-17557 =360	=23702 =16469	=-17001 =23611	=1139 =15387	=-23452 =17982	=18988 =2636	=23452 =14102					
256-287	=-21819 =8424	=21631 =8827	=-9739 =21219	=7389 =22108	=20530 =11031	=-22475 =5976	=12288 =19735	=-4535 =22780	=-18869 =13485	=22988 =3074	=-14615 =17953	=-1636 =23063	=16969 =15683	=-23085 =185	=16687 =15907	=23985 =23011	=16687 =17618	=15687 =2704	=1772 =13645	=-14794 =22556	=22833 =19264	=-19475 =19264	=4129 =5522	=12427 =11174	=19953 =21771	=-6882 =19527	=-9989 =21274	=21271 =11460	=12171 =4538	=21271 =18816	=18816 =21524
288-319	=-4444 =22189	=18401 =13096	=-22371 =3061	=14200 =17511	=1645 =22469	=-16570 =15219	=22469 =249	=-16200 =15530	=1149 =22400	=14482 =17086	=-22254 =2535	=17923 =13372	=-3879 =21985	=-12213 =18660	=21644 =5256	=-19329 =10992	=6548 =21248	=9746 =19946	=-20732 =7837	=20475 =9496	=-9073 =20177	=-7181 =20901	=19527 =10294	=-21274 =3872	=11460 =18816	=4538 =18816	=21524 =21524				

Carrier Type: TSS  SNR  QLN  HLIN  HLOG

The HLOG formula:  $6 - (\text{value}/10)(\text{dB})$ . Real values in dB for each carrier over the Upstream passband.(Near-END)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
0~31	251	1023	776	776	776	673	262	138	39	39	35	27	23	23	25	28	34	40	46	53	61	70	78	87	96	105	113	122	130	137	144	152
32~63	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023	1023

The HLOG formula:  $6 - (\text{value}/10)(\text{dB})$ .Real values in dB for each carrier over the Downstream passband.(Far-END)

Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
0~31	850	490	490	490	520	520	520	520	560	560	560	520	560	560	560	560	560	610	620	520	570	510	490	470	430	410	390	370	340	320	300	280
32~63	260	250	230	210	200	180	170	160	150	140	140	130	120	120	110	110	100	100	100	100	90	90	90	90	80	80	80	80	80	80	80	70
64~95	70	70	70	70	70	60	60	60	60	60	60	60	60	60	60	60	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	
96~127	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	
128~159	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	60	70
160~191	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70
192~223	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	80	80	80	80	80	80	80	80	80	80	80	80
224~255	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80
256~287	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80
288~319	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80
320~351	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90
352~383	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90
384~415	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90
416~447	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100
448~479	120	120	120	120	120	120	120	120	120	130	130	130	130	130	130	130	130	130	140	140	140	140	140	140	140	140	150	150	150	150	150	150
480~511	160	170	170	170	170	180	180	180	180	190	190	190	190	190	200	200	200	210	210	210	220	220	230	230	230	240	240	240	240	250	250	250

### 4.3.2.3 Carrier Data

This option allows you to view the ADSL line carrier data. From the *ADSL* menu, click on *Data & Inventory* and then *Carrier Data*. The following page is displayed.

Select the line port (1 ~ 48) and carrier type (LOAD or GAIN). Then click on **Query** button. Note that if the line port is still in loop testing status, you cannot query the carrier data.

ADSL Carrier Data

Port:	2	Type:	LOAD <input type="radio"/> GAIN <input checked="" type="radio"/>	Query																															
<b>The LOAD formula: load=value*(1/256).The bit LOAD distribution over Downstream passband.(Near-END)</b>																																			
Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31			
0~31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
32~63	0	6	6	7	8	8	9	9	10	10	11	10	11	11	12	12	12	12	13	13	13	13	14	13	14	14	14	14	14	14	15	14	15		
64~95	0	0	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	13	15	15	15	15	15	15	15	15	15		
96~127	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15		
128~159	0	0	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15		
160~191	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	
192~223	0	0	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	
224~255	14	15	15	15	2	15	15	15	15	15	15	15	14	15	15	15	15	14	15	15	15	15	14	15	15	15	15	15	15	15	15	15	14	15	
256~287	0	0	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15
288~319	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15
320~351	0	0	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	14
352~383	15	15	15	15	15	15	14	15	15	15	15	15	15	14	15	15	15	14	15	15	15	14	15	15	15	14	15	15	15	14	15	14	15	15	15
384~415	0	0	15	14	15	15	14	15	14	15	14	15	14	15	14	15	14	15	14	15	14	15	14	15	14	15	14	15	14	14	15	14	15	14	15
416~447	15	14	14	15	14	15	14	14	15	14	15	14	14	15	14	14	15	14	14	14	15	14	14	15	14	14	15	14	14	14	15	14	14	14	14
448~479	0	0	15	14	14	14	14	14	14	14	14	14	14	14	14	14	13	14	14	13	14	14	13	14	13	13	14	13	13	13	14	13	13	13	13
480~511	13	13	13	13	12	13	12	13	12	12	12	12	12	12	12	11	11	11	10	11	10	10	9	9	9	9	7	7	6	6	3	2	0	0	0
<b>The LOAD formula: load=value*(1/256).The bit load distribution over Upstream passband.(Far-END)</b>																																			
Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31			
0~31	0	0	0	0	0	0	0	8	9	11	11	12	13	13	14	14	14	14	15	15	15	15	15	15	15	15	14	14	13	12	11	11	9		
32~63	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Port:	2	Type:	LOAD <input type="radio"/> GAIN <input checked="" type="radio"/>	Query																															
<b>The GAIN formula: gain=value*(1/512).The GAIN allocation over the Downstream passband.(Near-END)</b>																																			
Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31			
0~31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
32~63	0	482	394	469	541	455	541	469	573	496	625	394	496	455	590	541	482	442	590	541	482	442	455	625	406	541	511	482	469	455	608	418	573		
64~95	573	482	526	496	482	482	469	455	430	442	442	442	418	418	418	406	418	406	406	406	406	406	442	469	496	394	406	394	394	394	406	406	406		
96~127	406	406	406	394	406	406	418	406	406	406	406	418	418	418	430	430	430	430	430	430	430	442	442	442	442	455	455	455	455	455	469	469	482		
128~159	469	482	482	482	482	482	511	526	482	496	482	496	496	496	482	496	482	496	482	482	469	482	469	482	482	469	469	455	469	455	469	455	455		
160~191	455	455	455	455	455	455	455	455	455	469	455	469	455	455	482	469	455	469	455	455	455	455	469	482	469	469	469	469	469	469	455	469	455	482	
192~223	469	469	482	482	482	482	482	496	496	482	496	496	496	496	496	511	496	511	496	496	496	496	511	511	496	496	526	526	496	526	526	511	511		
224~255	372	511	526	526	511	511	526	526	526	526	541	372	541	541	526	541	383	541	541	557	526	383	526	541	526	511	526	511	526	526	372	608	608		
256~287	394	482	482	496	482	482	482	482	496	496	496	496	496	496	526	496	496	496	496	482	482	482	482	482	482	469	469	469	482	469	469	482	482	482	
288~319	455	469	482	482	482	482	482	482	482	482	482	482	482	482	496	496	482	496	482	482	482	482	482	482	496	496	496	496	496	496	496	496	496	496	
320~351	496	496	511	496	496	511	496	496	496	511	511	511	511	526	511	496	511	511	526	511	526	511	511	511	511	511	511	511	526	526	526	526	383	573	
352~383	526	526	526	541	526	526	383	526	526	526	526	541	526	383	541	541	541	394	541	541	557	383	557	557	541	406	557	406	557	573	406	573	573		
384~415	557	406	573	406	573	573	418	573	406	590	406	590	418	573	418	590	406	590	418	590	418	608	430	608	430	590	430	430	590	430	608	430	430		
416~447	608	430	430	608	430	608	430	430	608	442	625	442	442	625	442	442	625	455	442	455	625	455	455	455	644	455	455	455	469	644	469	469	482		
448~479	482	482	681	496	496	496	511	496	496	496	526	511	541	526	541	383	541	557	406	557	590	418	590	430	430	625	442	455	455	662	482	482	482		
480~511	496	511	526	541	394	590	418	608	455	469	482	511	541	557	573	442	469	541	418	625	496	557	418	496	541	430	496	469	590	482	394	0	0	0	
<b>The GAIN formula: gain=value*(1/512).The gain allocation over the Upstream passband.(Far-END)</b>																																			
Carrier	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31			
0~31	0	0	0	0	0	0	0	556	444	494	467	465	524	505	556	540	466	431	524	479	453	458	466	481	528	433	527	447	448	513	556	592			
32~63	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0



#### 4.3.2.4 OP Data

This option allows you to view the ADSL line/channel operational data and carrier data. From the *ADSL* menu, click on *Data & Inventory* and then *OP Data*. The following page is displayed.

**Line Operational Data:** Click on *ADSL OP Data* drop-down list and select the item *Line (OP)*. Then select the line port (1 ~ 48). Click on **Query** button.

ADSL Line Operational Data

ADSL OP Data: Line (OP) Port-1 Query		
ADSL LINE OP Data	NE US	FE DS
Rel Capacity Occupation	109(%)	100(%)
Noise Margin	3.5(db)	8.0(db)
Signal Attenuation	1.5(db)	0.0(db)
Loop Attenuation	1.8(db)	0.0(db)
ADSL LINE OP Data	NE DS	FE US
Output Power	12.1(dbm)	9.5(dbm)
Actual PSD	-50.0(dbm/Hz)	-38.0(dbm/Hz)
ADSL LINE OP Data	NE	FE
Line Status	Run Showtime L0	N/A
Actual Op Mode	(992.1_A_Pots_NonOverlapped)	N/A
ATUC Op Mode Capabilities	(ANSI_T1413)	(992.1_A_Pots_NonOverlapped)
	(ETSI_DTS_TM06006 )	(992.2_A_Pots_NonOverlapped)
	(992.1_A_Pots_NonOverlapped)	
	(992.1_B_Isdn_NonOverlapped)	
	(992.2_A_Pots_NonOverlapped)	
	(992.3_A_Pots_NonOverlapped)	
	(992.3_B_Isdn_NonOverlapped)	
	(992.3_L_Pots_NonOverlapped_Mode1)	
	(992.3_L_Pots_NonOverlapped_Mode2)	
	(992.3_M_Pots_Extend_US_NonOverlapped)	
(992.5_A_Pots_NonOverlapped)		
(992.5_B_Isdn_NonOverlapped)		
(992.5_M_Pots_Extend_US_NonOverlapped)		

**Channel Operational Data:** Click on *ADSL OP Data* drop-down list and select the item *Channel (OP)*. Then select the port (1~48). Click on **Query** button. The following page is displayed.

ADSL Channel Operational Data

ADSL OP Data: Channel(OP) Port-1 Query		
ADSL LINE OP Data	NE US	FE DS
Actual Bitrate(kbps)	1120	8128
Attainable Bitrate(kbps)	1024	8128
ADSL LINE OP Data	NE DS	FE US
Actual Interleaving Delay(ms)	0	0
Actual Impulse Noise Protection(Symbol)	0.0	0.0

### 4.3.3 Line Config & Info

#### 4.3.3.1 Line Configuration

This option allows you to setup the ADSL line configuration. From the *ADSL* menu, click on *Line Config & Info* and then *Line Configuration*. The following page is displayed.

ADSL Line Configuration

Port	OP MASK ID	Op Mode Board Capability	Carrier Data	Loop Diagnostics	Force L3 Mode
1	ANSI_T1413 ETSI_DTS_TM06006 992.1_A_Pots_NonOverlapped 992.1_B_Isdn_NonOverlapped 992.2_A_Pots_NonOverlapped 992.3_A_Pots_NonOverlapped 992.3_B_Isdn_NonOverlapped 992.3_L_Pots_NonOverlapped_Mode1 992.3_L_Pots_NonOverlapped_Mode2 992.3_M_Pots_ExtUS_NonOverlapped 992.5_A_Pots_NonOverlapped 992.5_B_Isdn_NonOverlapped 992.5_M_Pots_ExtUS_NonOverlapped		OFF	OFF	OFF

ADSL Line Configuration

Label	Description
ADSL Port From...To...	Type in the line port range. Valid number: 1 ~ 48.
Operational Mask Mode	Select the Operational Mode(s) to be masked. Select the modes in the block by using mouse and Shift or Ctrl key. Select the check box and then click on <b>Modify</b> button.
Carrier Data Mode	Click on this drop-down list and select the carrier data mode. Select the check box and then click on <b>Modify</b> button. OFF - Carrier data won't vary during show time. ON - Carrier data collection is active. The carrier data will be refreshed during show time. ON INIT - The ADSL facility is re-initialized and carrier data collection is active (will be refreshed).
FORCE L3 Mode	Click on this drop-down list and select ON to force the ADSL port to enter power management L3 mode (Idle state). Select the check box and then click on <b>Modify</b> button.
Modify	Click on this button to submit modification.
Query	Click on this button to display current line configuration.

### 4.3.3.2 Line Information

This option allows you to setup the ADSL line information. From the *ADSL* menu, click on *Line Config & Info* and then *Line Information*. The following page is displayed.

ADSL Line Information

ADSL Port from 1 To 5			
<input type="button" value="Modify"/> <input type="button" value="Query"/>			
Port	Identifier	Phone No	Description
<input checked="" type="checkbox"/> 1	ADSL-1	886-32826433	Mak Office
<input type="checkbox"/> 2			
<input type="checkbox"/> 3			
<input type="checkbox"/> 4			
<input type="checkbox"/> 5			

ADSL Line Information

Label	Description
ADSL Port From...To...	Type in the line port range. Valid number: 1~48.
Modify	Click on this button to submit the modification once you have entered new value for the ADSL line information. Note that to modify an entry, you must select the checkbox on the leftmost column before you click on Modify.
Query	Once you have typed in the port number range, click on this button to display line information of these ports.
Identifier	Type in the ADSL line identifier. Up to 63 characters is allowed.
Phone No	Type in the phone number. Up to 63 characters is allowed.
Description	Type in any comment of this line. Up to 63 characters is allowed.

## 4.4 Traffic

### 4.4.1 ATM Traffic Descriptor

This option allows you to modify the traffic table. From the *Traffic* menu, click on *ATM Traffic Descriptor*. The following page is displayed:

ATM Traffic Descriptor

---

PCR	CDVT	SCR	MBS	TYPE			
20000	10000	0	0	Policed			
Descriptor: (2) [Policed CBR]atm<CLP> <Transparent> [NoSCR] <input type="button" value="Create"/>							
<input type="button" value="Delete"/>							
Delete Select	Row No.	ATM Traffic Descriptor	PCR	CDVT	SCR	MBS	TYPE
<input type="radio"/>	DEF	[Unshaped]atmNoTrafficDescriptor	0	0	0	0	SHAPED
<input type="button" value="ADSL PVC CONFIGURATION"/>							

### ATM Traffic Descriptor Setup

Label	Description
PCR	PCR stands for Peak Cell Rate (cells/second).
CDVT	CDVT stands for Cell Delay Variation Tolerance (microseconds).
SCR	SCR stands for Sustained Cell Rate (cells/second).
MBS	MBS stands for Maximum Burst Size (cells).
TYPE	This field will show Shaped or Policed depending on the descriptor type you select.
Descriptor	<p>Click on this drop-down list and select a descriptor type. After you select a descriptor type, the corresponding parameters (which are configurable) will be displayed on the top. Valid descriptor types are:</p> <p><b>[Unshaped] atmNoTrafficDescriptor:</b> This identifies no ATM traffic descriptor type. This traffic descriptor type can be used for best effort traffic.</p> <p><b>[Policed CBR] atmCLPTransparentNoScr /</b> <b>[Shaped CBR] atmCLPTransparentNoScr:</b> This traffic descriptor type is for the CLP- transparent model and no Sustained Cell Rate. This traffic descriptor type is applicable to connections following the CBR.1 conformance definition. Connections specifying this traffic descriptor type will be rejected at UNI 3.0 or UNI 3.1 interfaces. For a similar traffic descriptor type that can be accepted at UNI 3.0 and UNI 3.1 interfaces, see "atmNoClpNoScr".</p> <p><b>[Policed VBR1] atmNoCLPScrCdv:</b> This traffic descriptor type is for no CLP with Sustained Cell Rate and CDVT. This traffic descriptor type is applicable to VBR connections following the UNI 3.0/3.1 conformance definition for PCR CLP=0+1 and SCR CLP=0+1. These VBR connections differ from VBR.1</p>

	<p>connections in that the CLR objective applies only to the CLP=0 cell flow.</p> <p><b>[Policed VBR2] atmCLPNoTaggingScrCdvT /</b>  <b>[Shaped VBRNRT] atmCLPNoTaggingScrCdvT:</b>  This traffic descriptor type is for CLP with Sustained Cell Rate and CDVT and no tagging. This traffic descriptor type is applicable to connections following the VBR.2 conformance definition.</p> <p><b>[Policed VBR3] atmCLPTaggingScrCdvT:</b>  This traffic descriptor type is for CLP with tagging and Sustained Cell Rate and CDVT. This traffic descriptor type is applicable to connections following the VBR.3 conformance definition.</p> <p><b>[Policed UBR1] atmNoCLPNoScrCdvT:</b>  This traffic descriptor type is for no CLP with CDVT and no Sustained Cell Rate. This traffic descriptor type is applicable to CBR connections following the UNI 3.0/3.1 conformance definition for PCR CLP=0+1. These CBR connections differ from CBR.1 connections in that the CLR objective applies only to the CLP=0 cell flow. This traffic descriptor type is also applicable to connections following the UBR.1 conformance definition.</p> <p><b>[Policed UBR2] atmNoCLPTaggingNoScr:</b>  This traffic descriptor type is for no CLP with tagging and no Sustained Cell Rate. This traffic descriptor type is applicable to connections following the UBR.2 conformance definition.</p> <p><b>[Shaped UBR] atmNoCLPNoScr:</b>  This traffic descriptor type is for no CLP and no Sustained Cell Rate</p> <p><b>[Shaped VBR] atmCLPTransparent:</b>  This traffic descriptor type is for the CLP- transparent model with Sustained Cell Rate. This traffic descriptor type is applicable to connections following the VBR.1 conformance definition. Connections specifying this traffic descriptor type will be rejected at UNI 3.0 or UNI 3.1 interfaces. For a similar traffic descriptor type that can be accepted at UNI 3.0 and UNI 3.1 interfaces, see "atmNoClpScr".</p>
Create	Click on this button to create a new traffic descriptor.
Delete	When you want to delete a traffic descriptor, click on the radio button beside the row number to select the traffic descriptor and then click on the Delete button. Note that the default profile cannot be deleted.

## 4.5 SNMP

### 4.5.1 SNMP Community

This option allows you to configure the SNMP community that is the group that IDL-4802s and management stations running SNMP belong to. It helps define where information is sent. The community name is used to identify the group and serve as form of authentication. From the *SNMP* menu, click on *SNMP Community*. The following page is displayed.

#### SNMP Community

Select modify/delete	No.	Community Name	Access Mode
	1	public	Read/Write


#### SNMP Community Setup

Label	Description
New	<p>Click on this button to create a new SNMP community. After you click on New, the following page is displayed. Type in the name of the SNMP community (up to 63 characters; note that community names beginning with a digital number are not allowed) and select the access mode (Read only or Read/Write). Then click on <b>Apply</b> button.</p> <p style="text-align: center;"><a href="#">SNMP Community</a></p>
Access Mode	Select the SNMP community access mode: Read only or Read/Write.
Modify	Click on this button to modify the community name.
Delete	Select an index and then click on this button to delete a community.


### 4.5.2 SNMP Target

This option allows you to configure the SNMP target to control where the SNMP traps (notifications) are sent. Traps are used to report an alarm or other asynchronous event about a managed IDL-4802 system. From the *SNMP* menu, click on *SNMP Target*. The following page is displayed.

#### SNMP Target



#### SNMP Community Setup

Label	Description
New	<p>Click on this button to create a new SNMP target. After you click on New, the following page is displayed. Type in the IP Address, Name and Tag of the SNMP target, Address Port (Usually SNMP uses UDP port 161 for general SNMP messages and UDP port 162 for SNMP trap messages), and select Trap Version (V1 or V2c). Then click on Apply button. The Target Tag can be the same with a Notify Tag; you can select the Notify Tag in the <b>Use Notify Tag</b> field. The Notify Tag is created in the SNMP Notify table. When the Target Tag is the same with a Notify Tag, the SNMP notification with that Notify Tag is sent to the Target with the same tag.</p> <p style="text-align: center;">SNMP Target</p> 
Target No.	Click on this drop-down list and select the SNMP target number.
Query	Select the target number and then click on this button to retrieve the information.
Delete	Select the target number and then click on this button to delete a target.
Modify	Select the target number and then click on this button to modify the target setting.

### 4.5.3 SNMP Notify

This option allows you to setup the SNMP Notification (In SNMPv1, asynchronous event reports are called traps while they are called notifications in later versions of SNMP). From the *SNMP* menu, click on *SNMP Notify*. The following page is displayed.

SNMP Notify

---

Next No:[3]

Delete/Modify Notify No:

Select modify/delete	Notify#	Notify Name	Notify Tag
<input checked="" type="radio"/>	<b>No.1</b>	123	<input type="text" value="123_Tag"/>
<input type="radio"/>	<b>No.2</b>	abc	abc_Tag

### SNMP Community Setup

Label	Description						
Notify No.	This field shows the Notify number you select.						
New	<p>Click on this button to create a new SNMP Notify. After you click on New, the following page is displayed. Type in the name and tag of the SNMP Notify and click on <b>Apply</b> button.</p> <p>By specifying the Notify tag, you can bind the Notify name to the SNMP target address table. When the Notify tag is the same with the Target Tag in a SNMP target table, the notification is sent to the corresponding Target address.</p> <p style="text-align: center;">SNMP Notify</p> <hr/> <div style="border: 1px solid #ccc; padding: 5px; margin: 10px auto; width: fit-content;"> <p><input type="button" value="Apply"/> <input type="button" value="Back"/></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #e1f5fe;"> <th colspan="2" style="text-align: left;">SNMP Notify No.3</th> </tr> </thead> <tbody> <tr> <td style="width: 30%;"><b>Notify Name</b></td> <td><input type="text" value="SnmNotifyName3"/></td> </tr> <tr> <td><b>Notify Tag</b></td> <td><input type="text" value="SnmNotifyTag3"/></td> </tr> </tbody> </table> </div>	SNMP Notify No.3		<b>Notify Name</b>	<input type="text" value="SnmNotifyName3"/>	<b>Notify Tag</b>	<input type="text" value="SnmNotifyTag3"/>
SNMP Notify No.3							
<b>Notify Name</b>	<input type="text" value="SnmNotifyName3"/>						
<b>Notify Tag</b>	<input type="text" value="SnmNotifyTag3"/>						
Delete	Select a row and then click on this button to delete a Notify.						
Modify	Select the row and type in new notify tag and then click on this button to submit the modification.						



## 4.6 Maintenance

### 4.6.1 SYS Log Server

This option allows you to configure the IP address of the SYS Log server which listens for incoming Syslog messages. From the *Maintenance* menu, click on *SYS Log Server*. The following page is displayed.

System Log Server

---

Modify Action: Stop ▼

**Change Server Address**      192 . 168 . 1 . 1


#### SYS Log Server Setup

Label	Description
Current Server IP	This field shows the IP address of current Sys Log server.
Change Server Address	Type in the new IP address of Sys Log server. The server must be a remote host.
Modify	To change SYS Log server address, click on this button once you have type in a new server IP address.
Action	Click on this drop-down list and select <b>Start</b> to start sending the Syslog messages to the server or <b>Stop</b> to stop sending the Syslog messages to the server.


### 4.6.2 Database

This option allows you to import/export the configuration data. From the *Maintenance* menu, click on *Database*. The following page is displayed. Select the database configuration action you want to perform.

#### Database Configuration



### DB Configuration Concept:



**(A) Import File (Write Download Config To Flash):**

Type in the TFTP Server IP address and the name of the file you want to download. Then click on **Get File** button.

Database Configuration

---

DB Config Select:	(A)Import File (Write Download Config To FLASH)	<input type="button" value="Get File"/>
Write flash at:	Partition2	
TFTP Server IP:	172.16.10.241	File Name: config1

Write downloaded Config to Flash in progress:

Database Configuration

---

DB Config Select:	(A)Import File (Write Download Config To FLASH)	<input type="button" value="Get File"/>
Write flash at:	Partition2	
TFTP Server IP:	172.16.10.241	File Name: config1
<b>Action Name</b>	WRITE_DOWNLOAD	
<b>Action Status</b>	MEMORY WRITE IN PROGRESS	

Write to memory successfully:

Database Configuration

---

DB Config Select:	(A)Import File (Write Download Config To FLASH)	<input type="button" value="Get File"/>
Write flash at:	Partition2	
TFTP Server IP:	172.16.10.241	File Name: config1
<b>Action Name</b>	WRITE_DOWNLOAD	
<b>Action Status</b>	MEMORY WRITE SUCCESS	

Fail to Get File:

---

DB Config Select:	(A)Import File (Write Download Config To FLASH)	<input type="button" value="Get File"/>
Write flash at:	Partition2	
TFTP Server IP:	172.16.10.28	File Name: config1
<b>Action Name</b>	GET_LOCAL	
<b>Action Status</b>	TFTP GET FAIL	

## (B) Import File (Load Remote Config to Running Config)

Type in the TFTP Server IP address and the name of the file you want to download. Then click on **Get File** button.

### Database Configuration

---

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.241	File Name: config1
		<input type="button" value="Get File"/>

Load to Running Config successfully:

### Database Configuration

---

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.241	File Name: config1
		<input type="button" value="Get File"/>
<b>Action Name</b>	LOAD_REMOTE	
<b>Action Status</b>	MEMORY READ SUCCESS	

Fail to Get File:

### Database Configuration

---

DB Config Select:	(B)Import File (Load Remote Config to Running Config)	
TFTP Server IP:	172.16.10.28	File Name: config1
		<input type="button" value="Get File"/>
<b>Action Name</b>	GET_LOCAL	
<b>Action Status</b>	TFTP GET FAIL	

### (C) Export File (Put Running Config to Remote TFTP Server)

Type in the TFTP Server IP address and the name of the file you want to export. Then click on **Put File** button.

#### Database Configuration

---

DB Config Select:	(C)Export File (Put Running Config To Remote TFTP Server) ▼			
TFTP Server IP:	172.16.10.241	File Name:	config1	Put File

TFTP put file successfully:

#### Database Configuration

---

DB Config Select:	(C)Export File (Put Running Config To Remote TFTP Server) ▼			
TFTP Server IP:	172.16.10.241	File Name:	config1	Put File
<b>Action Name</b>	PUT_REMOTE			
<b>Action Status</b>	TFTP PUT SUCCESS			

TFTP put file fail:

#### Database Configuration

---

DB Config Select:	(C)Export File (Put Running Config To Remote TFTP Server) ▼			
TFTP Server IP:	172.16.10.28	File Name:	config1	Put File
<b>Action Name</b>	PUT_REMOTE			
<b>Action Status</b>	TFTP PUT FAIL			

### (D) Save Running Config to Flash (System Config)

Click on the drop-down list and select partition, and then click on **Write\_Running** button to write running configuration to Flash.

Database Configuration

---

DB Config Select:	(D)Save Running Config to Flash(System Config) ▼	
Write flash at:	Partition2 ▼	Write_Running

Write running config to Flash successfully:

Database Configuration

---

DB Config Select:	(D)Save Running Config to Flash(System Config) ▼	
Write flash at:	Partition2 ▼	Write_Running
<b>Action Name</b>	WRITE_RUNNING	
<b>Action Status</b>	MEMORY WRITE SUCCESS	

### (E) Reload Flash to Running Config

Click on the drop-down list and select partition, and then click on **LOAD\_FLASH** button to load configuration from Flash to Running Config.

#### Database Configuration

---

DB Config Select:	(E)Reload FLASH(System Config) to Running Config	▼
Load flash at:	Partition2	▼
		LOAD_FLASH

Load configuration from Flash to Running Config successfully:

#### Database Configuration

---


DB Config Select:	(E)Reload FLASH(System Config) to Running Config	▼
Load flash at:	Partition2	▼
		LOAD_FLASH
<b>Action Name</b>	LOAD_FLASH	
<b>Action Status</b>	MEMORY READ SUCCESS	

## (F) Restore Factory Default

Except out-band IP address and user account, all other configuration will be restored to factory default.

Click on **Factory\_Default** button to restore factory default configuration.


### Database Configuration



DB Config Select: (F)Restore Factory Default

Factory Default

After loading default configuration to Flash successfully, you must click on **RESTART** button to restart the system so that the configuration can take effect.



Database Configuration

DB Config Select: (F)Restore Factory Default

Factory Default

<b>Action Name</b>	RESTORE_FACTORY
<b>Action Status</b>	MEMORY WRITE SUCCESS


Would you like to restart system? RESTART



### (G) Flash Boot Point Configuration Select

Click on the *Boot Config* drop-down list and select the partition (Partition1 or Partition2) as the boot point. Click on **Apply** button and then restart the system. The system will restart and load the configuration in the partition you select into the running configuration.

#### Database Configuration



### 4.6.3 Firmware Update

This option allows you to ftp get the firmware from a server and write to flash for updating the system firmware. From the *Maintenance* menu, click on *Firmware Update*. The following page is displayed.

Firmware Update			
<b>Remote FTP Server IP</b>	172 . 16 . 10 . 41 ; 21		
<b>Server User Name</b>	[ share ]		
<b>Server Password</b>	[ ***** ]		
<b>File Name</b>	[ vmlinux_4802_0.73B05 ]		
<b>Firmware Update Status</b>	No Action[0]		
Firmware Partition Select:	Partition 2 ▾		
Once system has 2 versions, an operator can use Partition Select from 1 to 2, vice versa. (e.g)Partition changes from version A.a to version B.b			
<b>Partition Location</b>	Version	Build Date	Status
<b>Partition:1</b>	0.73B05	2007/07/10	----
<b>Partition:2</b>	0.73B05	2007/07/10	Active
<b>Current Version</b>	0.73B05		
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>			
<b>2.Once the system has upgraded already, please restart it!</b>			

Firmware Update

Label	Description
Firmware Update	Once you have typed in the parameter values, click on this button to start firmware update.
Remote FTP Server IP	Type in the IP address of the FTP server.
Server User Name	Type in the ftp user name.
Server Password	Type in the ftp password.
File Name	Type in the firmware path and filename (max 31 characters).
Firmware Update Status	This field shows current status of firmware update process.
Firmware Partition Select	Select firmware memory partition (Partition 1 or 2). if you change to the other partition (not current partition), the system will restart immediately.
Partition Information	This section displays the partition information including firmware version, updating date, and status (active or not). Note that active partition means the partition for next power-up, not current partition in use. You can refer to <b>Current Version</b> to know which partition is the current partition in use. When you update the firmware, new firmware will be written to the partition that is not currently in use.

### FTP Get in progress:

The following message is displayed during getting file from FTP server.

```
incoming cluster id 0  
FTP SERVER IP=172.16.10.41  
Waiting for FTP Session (about 30 sec..)
```

### Firmware Write in progress:

The Flash Write process may take a few minutes; **you must not turn off or reset the system during the process.**

Current Service	james@172.16.10.41,File:vmlinux_u4802_0.73B05
Firmware Update Status	/ FLASH WRITE IN PROGRESS /
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>	
<b>2.Once the system has upgraded already, please restart it!</b>	

### Firmware Write successfully:

When the Flash Write process has completed successfully, the Firmware Update Status shows “Firmware has upgraded already”. You can now restart the system.

#### Firmware Update

Firmware Update			
<b>Remote FTP Server IP</b>	. . . : 21		
<b>Server User Name</b>	[ ]		
<b>Server Password</b>	[ ]		
<b>File Name</b>	[ ]		
<b>Firmware Update Status</b>	<b>Firmware has upgraded already[7]</b>		
Firmware Partition Select: <input type="button" value="Partition 1"/>			
Once system has 2 versions, an operator can use Partition Select from 1 to 2, vice versa. (e.g)Partition changes from version A.a to version B.b			
<b>Partition Location</b>	<b>Version</b>	<b>Build Date</b>	<b>Status</b>
<b>Partition:1</b>	0.73B05	2007/07/10	Active
<b>Partition:2</b>	0.73B05	2007/07/10	-----
<b>Current Version</b>	0.73B05		
<b>1.[Warning]Upgrading firmware may take a few minutes, please don't turn off or reset the system.</b>			
<b>2.Once the system has upgraded already, please restart it!</b>			

#### 4.6.4 ATM Loopbacks

This option allows you to modify the ATM F4/F5 entries or send the diagnostic entry. From the *Maintenance* menu, click on *ATM Loopbacks*. The following page is displayed:

#### ATM Loopback

OAM Cell Generation Disabled:  Enabled:

Port 01~12

Select	Port	LoopBack ID				Test Type	Status
<input checked="" type="checkbox"/>	ADSL Port1-PVC1	00000000	00000000	00000000	00000000	F5 E2E	FAIL
<input type="checkbox"/>	ADSL Port2-PVC1	00000000	00000000	00000000	00000000	--Select--	----
<input type="checkbox"/>	ADSL Port3-PVC1	00000000	00000000	00000000	00000000	--Select--	----
<input type="checkbox"/>	ADSL Port4-PVC1	00000000	00000000	00000000	00000000	--Select--	----
<input type="checkbox"/>	ADSL Port5-PVC1	00000000	00000000	00000000	00000000	--Select--	----
<input type="checkbox"/>	ADSL Port6-PVC1	00000000	00000000	00000000	00000000	--Select--	----

#### ATM Loopbacks Setup

Label	Description
OAM Cell Generation	Click on the radio button to Disable/Enable OAM Cell Generation. Then click on <b>Apply</b> button to submit the setting.
<input type="button" value="Port 01~12"/> <input type="button" value="PVC-1"/>	Click on the drop-down lists to select port range and PVC (1 ~ 8).
Create	Click on this button to create a loopback setting. <i>Note:</i> make sure the interface has been setup and the service state of the circuit is turned on.
Query	Click on this button to query the loopback status.
Delete	Click on this button to delete a loopback entry.
Select	Click on the checkbox to select the PVC you want to create or delete the loopback setting for.
Port	This field shows the line port and PVC number.
LoopBack ID	Type in a loopback ID (32 digit).
Test Type	Select the loopback type: F5 E2E or F5 Segment.
Status	This field shows current loopback testing status. Possible values are: Fail, Success, In Progress, or ----.

## 4.6.5 Fault Management

### 4.6.5.1 Alarm/Event

This option allows you to query current alarm, history alarm, and event log. From the *Maintenance* menu, click on *Fault Management* and then *Alarm/Event*. The *Current Alarm* page is displayed. Click on the *Alarm/Event Select* drop-down list and select *Current Alarm*, *History Alarm*, or *Event Log* to view.

#### Current Alarm:

Type in the range of rows (1 ~ 1024) and then click on the **Query** button.

#### Current Alarm

Row	ID	Description	Level	State	Sequential	Time
1	116	[System]GBE1 FIBER LOS	MN	Set	1	2007/08/09 19:34:21
2	117	[System]GBE2 FIBER LOS	MN	Set	2	2007/08/09 19:34:21
3	620	[Port:1]ADSL_NOPEER_FE	MN	Set	10	2007/08/09 19:35:21
4	106	[System]SYS_ABOVETEMP	MN	Set	4	2007/08/09 19:34:31
5	620	[Port:2]ADSL_NOPEER_FE	MN	Set	11	2007/08/09 19:35:21
6	620	[Port:3]ADSL_NOPEER_FE	MN	Set	12	2007/08/09 19:35:23
7	620	[Port:4]ADSL_NOPEER_FE	MN	Set	13	2007/08/09 19:35:23
8	620	[Port:5]ADSL_NOPEER_FE	MN	Set	14	2007/08/09 19:35:23
9	620	[Port:6]ADSL_NOPEER_FE	MN	Set	15	2007/08/09 19:35:24
10	104	[System]SYS_FAN	MN	Set	2872	2007/08/10 13:16:23

Current Alarm Table

Label	Description
ACO	Click on this button to cut-off alarm.
Query	Click on this button to get most recent data.
Row	This field shows the row number.
ID	This field shows the alarm ID.
Description	This field shows the description for the alarm.
Level	This field shows the alarm level. Valid values are: MJ: major alarm. MN: minor alarm.
State	This field shows the alarm state: Set or Clear.
Sequential	Sequential number.
Time	Alarm occurring date and time.

## History Alarm:

### History Alarm

Alarm/Event Select History Alarm						
Query		Clear History				
Row	ID	Description	Level	State	Sequential	Time
68	104	[System]SYS_FAN	MN	Set	2884	2007/08/10 13:20:48
67	104	[System]SYS_FAN	MN	Clear	2883	2007/08/10 13:20:43
66	104	[System]SYS_FAN	MN	Set	2882	2007/08/10 13:19:53
65	104	[System]SYS_FAN	MN	Clear	2881	2007/08/10 13:19:48
64	104	[System]SYS_FAN	MN	Set	2880	2007/08/10 13:19:18
63	104	[System]SYS_FAN	MN	Clear	2879	2007/08/10 13:19:13
62	104	[System]SYS_FAN	MN	Set	2878	2007/08/10 13:18:58
61	104	[System]SYS_FAN	MN	Clear	2877	2007/08/10 13:18:53
60	104	[System]SYS_FAN	MN	Set	2876	2007/08/10 13:18:28
59	104	[System]SYS_FAN	MN	Clear	2875	2007/08/10 13:18:23
58	104	[System]SYS_FAN	MN	Set	2874	2007/08/10 13:18:13

### History Alarm Table

Label	Description
Query	Click on this button to query history alarms.
Clear History	Click on this button to clear the alarm history table.
Row	This field shows the row number.
ID	This field shows the alarm ID.
Description	This field shows the description for the alarm.
Level	This field shows the alarm level. Valid values are: MJ: major alarm. MN: minor alarm.
State	This field shows the alarm state: Set or Clear.
Sequential	Sequential number.
Time	Alarm occurring date and time.

## Event Log:

Type in the range of rows and then click on the **Query** button.

### Event Log

Row	ID	Description	Sequential	Time
0	787	ATM-OAM-CREATE-LOOPBACK	38	2007/08/10 12:19:48
1	8	TRUNK-CARD-PROVISION-DATA-SET-DEFAULT	37	2007/08/10 12:15:37
2	28	[Giga:1]TRUNK_CARD_CLUSTER_CHANGED	36	2007/08/10 10:22:40
3	28	[Giga:1]TRUNK_CARD_CLUSTER_CHANGED	35	2007/08/09 19:35:14
4	770	[Port-PVC:12-1]ATM-CREATE-VCL	34	2007/08/09 19:34:52
5	1540	[Port:12]ADSL-USER-PORT-ENABLESET	33	2007/08/09 19:34:52
6	770	[Port-PVC:11-1]ATM-CREATE-VCL	32	2007/08/09 19:34:52
7	1540	[Port:11]ADSL-USER-PORT-ENABLESET	31	2007/08/09 19:34:52
8	770	[Port-PVC:10-1]ATM-CREATE-VCL	30	2007/08/09 19:34:52
9	1540	[Port:10]ADSL-USER-PORT-ENABLESET	29	2007/08/09 19:34:52

### Event Log

Label	Description
Query	Click on this button to query most recent event log.
Clear Event	Click on this button to clear the event log.
Row	This field shows the row number.
ID	This field shows the event ID.
Description	This field shows the description for the event.
Sequential	Sequential number.
Time	Event occurring date and time.



#### 4.6.5.2 Alarm Profile

This option allows you to view and update the alarm profiles. From the *Maintenance* menu, click on *Fault Management* and then *Alarm profile*. The *Alarm Profile* page is displayed. Click on the *Select Page* drop-down list and select a page to display.

To modify an alarm profile, click on the radio button beside the alarm ID, select the Level (Major/Minor), Mask/Unmask, and then click on the **Modify** button. You can also select the *ALL ID* checkbox to modify all alarm types at a time.

#### Alarm Profile

ID	Type	Level	Mask	ID	Type	Level	Mask
<input checked="" type="radio"/> 101	SYS_HOUSEKEEP1	MN	UnMask	<input type="radio"/> 102	SYS_HOUSEKEEP2	MN	UnMask
<input type="radio"/> 103	SYS_HOUSEKEEP3	MN	UnMask	<input type="radio"/> 104	SYS_FAN	MN	UnMask
<input type="radio"/> 105	SYS_SELFTESTFAILED	MN	UnMask	<input type="radio"/> 106	SYS_ABOVETEMP	MN	UnMask
<input type="radio"/> 107	SYS_BELOWTEMP	MN	UnMask	<input type="radio"/> 110	SYS_HOUSEKEEP4	MN	UnMask
<input type="radio"/> 115	SYS_FANCARDUNEQ	MN	UnMask	<input type="radio"/> 116	GBE1 SFP LOS	MN	UnMask
<input type="radio"/> 117	GBE2 SFP LOS	MN	UnMask	<input type="radio"/> 118	SYS_DSP	MN	UnMask
<input type="radio"/> 601	ADSL_LOS	MN	UnMask	<input type="radio"/> 602	ADSL_LOF	MN	UnMask
<input type="radio"/> 603	ADSL_LOM	MN	UnMask	<input type="radio"/> 610	ADSL_LCD	MN	UnMask
<input type="radio"/> 612	ADSL_NCD	MN	UnMask	<input type="radio"/> 613	ADSL_LOS_FE	MN	UnMask
<input type="radio"/> 614	ADSL_LOF_FE	MN	UnMask	<input type="radio"/> 615	ADSL_LOM_FE	MN	UnMask
<input type="radio"/> 616	ADSL_LOPWR_FE	MN	UnMask	<input type="radio"/> 619	ADSL_COMMF_FE	MN	UnMask
<input type="radio"/> 620	ADSL_NOPEER_FE	MN	UnMask	<input type="radio"/> 622	ADSL_LCD_FE	MN	UnMask
<input type="radio"/> 624	ADSL_NCD_FE	MN	UnMask				

### 4.6.5.3 Hardware Temperature

This page allows you to:

- view current system temperature
- set several temperature and time thresholds (see description in the following table)

From the *Maintenance* menu, click on *Fault Management* and then *Hardware Temp*. The following page is displayed:

#### Temperature Threshold

Modify						
Current Temperature (°C)	Up Shift Threshold (°C)	Up Shift Time (Sec)	Down Shift Threshold (°C)	Down Shift Time (Sec)	Fan ON Threshold (°C)	Fan Shift Time (Sec)
70	65	10	-40	10	-40	64590
If current temperature <b>exceeds/descends</b> Up/Down Shift Threshold, Alarm Manager will declare that there is a <b>high/lower</b> temperature alarm after Up/Down ShiftTime seconds.						
[ <a href="#">ALARM/EVENT</a> ]						

#### Temperature Configuration

Label	Description
Modify	Click on this button to submit the update once you have entered all the new threshold values.
Current Temperature (°C)	This field shows the current system temperature.
Up Shift Threshold (°C)	The system will produce notification (alarm) when the monitored system temperature is higher than Up Shift Threshold (-55~85 °C) for over Up Shift Time (1~255 sec).
Up Shift Time (Sec)	Refer to the description for Up Shift Threshold.
Down Shift Threshold (°C)	The system will produce notification (alarm) when the monitored system temperature is lower than Down Shift Threshold (-55~85 °C) for over Down Shift Time (1~255 sec).
Down Shift Time (Sec)	Refer to the description for Down Shift Threshold.
Fan ON Threshold (°C)	FAN Enable temperature threshold (-40~15 °C). When the system temperature is higher than the threshold, the fan will be turned on automatically.
Fan Shift Time (Sec)	This field shows the elapsed time since the FAN was turned on.

## 4.6.6 Performance Monitoring

### 4.6.6.1 System Utilization

This option allows you to monitor the memory utilization and network processor utilization. From the *Maintenance* menu, click on *Performance Monitoring* and then *System Utilization*. The following page is displayed.

#### System Utilization

Current Memory Utilization	
(0)Parameter Bus(ZBT)	21.0%
(1)Packet Bus(SDRAM)	0.0%
(2)Host Bus(SDRAM)	0.0%
Current CPU Utilization	
(3)WinGine1	41.6%
(4)WinGine2	8.3%
(5)Average Loading	25.0%
(6)Idle	75.0%

#### 4.6.6.2 Ethernet Statistics

This option allows you to view the Gigabit Ethernet counter values for the trunk or line interface. From the *Maintenance* menu, click on *Performance Monitoring* and then *Ethernet Statistics*. Click on the leftmost drop-down list to select interface (giga port or DSL line port); if line interface is selected, you must further click on the middle and rightmost drop-down list to select the line port number and PVC number. At last, click on **Query** to get data of that interface.

**GBE interface:**

#### Ethernet Statistics

GIGA Port ▾ XDSL Port-1 ▾ PVC-1 ▾ Query			
Statistics Name	Giga Port 1	Giga Port 2	
MTU Size	1536	1536	
Queue LEN	0	0	
Last Change	0	0	
Specification	L	L	
Description	Giga Ethernet	Giga Ethernet	
Input Bytes	0	11839066	
Input Broadcast Packets	0	0	
Input Discard Packets	0	5729	
Input Multicast Packets	0	295	
Input Unicast Packets	0	0	
Input Not Unicast Packets	0	295	
Input Error Packets	0	0	
Input Unknown Protocol Packets	0	0	
Output Bytes	1870016	1814916	
Output Broadcast Packets	2882	2882	
Output Discard Packets	2	2	
Output Multicast Packets	0	0	
Output Unicast Packets	0	0	
Output Not Unicast Packets	2882	2882	
Output Error Packets	0	0	

ADSL line PVC:

Ethernet Statistics

Statistics Name	XDSL Port
MTU Size	1536
Queue Length	0
Last Change	0
Specification	L
Description	ATM
Input Bytes	0
Input Broadcast Packets	0
Input Discard Packets	0
Input Multicast Packets	0
Input Unicast Packets	0
Input Not Unicast Packets	0
Input Error Packets	0
Input Unknown Protocol Packets	0
Output Bytes	1749
Output Broadcast Packets	66
Output Discard Packets	27102
Output Multicast Packets	0
Output Unicast Packets	0
Output Not Unicast Packets	66
Output Error Packets	0

### 4.6.6.3 ATM Statistics

This option allows you to query the ATM Statistics. From the *Maintenance* menu, click on *Performance Monitoring* and then *ATM Statistics*. The following page is displayed.

#### ATM Statistics

ADSL Port	1	Show	Tx Cells	Query
Auto Update <input type="checkbox"/>				
<b>ATM Cell Name</b>	<b>Port:1</b>			
(12)Tx_cells	0000000000000001			
(13)Tx_clp1_cells	0000000000000000			
(14)Tx_efci_cells	0000000000000000			
(15)Tx_oam_cells	0000000000000001			
(16)Tx_rm_cells	0000000000000000			
(17)Tx_clp0_cells	0000000000000001			

#### Query ATM Statistics

Label	Description
ADSL Port	Click on this button to select line port (1 ~ 48).
Auto Update	Click on this checkbox to auto update the displayed statistics.
Show	Click on this drop-down list to select Tx, Rx, or All (Tx & Rx) data.
Query	Click on this button to query current statistics.

#### 4.6.6.4 RMON

This option allows you to configure and query the RMON Statistics. The IDL-4802 supports performance statistics defined in RMON MIB groups 1 (Ethernet statistics), 2 (history control), 3 (alarm), and 9 (event) per RFC 2819 for all network uplink ports. From the *Maintenance* menu, click on *Performance Monitoring* and then *RMON*. The following page is displayed. Select type of RMON table in the drop-down list.

#### Remote Monitoring

Select Type	[Select] ▼
<b>RMON Table</b>	
(1)ETH Statistics	
(2)History Control	
(3)ETH History	
(4)Alarm	
(5)Event	
(6)LOG	

✧ **ETH Statistics**

This option is for displaying the Ethernet interface RMON data. Click on the *Data Source* drop-down list and select GBE1 or GBE2. Type in an owner name and then click on **New** button to create a new ETH statistics entry. An owner is the entity that configured this entry and is therefore using the resources assigned to it.

Remote Monitoring - ETH Statistics

Select Type: ETH Statistics		
Next No: 3	Data Source: GBE1	
Owner: RMON3	NEW	
Query	Modify	Delete
Index (Delete/Modify)	1 <input type="checkbox"/>	2 <input type="checkbox"/>
Data Source	GBE1	GBE2
Owner	RMON1	RMON2
Rx DropEvents	00000000	00000000
Rx Bytes	00000000	00000000
Rx Packets	00000000	00000000
Rx BroadcastPkts	00000000	00000000
Rx MulticastPkts	00000000	00000000
Rx CRC Align Errors	00000000	00000000
Rx Undersize Pkts	00000000	00000000
Rx Oversize Pkts	00000000	00000000
Rx Fragments	00000000	00000000
Rx Jabbers	00000000	00000000
Tx Collisions	00000000	00000000
Tx/Rx Pkts 64bytes	00000000	00000000
Tx/Rx Pkts 65-127bytes	00000000	00000000
Tx/Rx Pkts 128-255bytes	00000000	00000000
Tx/Rx Pkts 256-511bytes	00000000	00000000
Tx/Rx Pkts 512-1023bytes	00000000	00000000
Tx/Rx Pkts 1024-1518bytes	00000000	00000000
Tx Bytes	00000000	00000000
Tx Packets	00000000	00000000
Tx Multicast Pkts	00000000	00000000
Tx Broadcast Pkts	00000000	00000000

To modify an entry in this table, click on the index to select the entry, type in new value, and then click on **Modify**. To delete an entry, click on the index to select the entry and then click on **Delete**.



The following parameters are monitored in this table:

RMON ETH Statistics variables

<b>Variable</b>	<b>Description</b>
Rx DropEvents	Monitoring Rx dropped events
Rx Bytes	Monitoring Rx bytes packets
Rx Packets	Monitoring Rx packets
Rx BroadcastPkts	Monitoring Rx broadcast packets
Rx MulticastPkts	Monitoring Rx multicast packets
Rx CRC Align Errors	Monitoring Rx error alignment packets
Rx Undersize Pkts	Monitoring Rx undersize packets
Rx Oversize Pkts	Monitoring Rx oversize packets
Rx Fragments	Monitoring Rx fragments packets
Rx Jabbers	Monitoring Rx jabber packets
Tx Collisions	Monitoring Tx single collision packets
Tx/Rx Pkts 64 bytes	Monitoring Tx/Rx 64 bytes packets
Tx/Rx Pkts 65~127 bytes	Monitoring Tx/Rx 65 to 127 bytes packets
Tx/Rx Pkts 128~255 bytes	Monitoring Tx/Rx 128 to 255 bytes packets
Tx/Rx Pkts 256~511 bytes	Monitoring Tx/Rx 256 to 511 bytes packets
Tx/Rx Pkts 512~1023 bytes	Monitoring Tx/Rx 512 to 1023 bytes packets
Tx/Rx Pkts 1024~1518 bytes	Monitoring Tx/Rx 1024 to 1518 bytes packets
Tx Bytes	Monitoring Tx bytes packets
Tx Packets	Monitoring Tx packets
Tx MulticastPkts	Monitoring Tx multicast packets
Tx BroadcastPkts	Monitoring Tx broadcast packets

## ✧ History Control

This table is for controlling the ETH History table. History Control 1 is for controlling ETH History table 1; History Control 2 is for controlling ETH History table 2; etc. Type in the Requested value and Interval (sec) and then click on **New** to create a History Control entry. Up to 10 History Control entries can be created. To modify an entry, click on the index to select the entry, type in new value, and then click on **Modify**. To delete an entry, click on the index to select the entry and then click on **Delete**.

### Remote Monitoring - History Control

Select Type: History Control	
Next No: 3	Data Source: GBE1
Owner: RMON3	Requested: 50 Interval: 1800 <b>NEW</b>
<b>Modify</b>	<b>Delete</b> <b>Query</b>
<b>Index (Delete/Modify)</b>	1 <input type="checkbox"/> 2 <input type="checkbox"/>
<b>Data Source</b>	GBE1 GBE1
<b>Owner</b>	RMON1 RMON2
<b>Requested</b>	3 96
<b>Granted</b>	3 96
<b>Interval</b>	1 1

RMON History Control Table

Label	Description
Data Source	Data source identifies the source of the data for which historical data was collected and placed in a table on behalf of this HistoryControl entry. Here the source is GBE1 interface or GBE2 interface.
Owner	An owner is the entity that configured this entry and is therefore using the resources assigned to it.
Requested	Requested value is the requested number of intervals over which data is to be saved in the part of the media-specific table associated with this HistoryControl entry.
Granted	The number of sampling intervals over which data shall be saved in the part of the media-specific table associated with this HistoryControl entry.
Interval	The interval in seconds over which the data is sampled for each bucket in the part of the media-specific table associated with this HistoryControl entry. The value range is 1 to 3600 (sec).

✧ **ETH History**

This option is for displaying Ethernet interface RMON history data. Before a history table is available, you have to create a History Control entry in advance. To query the History table, click on the *History Index* drop-down list and select a history table and then click on **Query**.

Remote Monitoring - ETH History

Select Type: ETH History	
History Index: History1 <input type="button" value="Query"/>	
HistIndex	1
SampleIndex	8354
IntervalStart	13818days 06:27:31
Rx DropEvents	00000000
Rx Bytes	00000318
Rx Packtes	0000000c
Rx Broadcast Pkts	0000000c
Rx Multicast Pkts	00000000
Rx CRC Align Errors	00000000
Rx Undersize Pkts	00000000
Rx Oversize Pkts	00000000
Rx Fragments	00000000
Rx Jabbers	00000000
Tx Collisions	00000000
Tx Bytes	000008c0
Tx Packets	00000023
Tx Multicast Pkts	00000023
Tx Broadcast Pkts	00000000
Utilization	0000001f

RMON ETH History Table

Label	Description
HistIndex	This field shows the History Table index. The history identified by this index is the same history as identified by the same value of History Control index.
SampleIndex	The Sample index uniquely identifies the particular Sample among all samples associated with the same History Control entry.
IntervalStart	The value of System Up Time* at the start of the interval over which this sample was measured.

\*System Up Time is the time since the network management portion of the system was last re-initialized.

### RMON ETH History variables

Variable	Description
Rx DropEvents	Monitoring Rx dropped events
Rx Bytes	Monitoring Rx bytes packets
Rx Packets	Monitoring Rx packets
Rx Broadcast Pkts	Monitoring Rx broadcast packets
Rx Multicast Pkts	Monitoring Rx multicast packets
Rx CRC Align Errors	Monitoring Rx error alignment packets
Rx Undersize Pkts	Monitoring Rx undersize packets
Rx Oversize Pkts	Monitoring Rx oversize packets
Rx Fragments	Monitoring Rx fragments packets
Rx Jabbers	Monitoring Rx jabber packets
Tx Collisions	Monitoring Tx single collision packets
Tx Bytes	Monitoring Tx bytes
Tx Packets	Monitoring Tx packets
Tx Multicast Pkts	Monitoring Tx multicast
Tx Broadcast Pkts	Monitoring Tx broadcast
Utilization	Monitoring Tx Utilization

✧ **Alarm**

This option allows you to configure the RMON alarm setting. This table controls the conditions on which alarms occur. Click on **New** to create an entry. To modify an entry, click on the index to select the entry, type in new value, and then click on **Modify**. To delete an entry, click on the index to select the entry and then click on **Delete**.

Remote Monitoring - Alarm


Index (Delete/Modify)	1	2
Interval	1800	1800
Owner	RMON1	RMON2
OID Variable	DropEvents 1	DropEvents 1
SampleType	Sampling ABSOLUTE	Sampling ABSOLUTE
StartupAlarm	Startup By RISING	Startup By RISING
Value	0	0
RisingThreshold	0	0
FallingThreshold	0	0
RisingEventIndex	0	0
FallingEventIndex	0	0

RMON Alarm setup


Label	Description
Interval	The interval in seconds over which the data is sampled and compared with the rising and falling thresholds. Value range: 0~2147483647 (0: disable).
Owner	RMON alarm owner (max 31 characters).
OID Variable	Click on the drop-down list to select ETH statistics variable and index of ETH Statistics table entries.
SampleType	RMON alarm sample type includes: ABSOLUTE: the value of the selected variable will be compared directly with the thresholds at the end of the sampling interval. DELTA: the value of the selected variable at the last sample will be subtracted from the current value, and the difference compared with the thresholds.

StartupAlarm	<p>Set the alarm type that may be sent. Options are Rising, Falling, and Both.</p> <p>Rising or Both: If the first sample after this entry becomes valid is greater than or equal to the Rising Threshold, then a single rising alarm will be generated.</p> <p>Falling or Both: If the first sample after this entry becomes valid is less than or equal to the Falling Threshold, then a single falling alarm will be generated.</p>
Value	This field shows the value of the monitored data.
Rising Threshold	RMON alarm rising threshold (0~4294967295).
Falling Threshold	RMON alarm falling threshold (0~4294967295).
Rising Event Index	This index is used when a rising threshold is crossed. You must refer to the index of RMON Event table. If there is no corresponding entry in the Event table, then no association exists.
Falling Event Index	This index is used when a falling threshold is crossed. You must refer to the index of RMON Event table. If there is no corresponding entry in the Event table, then no association exists.

Following figure shows an example of RMON alarm for ABSOLUTE sample type. As shown in the figure, the counting value keeps increasing. But when the value overflows, the system will count from zero again. The sample in T2 is the first one crossing the Rising Threshold, so an alarm occurs. No alarms will be generated afterwards unless the counting value overflows and count from zero again (the sample in T10 causes an alarm again).



Another figure shows the example of RMON alarm for DELTA sample type. As shown in the following figure, the delta value varies high and low. The sample in T1 is the first one crossing the Rising Threshold, so an alarm occurs. No alarms will be generated afterwards until T5 sample which is crossing the Falling Threshold (note that the value of the previous sample, T4 sample, is greater than the Falling Threshold and the value of T5 sample). Alarm is not generated for T7 sample since an alarm is already generated for T5 sample and the curve is not in a downward trend around T7. A Rising Threshold crossing alarm is generated again for T10 sample, because a Falling Threshold crossing alarm (T5) has occurred after the previous Rising Threshold crossing alarm (T1).



✧ **Event**

This option allows you to configure the RMON event setting. Click on **New** to create an entry.

To modify an entry, click on the index to select the entry, type in new value, and then click on **Modify**. To delete an entry, click on the index to select the entry and then click on **Delete**.

Remote Monitoring - Event

Select Type: <input type="text" value="Event"/>			
Next No: <input type="text" value="4"/>		Description: <input type="text" value="Description4"/>	
Community: <input type="text" value="Community4"/>		Owner: <input type="text" value="RMON4"/>	
Event Type: <input type="text" value="NONE"/>		<input type="button" value="NEW"/>	
<input type="button" value="Modify"/>		<input type="button" value="Delete"/>	
<input type="button" value="Query"/>			
<b>Index (Delete/Modify)</b>	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>
<b>Description</b>	<input type="text" value="Description1"/>	<input type="text" value="Description2"/>	<input type="text" value="Description3"/>
<b>event Type</b>	<input type="text" value="LOG"/>	<input type="text" value="SNMPTRAP"/>	<input type="text" value="LOGANDTRAP"/>
<b>Community</b>	<input type="text" value="Community1"/>	<input type="text" value="Community2"/>	<input type="text" value="Community3"/>
<b>LastTimeSent</b>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
<b>Owner</b>	<input type="text" value="RMON1"/>	<input type="text" value="RMON1"/>	<input type="text" value="RMON2"/>

RMON Event setup

Label	Description
Description	Type in comment describing the event.
Community	If an SNMP trap is to be sent, it will be sent to the SNMP community specified in this column.
Owner	Type in the RMON event owner.
Event Type	Click on the drop-down list and select event type. Options are NONE, LOG (an entry is made in the log table for each event), SNMPTRAP (an SNMP trap is sent to one or more management stations), LOGANDTRAP (log and send trap).
LastTimeSent	The value of System Up Time at the time this event entry last generated an event.



✧ **LOG**

This option allows you to query the RMON LOG. Click on **Query** button to display the log. Only the event indices with LOG or LOGANDTRAP event type are possible to appear in the log.

Remote Monitoring - LOG

Select Type	LOG		
<input type="button" value="Query"/>			
Index	EventIndex	Time	Description

#### 4.6.6.5 ADSL Day/Interval

This option allows you to query the ADSL PM 15-Min and Day Statistics. The IDL-4802 provides Today and Previous 1 day for Day PM, and also provides Current and Previous 1 ~ 96 interval for 15-Min PM. From the *Maintenance* menu, click on *Performance Monitoring* and then *ADSL Day/Interval*. The following page is displayed. You can select to display one interval or all intervals data of a single port; you can also select to display one interval data for twelve ports (1~12, 13~24, 25~36, or 37~48) at the same time.

#### ADSL Performance Statistics

More Port:  Port:  ALL Interval:

Day   15-Min

Clearing current interval PM:

PM Counter	Near End	Far End
LOS	0	0
LOF	0	0
LOM	0	0
LPR	N/A	0
LOL	0	N/A
ES	0	0
SES	0	0
UAS	766	766
Re-Initialize(s)	0	N/A
Initialize fail(s)	0	N/A
User Cell(CU)	0	N/A
Delineate Cell(CD)	0	N/A
HEC	0	0
IBE	0	0
Channel-CV's	0	0
Channel-FECCs	0	0

[\[ TCA PROFILE \]](#)

15-Min Previous PM number between 1 and 96

## ADSL PM Statistics

Label	Description
More Port	Click on the drop-down list and select the port range. Options are: 01~12, 13~24, ..., 37~48. This drop-down list is available only when <b>All</b> is selected in the <i>Port</i> drop-down list.
Port	Click on the drop-down list and select a line port number (1 ~ 48). You can also select <b>All</b> and then click on <i>More Port</i> to select a port range to view the data of twelve ports at the same time.
All Interval	When you select to view a single port PM data, you can click on this checkbox to display the data of all intervals.
Query	Click on this button to get most recent data.
Clear PM	Click on this button to clear current PM data of the port you select.
LOS	Loss of Signal
LOF	Loss of Frame
LOM	Loss of Margin
LPR	Loss of Power (only for Far End)
LOL	Loss of Link (only for Near End)
ES	Errored Seconds
SES	Severely Errored Seconds
UAS	Unavailable Seconds
Re-Initialize	Modem Re-initialization events (only for Near End)
Initialize fail(s)	Modem Failed Initialization events (only for Near End)
User Cell (CU)	User Total Cell Count (only for Near End)
Delineate Cell (CD)	Delineated Total Cell Count (only for Near End)
HEC	ATM Header Error Count
IBE	Idle Cell Bit Error Count
Channel-CVs	Channel PM - Code Violations
Channel-FECCs	Channel PM- Forward Error Corrections

# CLI Command Reference

## Introduction

Access to the Operations System (OS) /Network Element (NE) system is protected by a logon security system. You can log on to the NE with the user name and password. After three failed logon attempts, the system refuses further attempts.

After you log on, the system monitors the interface for periods of inactivity. If the interface is inactive for too long, you are automatically logged off.

All the NEs have the same initial user name (admin) and password (admin). You should change the password as soon as possible, because the initial password is known to anyone who reads this manual. You can also change the user name or add additional user names. Use the "account add" command to enter a new user identification, password and authorization level. The system can handle one local logon session and at least four remote/OS sessions.

## Connect Interface

Interface	Parameter
Console	Baud rate: 9600, Data bit:8, Parity: None, Stop bit :1
Telnet	Port 23
SSH	Port 22 (In Windows, you can run terminal emulator such as PuTTY)

## Authorization Level

Level	Description
Super user	Superuser can run all commands.
Engineer	Engineer can run all commands except the commands for creating/modifying/ deleting account and displaying running configuration.
Guest (default)	Guest can run most commands except the commands that have creating/ modifying/deleting purpose.

# Screen Description

```
LOCAL login: admin
Password:

this is motd file to inform any information to user

System Description:IDL-4802 48-port ADSL2+ POTS
Hardware Version:B
Firmware Version:0.32
Software Version:0.32
Compiled Tue Nov 7 11:03:45 CST 2006
local:>
===== CLI Help =====
bye          Quit CLI
disable     Disable mode
exit        Exit current mode
help        Help command
list        List command
system      System Shell or System commands
cluster     Cluster management switch
-----
enable      Enable execute mode
show        Show commands
local:>|
```

System Information

System HW, FW, SW version

Global Command and Description

General Command and Description

Prompt Symbol

## Screen Description

## Execution Modes

The CLI contains several execution modes. Users will see different set of commands under different execution modes. Following table lists all the execution modes and their purposes. When users enter a certain execution mode, the corresponding mode prompt will be displayed automatically on the screen. The mode prompts of all the execution modes are also listed in list of Execution modes.

List of Execution Modes

Execute mode	Description	Prompt symbol
Initialize	Without login prompt or already authenticated	>
Enable	Management capable	%
Configure	Configuration capable	(conf)#
Interface	Interface configure capable	(intf-conf)#
Ethernet Interface	Ethernet Interface configure capable	(ethernet-intf-conf)#
ATM Bridge	ATM Bridge configuration capable	(bridge-atm-conf)#
ATM Description	ATM Description configuration capable	(atm-desc-conf)#
ADSL config	ADSL line configuration capable	(adsl-intf-conf)#
IPOA config	IPOA routed mode configuration capable	(ipoa-intf-conf)#
Bridge	Bridge configuration capable	(bridge-eth-conf)#
Access List	ACL configuration capable	(acl-conf)#
Service Profile	User/Line service profile configuration capable	(service-profile)#
Spectrum Profile	User/Line spectrum profile configuration capable	(spectrum-profile)#
Alarm Profile	User/Line alarm profile configuration capable	(alarm-profile)#
Tca Profile	User/Line tca profile configuration capable	(tca-profile)#
IGMP ACL Profile	IGMP ACL profile configuration capable	(igmpacl-profile)#
Rate Limit Profile	Rate-Limit Policer profile configuration capable	(rate-limit-profile)#
Priority List	Priority List configuration capable	(prio-conf)#

## Getting help

The user can get help in two ways.

The first is by using the **help** command. The user can also enter a question mark '?' at each position in the command. The displayed result depends on the execution mode and previous input.

## Terminal Key Function

Following is the list of all the terminal keys and their function.

#### List of Terminal Keys

TAB	Attempt to perform completion on the text before point
TAB TAB	Display the next keyword of this command
?	Display help of command
ENTER	Execute input
DEL or BACKSPACE	Delete the character to the left of the cursor
UP Arrow	History of last input line
DOWN Arrow	History of previous input Line
CTRL-d	Delete the character at point. If point is at the beginning of the line, there are no characters in the line, and the last character typed was not bound to delete-char, then return EOF.
CTRL-a	Move to the start of the line
CTRL-e	Move to the end of the line
CTRL-f	Move Forward one character
CTRL-b	Move Back one character
CTRL-c	Force to interrupt
CTRL-k	Kill the text from the current cursor to the end
CTRL-p	Move 'back' through the history list, fetching the previous command.
CTRL-n	Move 'forward' through the history list, fetching the next command.
CTRL-r	Search backward starting at the current line and moving 'up' through the history as necessary. This is an incremental search.
CTRL-t	Drag the character before the cursor forward over the character at the cursor, moving the cursor forward as well. If the insertion point is at the end of the line, this transposes the last two characters of the line. Negative arguments have no effect.
CTRL-u	Kill backward from the cursor to the beginning of the current line.
CTRL-w	Kill the word behind point, using white space as a word boundary. The killed text is saved on the kill-ring.
CTRL-y	Yank the top of the kill ring into the buffer at point.
CTRL-s	Terminal will not response to what the operator key in
CTRL-q	Back to normal mode from terminal not responding mode
CTRL-z	Exit current execution mode

## Notation Conventions

The notation conventions for the parameter syntax of each CLI command are as follows:

- Parameters enclosed in [ ] are optional.
- Parameter values are separated by a vertical bar “|” only when one of the specified values can be used.
- Parameter values are enclosed in { } when you must use one of the values specified.

## About String-type Parameters

Some commands have string type parameters. When you type in the values of these parameters, you must be careful not to use the keyword that is actually a part of some command. For example, ‘account add default’ will cause a syntax mistake, since **default** is the keyword of the command ‘igmp default’ and some other commands. Therefore, it is recommended to add “ ” when you have to use the command keyword as the parameter value. In this way, the keyword will be regarded as a common string. For example, account add “default”.



## 5.1 Global Commands

The Global commands can be used in all execution modes.

### 5.1.1 bye

**Description** Exit  
**Syntax** bye  
**Parameter** None

### 5.1.2 cluster

**Description** Switch to a NE (network element) in the cluster

**Syntax** cluster <string>  
**Parameter**

Name	Description
<string>	NE name in the cluster you want to switch to. <b>Valid values:</b> string type value. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.1.3 cluster local

**Description** Switch to Master in the cluster  
**Syntax** cluster local  
**Parameter** None

### 5.1.4 disable

**Description** Go to Disable execution mode from logoff mode  
**Syntax** disable  
**Parameter** None

### 5.1.5 end

**Description** Return to Enable mode  
**Syntax** end  
**Parameter** None

### 5.1.6 exit

**Description** Go to previous execution mode  
**Syntax** exit  
**Parameter** None

### 5.1.7 help

**Description** Display help

**Syntax** help

**Parameter** None

### 5.1.8 list

**Description** Display all commands of current mode

**Syntax** list

**Parameter** None

### 5.1.9 list opmode

**Description** List all the ADSL modes of operation.

**Syntax** list opmode

**Parameter** None

### 5.1.10 system contact

**Description** Set system contact

**Syntax** system contact <contact>

**Parameter**

Name	Description
<contact>	System contact <b>Valid values:</b> string type value. Max 63 characters. <b>Default value:</b> - <b>Type:</b> Optional

### 5.1.11 system location

**Description** Set system location

**Syntax** system location <location>

**Parameter**

Name	Description
<location>	System location <b>Valid values:</b> string type value. Max 63 characters. <b>Default value:</b> - <b>Type:</b> Optional

### 5.1.12 system name

**Description** Set system name  
**Syntax** system name <name>  
**Parameter**

Name	Description
<name>	System name <b>Valid values:</b> string type value. Max 32 characters. <b>Default value:</b> - <b>Type:</b> Optional

### 5.1.13 system restart

**Description** Restart the system  
**Syntax** system restart  
**Parameter** None

## 5.2 Initialize Mode Commands

### 5.2.1 enable

<b>Description</b>	Go to Enable execution mode from disable mode
<b>Syntax</b>	enable
<b>Parameter</b>	None

### 5.2.2 show license

<b>Description</b>	Display GNU software license
<b>Syntax</b>	show license
<b>Parameter</b>	None

### 5.2.3 show time

<b>Description</b>	Display current time
<b>Syntax</b>	show time
<b>Parameter</b>	None

### 5.2.4 show uptime

<b>Description</b>	Display System up time and CPU loading
<b>Syntax</b>	show uptime
<b>Parameter</b>	None

### 5.2.5 show version

<b>Description</b>	Display CLI software version
<b>Syntax</b>	show version
<b>Parameter</b>	None

### 5.3 Enable Mode Commands

The commands in this section can be executed only in the Enable execution mode.

#### 5.3.1 configure

**Description** Go to Configure execution mode from Enable mode.

**Syntax** configure

**Parameter** None

#### 5.3.2 ping

**Description** ICMP echo and reply from hostname address or IP address. If no reply for a long time, you can press Ctrl + c to interrupt ping.

**Syntax** ping {ipv4 address}  
ping {ipv4 address} count <count>  
ping {ipv4 address} size <size>  
ping {ipv4 address} count <count> size <size>

**Parameter**

Name	Description
ipv4 address	IPv4 address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> -
count	The number of PING packets sent. <b>Default value:</b> -
size	Packet size. <b>Default value:</b> -

#### 5.3.3 show access-list bcrate

**Description** Display all broadcast rate limiting list

**Syntax** show access-list bcrate

**Parameter** None

#### 5.3.4 show access-list dstip

**Description** Display all dest IP deny access list or by index

**Syntax** show access-list dstip [<index>]

**Parameter**

Name	Description
<index>	Destination IP deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.5 show access-list dstmac

**Description** Display all destination MAC address deny access list or by index

**Syntax** show access-list dstmac [<index>]

**Parameter**

Name	Description
<index>	Destination MAC deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.6 show access-list ethertype

**Description** Display all EtherType deny access list or by index

**Syntax** show access-list ethertype [<index>]

**Parameter**

Name	Description
<index>	EtherType deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.7 show access-list ip-allowed

**Description** Display all static IP allowed access list or by index

**Syntax** show access-list ip-allowed [<index>]

**Parameter**

Name	Description
<index>	Static IP allowed access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.8 show access-list ipprotocol

**Description** Display all IP protocol deny access list or by index

**Syntax** show access-list ipprotocol [<index>]

**Parameter**

Name	Description
<index>	IP Protocol deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.9 show access-list l4dstport

**Description** Display all L4 dest port deny access list or by index

**Syntax** show access-list l4dstport [<index>]

**Parameter**

Name	Description
<index>	L4 destination port deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.10 show access-list mcfldrate

**Description** Display all flooding rate limiting list or by VLAN ID

**Syntax** show access-list mcfldrate [vlan <VLAN ID>]

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.11 show access-list srcip

**Description** Display all source IP deny access list or by index

**Syntax** show access-list srcip [<index>]

**Parameter**

Name	Description
<index>	Source IP deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.12 show access-list srcmac

**Description** Display all source mac address deny access list or by index

**Syntax** show access-list srcmac [<index>]

**Parameter**

Name	Description
<index>	Source MAC deny access list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.13 show account

**Description** Display system account list / detail information  
**Syntax** show account [detail]  
**Parameter** None

### 5.3.14 show aging

**Description** Display bridge aging time  
**Syntax** show aging  
**Parameter** None

### 5.3.15 show alarm current

**Description** Display current alarm list  
**Syntax** show alarm current  
**Parameter** None

### 5.3.16 show alarm event

**Description** Display event list  
**Syntax** show alarm event  
**Parameter** None

### 5.3.17 show alarm history

**Description** Display alarm history list  
**Syntax** show alarm history  
**Parameter** None

### 5.3.18 show alarm aco

**Description** Display ACO status  
**Syntax** show alarm aco  
**Parameter** None

### 5.3.19 show atmdesc

**Description** Display ATM descriptor  
**Syntax** show atmdesc  
**Parameter** None



### 5.3.20 show atm-loopback

**Description** Display ATM loopback status (by port)

**Syntax** show atm-loopback [<port>]

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.21 show cli-config

**Description** Display current setting for CLI configuration (timeout value, session value)

**Syntax** show cli-config

**Parameter** None

### 5.3.22 show cluster

**Description** Display cluster configuration / Display cluster member list / Display cluster status

**Syntax** show cluster {config | member | status}

**Parameter** None

### 5.3.23 show cpu

**Description** Display CPU information

**Syntax** show cpu

**Parameter** None

### 5.3.24 show dsl-line-identify

**Description** Display DSL line identify information

**Syntax** show dsl-line-identify

**Parameter** None

### 5.3.25 show fdb

**Description** Display all MAC learning table or by VLAN ID

**Syntax** show fdb [vlan <VLAN ID>]

**Parameter**

Name	Description
<VLAN ID>	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.26 show fdbstatic

**Description** Display all static MAC forwarding table or by index

**Syntax** show fdbstatic [<index>]

**Parameter**

Name	Description
<index>	Static MAC forwarding table number. <b>Valid values:</b> 1 ~ 512 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.27 show firmware

**Description** Display firmware update status or partition information. **Note:** the 'Active' status of the firmware partition information means the active partition for next time restart, not current running partition.

Ex.

```
local:%show firmware partition
```

```
Current Version:0.73B05
```

```
Partition  Version      Date          Status
-----
1          0.73B05      2007/07/10   --
2          0.73B05      2007/07/10   Active
```

**Syntax** show firmware {status | partition}

**Parameter** None

### 5.3.28 show help

**Description** Display Help

**Syntax** show help

**Parameter** None

### 5.3.29 show http

**Description** Display HTTP Web port

**Syntax** show http

**Parameter** None

### 5.3.30 show igmp

**Description** Display IGMP information

**Syntax** show igmp

**Parameter** None

### 5.3.31 show igmp group

**Description** Display IGMP VLAN group list

**Syntax** show igmp group list

show igmp group ip <ipv4 address> vlan <VLAN ID>

show igmp group ip <ipv4 address> vlan <VLAN ID> src list

show igmp group ip <ipv4 address> vlan <VLAN ID> src <ipv4 address>

#### Parameter

Name	Description
ipv4 address	IGMP group address <b>Valid values:</b> 224.0.0.0 ~ 239.255.255.255 The range of addresses from 224.0.0.0 to 224.0.0.255 is reserved for the use of routing protocols and other low-level topology discovery or maintenance protocols. <b>Default value:</b> - <b>Type:</b> Mandatory
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.32 show igmp rtpport

**Description** Display all IGMP router port list or by VLAN ID

**Syntax** show igmp rtpport [vlan <VLAN ID>]

#### Parameter

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.33 show igmp-acl bind gigabit

**Description** Display IGMP ACL bind status for gigabit interface

**Syntax** show igmp-acl bind gigabit <port>

#### Parameter

Name	Description
port	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.34 show igmp-acl bind gigabit la

- Description** Display IGMP ACL bind status for link aggregation gigabit interface
- Syntax** show igmp-acl bind gigabit la
- Parameter** None

### 5.3.35 show igmp-acl bind xdsl

- Description** Display IGMP ACL bind status for xdsl bridge port
- Syntax** show igmp-acl bind xdsl <port>
- Parameter**

Name	Description
port	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.36 show interface xdsl {all | <port>} adsl carrier fe ds snr

- Description** Display carrier information of far-end snr downstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)
- Syntax** show interface xdsl {all | <port>} adsl carrier fe ds snr
- Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.37 show interface xdsl {all | <port>} adsl carrier fe ds qln

- Description** Display carrier information of far-end qln downstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)
- Syntax** show interface xdsl {all | <port>} adsl carrier fe ds qln
- Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.38 show interface xdsl {all | <port>} adsl carrier fe ds hlin

**Description** Display carrier information of far-end hlin downstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier fe ds hlin

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.39 show interface xdsl {all | <port>} adsl carrier fe ds hlog

**Description** Display carrier information of far-end hlog downstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier fe ds hlog

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.40 show interface xdsl {all | <port>} adsl carrier fe us load

**Description** Display carrier information of far-end load upstream by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl carrier fe us load

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.41 show interface xdsl {all | <port>} adsl carrier fe us gain

**Description** Display carrier information of far-end gain upstream by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl carrier fe us gain

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.42 show interface xdsl {all | <port>} adsl carrier fe us tss

**Description** Display carrier information of far-end tss upstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | port>} adsl carrier fe us tss

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.43 show interface xdsl {all | <port>} adsl carrier ne us snr

**Description** Display carrier information of near-end snr upstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier ne us snr

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.44 show interface xdsl {all | <port>} adsl carrier ne us qln

**Description** Display carrier information of near-end qln upstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier ne us qln

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.45 show interface xdsl {all | <port>} adsl carrier ne us hlin

**Description** Display carrier information of near-end hlin upstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier ne us hlin

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.46 show interface xdsl {all | <port>} adsl carrier ne us hlog

**Description** Display carrier information of near-end hlog upstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier ne us hlog

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.47 show interface xdsl {all | <port>} adsl carrier ne ds load

**Description** Display carrier information of near-end load downstream by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl carrier ne ds load

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.48 show interface xdsl {all | <port>} adsl carrier ne ds gain

**Description** Display carrier information of near-end gain downstream by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl carrier ne ds gain

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.49 show interface xdsl {all | <port>} adsl carrier ne ds tss

**Description** Display carrier information of near-end tss downstream by Bridge port (the xdsl port must be in diagnostic mode and the test is completed)

**Syntax** show interface xdsl {all | <port>} adsl carrier ne ds tss

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.50 show interface xdsl {all | <port>} adsl channel

**Description** Display xDSL line channel information by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl channel

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.51 show interface xdsl {all | <port>} adsl failure

**Description** Display xDSL failure by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl failure

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.52 show interface xdsl {all | <port>} adsl line

**Description** Display xDSL line status by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl line

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory



### 5.3.53 show interface xdsl {all | <port>} adsl line config

**Description** Display xDSL line configuration information by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl line config

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.54 show interface xdsl {all | <port>} adsl line delt-test

**Description** Display xDSL line DELT test information by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl line delt-test

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.55 show interface xdsl {all | <port>} adsl line information

**Description** Display xDSL line information by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl line information

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.56 show interface xdsl {all | <port>} adsl inventory

**Description** Display xDSL inventory by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl inventory

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.57 show interface xdsl {all | <port>} adsl operational

**Description** Display xDSL far-end/near-end operational information by Bridge port

**Syntax** show interface xdsl {all | <port>} adsl operational {fe | ne}

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.58 show interface xdsl {all | <port>} bridge

**Description** Display Bridge information by Bridge port

**Syntax** show interface xdsl {all | <port>} bridge

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.59 show interface xdsl {all | <port>} cellcount

**Description** Display ATM cell counter by Bridge port

**Syntax** show interface xdsl {all | <port>} cellcount

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.60 show interface xdsl {all | <port>} counter

**Description** Display Ethernet packet counter by Bridge port

**Syntax** show interface xdsl {all | <port>} counter

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.61 show interface xdsl {all | <port>} ipoa

**Description** Display IPoA (RFC 2684) information by Bridge port

**Syntax** show interface xdsl {all | <port>} ipoa

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.62 show interface xdsl {all | <port>} vc

**Description** Display VC information by Bridge port

**Syntax** show interface xdsl {all | <port>} vc

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.63 show interface xdsl {all | <port>} vlan

**Description** Display VLAN information by Bridge port

**Syntax** show interface xdsl {all | <port>} vlan

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.64 show interface bridge

**Description** Display All interface Bridge information

**Syntax** show interface bridge

**Parameter** None

### 5.3.65 show interface counter

**Description** Display All interface Ethernet packet counter

**Syntax** show interface counter

**Parameter** None

### 5.3.66 show interface gigabit [<port>] bridge

**Description** Display Bridge information of all Gigabit Ethernet interfaces or by Gigabit Ethernet port

**Syntax** show interface gigabit [<port>] bridge

**Parameter**

Name	Description
port	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.67 show interface gigabit [<port>] counter

**Description** Display Gigabit Ethernet counter of all Gigabit Ethernet interfaces or by Gigabit Ethernet port

**Syntax** show interface gigabit [<port>] counter

**Parameter**

Name	Description
port	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.68 show interface gigabit [<port>] stp

**Description** Display Port Spanning Tree status of all Gigabit Ethernet interfaces or by Gigabit Ethernet port

**Syntax** show interface gigabit [<port>] stp

**Parameter**

Name	Description
port	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.69 show interface gigabit [<port>] vlan

**Description** Display VLAN information of all Gigabit Ethernet interface or by Gigabit Ethernet port

**Syntax** show interface gigabit [<port>] vlan

**Parameter**

Name	Description
port	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.70 show interface gigabit la bridge

**Description** Display link aggregation gigabit Ethernet bridge information

**Syntax** show interface gigabit la bridge

**Parameter** None

### 5.3.71 show interface gigabit la counter

**Description** Display link aggregation gigabit Ethernet counter

**Syntax** show interface gigabit la counter

**Parameter** None

### 5.3.72 show interface gigabit la lacp

**Description** Display gigabit Ethernet aggregator port information

**Syntax** show interface gigabit la lacp

**Parameter** None

### 5.3.73 show interface gigabit la vlan

**Description** Display link aggregation Gigabit Ethernet vlan information

**Syntax** show interface gigabit la vlan

**Parameter** None

### 5.3.74 show lacp

**Description** Display LACP information

**Syntax** show lacp

**Parameter** None

### 5.3.75 show mac-spoofing-detect config

**Description** Display MAC Spoofing Detect configuration

**Syntax** show mac-spoofing-detect config

**Parameter** None

### 5.3.76 show mac-spoofing-detect log

**Description** Display MAC Spoofing Detect log  
**Syntax** show mac-spoofing-detect log  
**Parameter** None

### 5.3.77 show management all

**Description** Display all system management port ip setting  
**Syntax** show management all  
**Parameter** None

### 5.3.78 show management dhcp

**Description** Display DHCP client setting  
**Syntax** show management dhcp  
**Parameter** None

### 5.3.79 show management gbe

**Description** Display GBE management port ip setting  
**Syntax** show management gbe  
**Parameter** None

### 5.3.80 show management mgmt

**Description** Display MGMT management port ip setting  
**Syntax** show management mgmt  
**Parameter** None

### 5.3.81 show pm <port> adsl day

**Description** Display performance monitoring data for previous 1 day or current day  
**Syntax** show pm <port> adsl day {<number> | current}  
**Parameter**

Name	Description
port	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory
number	Day number <b>Valid values:</b> 1~1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.82 show pm <port> adsl interval

**Description** Display performance monitoring data for previous 1~96 intervals or current interval

**Syntax** show pm <port> adsl interval {<number> | current}

**Parameter**

Name	Description
port	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory
number	Interval number <b>Valid values:</b> 1~96 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.83 show port-template parameter

**Description** Display parameter mask. That is, display which profiles (or function) of the template port are selected to be duplicated to other ports. Mask means selected; Unmask means not-selected.

**Syntax** show port-template parameter

**Parameter** None

### 5.3.84 show priority-list ds

**Description** Display differentiated services priority list

**Syntax** show priority-list ds [<number>]

**Parameter**

Name	Description
number	Differentiate services priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.85 show priority-list dstip

**Description** Display destination IP address priority list

**Syntax** show priority-list dstip [<number>]

**Parameter**

Name	Description
number	Destination IP address priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.86 show priority-list dstmac

**Description** Display destination MAC address priority list

**Syntax** show priority-list dstmac [<number>]

**Parameter**

Name	Description
number	Destination MAC address priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.87 show priority-list ethertype

**Description** Display specific Ether Type VLAN priority list

**Syntax** show priority-list ethertype [<number>]

**Parameter**

Name	Description
number	Ether Type priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.88 show priority-list ipprotocol

**Description** Display IP Protocol VLAN priority list

**Syntax** show priority-list ipprotocol [<number>]

**Parameter**

Name	Description
number	IP Protocol VLAN priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.89 show priority-list srcip

**Description** Display source IP address priority list

**Syntax** show priority-list srcip [<number>]

**Parameter**

Name	Description
number	Source IP address priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional



### 5.3.90 show priority-list srcmac

**Description** Display source MAC address priority list

**Syntax** show priority-list srcmac [<number>]

**Parameter**

Name	Description
number	Source MAC address priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.91 show priority-list tos

**Description** Display ToS (IP Precedence) priority list

**Syntax** show priority-list tos [<number>]

**Parameter**

Name	Description
number	ToS (IP Precedence) priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.92 show priority-list vlanid

**Description** Display VLAN ID priority list

**Syntax** show priority-list vlanid [<number>]

**Parameter**

Name	Description
number	VLAN ID priority list number. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.93 show priority-queue config

**Description** Display Priority and Queue mapping configuration

**Syntax** show priority-queue config

**Parameter** None

### 5.3.94 show priority-regen

**Description** Display VLAN priority tag filter

**Syntax** show priority-regen

**Parameter** None

### 5.3.95 show profile alarm all

**Description** Display alarm profile  
**Syntax** show profile alarm all  
**Parameter** None

### 5.3.96 show profile igmp-acl

**Description** Display IGMP ACL profile  
**Syntax** show profile igmp-acl <number>  
**Parameter**

Name	Description
<number>	Profile index <b>Valid values:</b> 1~15 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.97 show profile rate-limit policer

**Description** Display rate limit policer information  
**Syntax** show profile rate-limit policer  
**Parameter** None

### 5.3.98 show profile service adsl

**Description** Display ADSL service profile  
**Syntax** show profile service adsl {<number> | all}  
**Parameter**

Name	Description
<number>	Profile index <b>Valid values:</b> 1~120 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.99 show profile spectrum adsl

**Description** Display ADSL service profile  
**Syntax** show profile service adsl {<number> | all}  
**Parameter**

Name	Description
<number>	Profile index <b>Valid values:</b> 1~120 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.100 show profile tca adsl

**Description** Display one specified threshold crossing alert profile or all profiles

**Syntax** show profile tca adsl {<index> | all}

**Parameter**

Name	Description
<index>	Profile index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.101 show rmon alarm

**Description** Display RMON alarm information

**Syntax** show rmon alarm {all | <number>}

**Parameter**

Name	Description
number	RMON alarm entry index. <b>Valid values:</b> 1 ~ 64 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.102 show rmon ether\_history

**Description** Display RMON Ether history information

**Syntax** show rmon ether\_history <number>

**Parameter**

Name	Description
number	RMON index. <b>Valid values:</b> 1 ~ 10 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.103 show rmon event

**Description** Display RMON event information

**Syntax** show rmon event {all | <number>}

**Parameter**

Name	Description
number	RMON event entry index. <b>Valid values:</b> 1 ~ 128 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.104 show rmon history

**Description** Display RMON history control information

**Syntax** show rmon history {all | <number>}

**Parameter**

Name	Description
number	RMON history control entry index. <b>Valid values:</b> 1 ~ 10 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.105 show rmon log

**Description** Display RMON log

**Syntax** show rmon log

**Parameter** None

### 5.3.106 show rmon statistic

**Description** Display RMON statistic information

**Syntax** show rmon statistic {all | <number>}

**Parameter**

Name	Description
number	RMON statistic entry index. <b>Valid values:</b> 1 ~ 10 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.107 show route

**Description** Display GBE routing table and default gateway

**Syntax** show route

**Parameter** None

### 5.3.108 show runningcfg

**Description** Display running config

**Syntax** show runningcfg

**Parameter** None

### 5.3.109 show runningcfg interface xdsl

**Description** Display running config by XDSL interface

**Syntax** show runningcfg interface xdsl <port>

**Parameter**

Name	Description
port	XDSL Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.110 show runningcfg interface gigabit

**Description** Display running config by Gigabit Ethernet interface (or Link aggregation)

**Syntax** show runningcfg interface gigabit {<port> | la}

**Parameter**

Name	Description
port	Gigabit port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.111 show snmp

**Description** Display SNMP community/notify/target setting

**Syntax** show snmp {community | notify | target}

**Parameter** None

### 5.3.112 show sntp

**Description** Display SNTP setting

**Syntax** show sntp

**Parameter** None

### 5.3.113 show stp

**Description** Display spanning tree

**Syntax** show stp

**Parameter** None

### 5.3.114 show syslog server

**Description** Display IP address of the syslog server

**Syntax** show syslog server

**Parameter** None

### 5.3.115 show system

**Description** Display system information/inventory/name/performance  
**Syntax** show system {information | inventory | name | performance}  
**Parameter** None

### 5.3.116 show tcm config

**Description** Display TCM (Three-Color Marking) Policer configuration  
**Syntax** show tcm config  
**Parameter** None

### 5.3.117 show tcm-policer

**Description** Display TCM Policer Binding Table  
**Syntax** show tcm-policer  
**Parameter** None

### 5.3.118 show temperature

**Description** Display system temperature  
**Syntax** show temperature  
**Parameter** None

### 5.3.119 show time

**Description** Display current time  
**Syntax** show time  
**Parameter** None

### 5.3.120 show uptime

**Description** Display System up time and CPU loading  
**Syntax** show uptime  
**Parameter** None

### 5.3.121 show version

**Description** Display CLI software version  
**Syntax** show version  
**Parameter** None

### 5.3.122 show version detail

**Description** Display CLI software version and system information  
**Syntax** show version detail  
**Parameter** None

### 5.3.123 show vlan

**Description** Display bridge port member set

**Syntax** show vlan [<VLAN ID>]

**Parameter**

Name	Description
<VLAN ID>	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Optional

### 5.3.124 show vlan ethertype

**Description** Show VLAN S-Tag Ether type

**Syntax** show vlan ethertype

**Parameter** None

### 5.3.125 show vlan protocol-base

**Description** Display protocol based VLAN table

**Syntax** show vlan ethertype

**Parameter** None

### 5.3.126 show vlan-translation one-to-one

**Description** Display one-to-one VLAN translation table

**Syntax** show vlan-translation one-to-one

**Parameter** None

### 5.3.127 show vlan-translation many-to-one

**Description** Display many-to-one VLAN translation table

**Syntax** show vlan-translation many-to-one

**Parameter** None

### 5.3.128 telnet

**Description** Telnet to a destination (if you're connecting to the DSLAM through its console port, this command is not provided)

**Syntax** telnet <target address>

**Parameter**

Name	Description
target address	IPv4 address or hostname <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.3.129 traceroute

**Description** Trace route (and not use ICMP ECHO instead of UDP datagrams)

**Syntax** traceroute <target address> [no\_icmp]

**Parameter**

Name	Description
target address	IPV4 address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory



## 5.4 Configure Mode Commands

The commands in this section can be executed only in the Configure execution mode.

### 5.4.1 access-list

**Description** Go to access-list execution mode from Configure mode.

**Syntax** access-list

**Parameter** None

### 5.4.2 account add

**Description** Add new account

**Syntax** account add <name>

account add <name> password <password> comment <comment>

account add <name> password <password> level <level> [comment <comment>]

account add <name> password <password> password-expiration <day number>

**Parameter**

Name	Description
<name>	ID name (max 31 characters). Only 0-9, a-z, A-Z, and symbol “_.” are accepted for account name. For example, abc_12_XYZ-10.1 is a valid user name. Note that the IDL-4802 does not accept user names beginning with a digital number. For example, 123abc or 123456 are not a valid name. <b>Default value:</b> - <b>Type:</b> Mandatory
<password>	Input password (max 31 characters) <b>Default value:</b> space char <b>Type:</b> Optional
<level>	Set access level <b>Valid values:</b> superuser, engineer, guest <b>Default value:</b> guest <b>Type:</b> Optional
<comment>	Set comment (max 31 characters) <b>Default value:</b> space char <b>Type:</b> Optional
<day number>	Set password expiration days (0:disable) <b>Default value:</b> - <b>Type:</b> Optional

### 5.4.3 account delete

**Description** Delete account

**Syntax** account delete <name>

**Parameter**

Name	Description
<name>	ID name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.4.4 account modify

**Description** Modify account

**Syntax** account modify <name> comment <comment>

account modify <name> password <password> [{ level <level> [comment <comment>] | comment <comment> | password-expiration <day number> }]

account modify <name> level <level> [comment <comment>]

account modify <name> password-expiration <day number>

**Parameter**

Name	Description
<name>	ID name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<password>	Input password (max 31 characters) <b>Default value:</b> space char <b>Type:</b> Optional
<level>	Set access level <b>Valid values:</b> superuser, engineer, guest <b>Default value:</b> guest <b>Type:</b> Optional
<comment>	Set comment (max 31 characters) <b>Default value:</b> space char <b>Type:</b> Optional
day number	Set password expiration days (0:disable) <b>Default value:</b> - <b>Type:</b> Optional

#### 5.4.5 aging

**Description** Bridge aging time

**Syntax** aging <number>

**Parameter**

Name	Description
number	Aging time (sec). <b>Valid values:</b> (10~1000000) sec. <b>Default value:</b> 300 <b>Type:</b> Mandatory

#### 5.4.6 alarm aco active

**Description** Set ACO active

**Syntax** alarm aco active

**Parameter** None

#### 5.4.7 alarm event clear

**Description** Clear alarm event log

**Syntax** alarm event clear

**Parameter** None

#### 5.4.8 alarm history clear

**Description** Clear alarm history

**Syntax** alarm history clear

**Parameter** None

#### 5.4.9 atmdesc

**Description** Go to ATM-description execution mode from Configure mode

**Syntax** atmdesc

**Parameter** None

#### 5.4.10 atm-loopback

**Description** ATM loopback testing OAM Cell Generation enable / OAM Cell Generation disable / Set ATM loopback type or clear loopback status for a PVC

**Syntax** atm-loopback enable  
atm-loopback disable  
atm-loopback <port>/<pvc> {type <type> | clear}

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1~8 <b>Default value:</b> - <b>Type:</b> Mandatory
<type>	ATM loopback type <b>Valid values:</b> f5-e2e, f5-segment <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.11 cli-config session

**Description** Set CLI max number of connection sessions

**Syntax** cli-config session <number>

**Parameter**

Name	Description
<number>	Set CLI max number of connection sessions <b>Valid values:</b> 1~10 <b>Default value:</b> 5 <b>Type:</b> Mandatory

#### 5.4.12 cli-config timeout

**Description** Set CLI configuration timeout value

**Syntax** cli-config timeout <number>

**Parameter**

Name	Description
<number>	Set CLI connection timeout value <b>Valid values:</b> 180~3600 (sec) <b>Default value:</b> 300 (sec) <b>Type:</b> Mandatory

### 5.4.13 cluster-cfg domain

**Description** Set cluster domain name

**Syntax** cluster-cfg domain <string>

**Parameter**

Name	Description
<string>	Cluster domain name <b>Valid values:</b> (max length 31) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.4.14 cluster-cfg management

**Description** Set cluster management IP configuration

**Syntax** cluster-cfg management {ip <ipv4 address> | netmask <netmask> | gateway <ipv4 address>}

**Parameter**

Name	Description
<ipv4 address>	IP address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<netmask>	Netmask of the management port. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

### 5.4.15 cluster-cfg name

**Description** Set the NE name in a cluster

**Syntax** cluster-cfg name <string>

**Parameter**

Name	Description
<string>	A name for NE Identification. <b>Valid values:</b> (max length 31) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.4.16 cluster-cfg role

**Description** Set cluster role to System-decide or Slave only or Not in a cluster (default)

**Syntax** cluster-cfg role {cluster | slave-only | individual}

**Parameter** None

#### 5.4.17 cluster-cfg voting-key

**Description** Set cluster voting-key for the priority to be a Master

**Syntax** cluster-cfg voting-key <number>

**Parameter**

Name	Description
<number>	Cluster voting key. <b>Valid values:</b> 0 ~ 4294967295 <b>Default value:</b> 0 <b>Type:</b> Mandatory

#### 5.4.18 dsl-line-identify dhcp

**Description** Set DHCP Relay Option82 enable/disable

**Syntax** dsl-line-identify dhcp {enable | disable}

**Parameter** None

#### 5.4.19 dsl-line-identify dhcp option82 circuit

**Description** Set DHCP Option82 Circuit ID type (default type is <DSLAM name>:<circuit number>:<vpi>:<vci>, or customer-defined type)

**Syntax** dsl-line-identify dhcp option82 circuit {default | customer}

**Parameter** None

#### 5.4.20 dsl-line-identify dhcp option82 dslam-name

**Description** Set DSLAM name

**Syntax** dsl-line-identify dhcp option82 dslam-name <string>

**Parameter**

Name	Description
<string>	Set DSLAM name (max length 15) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.21 dsl-line-identify dhcp option82 dslam-name-cluster

**Description** Set DSLAM name by Cluster name

**Syntax** dsl-line-identify dhcp option82 dslam-name-cluster

**Parameter** None

#### 5.4.22 dsl-line-identify dhcp option82 dslam-name-customer

**Description** Set DSLAM name by customer defined

**Syntax** dsl-line-identify dhcp option82 dslam-name-customer

**Parameter** None

#### 5.4.23 dsl-line-identify dhcp option82 sub

- Description** Set DHCP Option82 sub mode (send Circuit ID/send Remote ID/send Both)
- Syntax** dsl-line-identify dhcp option82 sub {circuit | remote | both}
- Parameter** None

#### 5.4.24 dsl-line-identify dhcp option82 remote

- Description** Set Remote ID type as Default / Line ID / Line Description / Line phone number / Customer (default type is <DSLAM name>:<bridge port index>; customer type means the customer-defined type)
- Syntax** dsl-line-identify dhcp option82 remote {default | line-id | line-descr | line-phone | customer}
- Parameter** None

#### 5.4.25 dsl-line-identify pppoe srv-name

- Description** Set Service Name
- Syntax** dsl-line-identify pppoe srv-name <string>
- Parameter**

Name	Description
<string>	Set Service name <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.26 dsl-line-identify pppoe srv-name-check

- Description** Disable/Enable PPPoE Service Name check
- Syntax** dsl-line-identify pppoe srv-name-check {disable | enable}
- Parameter** None

#### 5.4.27 fdbstatic <number> {xdsl | gigabit}

**Description** Static MAC forwarding table setting

**Syntax** fdbstatic <number> xsdl <port>/<pvc> vlan <VLAN ID> mac <mac address> {deny | pass}

fdbstatic <number> gigabit {<port> | la} vlan <VLAN ID> mac <mac address> {deny | pass}

#### Parameter

Name	Description
<number>	Static MAC forwarding table number <b>Valid values:</b> 1~512 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<mac address>	MAC address <b>Valid values:</b> xx:xx:xx:xx:xx:xx (xx:00~ff) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.28 fdbstatic <number> disable

**Description** Disable specify static MAC forwarding entry

**Syntax** fdbstatic <number> disable

#### Parameter

Name	Description
<number>	Static MAC forwarding table number <b>Valid values:</b> 1~512 <b>Default value:</b> - <b>Type:</b> Mandatory



#### 5.4.29 fdbstatic list

**Description** Show static MAC forwarding table or specified static MAC forwarding entry

**Syntax** fdbstatic [<number>] list

**Parameter**

Name	Description
<number>	Static MAC forwarding table number <b>Valid values:</b> 1~512 <b>Default value:</b> - <b>Type:</b> Optional

#### 5.4.30 firmware bootcode-upgrade

**Description** Get bootcode from FTP server and write to Flash ROM

**Syntax** firmware bootcode-upgrade <filename>

**Parameter**

Name	Description
<filename>	Boot code path and file name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.31 firmware login

**Description** Login FTP server that firmware image belongs to

**Syntax** firmware login <ipv4 address> username <name> password <password>

**Parameter**

Name	Description
<ipv4 address>	IPV4 address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory
<name>	User name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<password>	Input password (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.32 firmware partition

**Description** Set booting partition

**Syntax** firmware partition <number>

**Parameter**

Name	Description
<number>	Partition number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.33 firmware upgrade

**Description** Get firmware image from FTP server and write to Flash ROM

**Syntax** firmware upgrade <filename>

**Parameter**

Name	Description
<filename>	Path and File name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.34 http port

**Description** Set http server listening port

**Syntax** http port <port number>

**Parameter**

Name	Description
port number	The port number. <b>Valid values:</b> Integer range 0-65535 <b>Default value:</b> 80 <b>Type:</b> Mandatory

#### 5.4.35 igmp acl

**Description** IGMP ACL control mode

**Syntax** igmp acl {enable | disable}

**Parameter** None

#### 5.4.36 igmp default

**Description** IGMP set default

**Syntax** igmp [default]

**Parameter** None

#### 5.4.37 igmp deny no-router-alert

<b>Description</b>	Enable or disable the function that the system will deny IGMP packets that have no router alert option in their IP header. Default is “disable”; the system doesn’t care router alert option.
<b>Syntax</b>	igmp deny no-router-alert {enable   disable}
<b>Parameter</b>	None

#### 5.4.38 igmp disable

<b>Description</b>	Disable snooping mode and proxy mode
<b>Syntax</b>	igmp disable
<b>Parameter</b>	None

#### 5.4.39 igmp max-group-limit

<b>Description</b>	Enable or disable the function that maximum active counter of IGMP groups can be joined for every bridge port will be limited.
<b>Syntax</b>	igmp max-group-limit {enable   disable}
<b>Parameter</b>	None

#### 5.4.40 igmp proxy

<b>Description</b>	Enable GMP proxy snooping mode
<b>Syntax</b>	igmp proxy
<b>Parameter</b>	None

#### 5.4.41 igmp snooping

<b>Description</b>	Enable IGMP normal snooping mode
<b>Syntax</b>	igmp snooping
<b>Parameter</b>	None

#### 5.4.42 igmp rtpport gigabit

**Description** Set IGMP router port (giga1, giga2, or link aggregation port) and set IGMP router IP address

**Syntax** igmp rtpport gigabit {<port> | la} vlan <VLAN ID> [disable | ip <ipv4 address>]

##### Parameter

Name	Description
<port>	Port number <b>Valid values:</b> 1-2 <b>Default value:</b> - <b>Type:</b> Mandatory
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Set router IP address for proxy mode IGMP general query packet reference. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Optional

#### 5.4.43 igmp rtpport list

**Description** Show IGMP router port list

**Syntax** igmp rtpport list [<VLAN ID>]

##### Parameter

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.44 igmp timeout

**Description** IGMP timeout setting (BC/LMQT/MRT/Query/URI)  
**Syntax** igmp timeout {bc | lmq | mrt | query | uri} <number>  
**Parameter**

Name	Description
<number>	Timeout value <b>Valid values:</b> 1~500 (second) <b>Default value:</b> BC: 400 LMQT: 1 MRT: 10 Query: 125 URI: 1 <b>Type:</b> Mandatory

#### 5.4.45 igmp version

**Description** Set IGMP protocol version  
**Syntax** igmp version {v1 | v2 | v3}  
**Parameter** None

#### 5.4.46 interface gigabit

**Description** Go to Gigabit Ethernet Interface execution mode from Configure mode  
**Syntax** interface gigabit <port>  
**Parameter**

Name	Description
<port>	Gigabit Ethernet port number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.47 interface gigabit la

**Description** Go to Gigabit Ethernet link aggregation Interface execution mode from Configure mode  
**Syntax** interface gigabit la  
**Parameter** None

#### 5.4.48 interface xdsl

**Description** Go to xDSL Interface execution mode from Configure mode

**Syntax** interface xdsl <port>

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.49 mac-spoofing-detect

**Description** Enable/Disable MAC spoofing detection

**Syntax** mac-spoofing-detect {enable | disable}

**Parameter** None

#### 5.4.50 mac-spoofing-detect log

**Description** Enable/Disable MAC spoofing detection log

**Syntax** mac-spoofing-detect log {enable | disable}

**Parameter** None

#### 5.4.51 management dhcp

**Description** Enable DHCP client / Disable DHCP client / Use DHCP to request and obtain IP address again

**Syntax** management dhcp {enable | disable | renew}

**Parameter** None

#### 5.4.52 management dhcp timeout

**Description** Set DHCP client timeout value

**Syntax** management dhcp timeout <number>

**Parameter**

Name	Description
<number>	DHCP timeout. <b>Valid values:</b> 0~4294967295 (sec) <b>Default value:</b> 60 <b>Type:</b> Mandatory

### 5.4.53 management dhcp leasetime

**Description** Set DHCP client lease time value

**Syntax** management dhcp leasetime <number>

**Parameter**

Name	Description
<number>	DHCP leasetime. <b>Valid values:</b> 0~4294967295 (sec) <b>Default value:</b> 4294967295 <b>Type:</b> Mandatory

### 5.4.54 management gbe

**Description** Set GBE port IP address

**Syntax** management gbe <ipv4 address> [netmask <netmask>]

**Parameter**

Name	Description
ipv4 address	IP address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
netmask	Netmask of the management port. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

### 5.4.55 management gbe vlan

**Description** Set incoming VLAN tag management (only allowing incoming packets with the specified VLAN ID or no limit of VLAN ID)

**Syntax** management gbe vlan <VLAN ID> {no-limit | <VLAN ID>}

**Parameter**

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.56 management gbe vlan priority

**Description** Set priority level of the inband management traffic sent out from GBE port

**Syntax** management gbe vlan priority <prio ID>

**Parameter**

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

#### 5.4.57 management mgmt

**Description** Set MGMT management port IP address

**Syntax** management mgmt <ipv4 address> [netmask <netmask>]

**Parameter**

Name	Description
ipv4 address	IP address with classful netmask. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
netmask	Netmask of the management port. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

#### 5.4.58 pm clear

**Description** Clear current performance monitoring data.

**Syntax** pm clear <port>

**Parameter**

Name	Description
<port>	Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory



#### 5.4.59 port-template mask

- Description** Mask the function (profile) of template line port. Mask means to select this item to be copied to other ports.
- Syntax** port-template mask {xDSL-lineconf | xDSL-profile | xDSL-adminstatus | dsl-identify-trust | pvc-vlan-bridge | igmp-acl | filter | priority-remark | priority-regen | ethernet-policer}
- Parameter** None

#### 5.4.60 port-template unmask

- Description** Unmask the function (profile) of template line port. Un-Mask means not to select this item to be copied to other ports.
- Syntax** port-template unmask {xDSL-lineconf | xDSL-profile | xDSL-adminstatus | dsl-identify-trust | pvc-vlan-bridge | igmp-acl | filter | priority-remark | priority-regen | ethernet-policer}
- Parameter** None

#### 5.4.61 port-template template-port

- Description** Select the template line port and pasted line port (copy configuration from template port)
- Syntax** port-template template-port <port> paste-port <port>
- Parameter**

Name	Description
<port>	XDSL Port number <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.62 priority-list

- Description** Go to Priority-list execution mode from Configure mode.
- Syntax** priority-list
- Parameter** None

#### 5.4.63 priority-queue atm priority

**Description** Set ATM interface priority queue mapping

**Syntax** priority-queue atm priority <prio ID> queue <number>

**Parameter**

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory
<number>	Priority queue value. <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.64 priority-queue atm queue0-weight

**Description** Set weight value of ATM Priority Queue 0

**Syntax** priority-queue atm queue0-weight <number>

**Parameter**

Name	Description
<number>	Weight value of ATM Priority Queue 0 <b>Valid values:</b> 1 ~ 255 <b>Default value:</b> 10 <b>Type:</b> Mandatory

#### 5.4.65 priority-queue atm queue1-weight

**Description** Set weight value of ATM Priority Queue 1

**Syntax** priority-queue atm queue1-weight <number>

**Parameter**

Name	Description
<number>	Weight value of ATM Priority Queue 1 <b>Valid values:</b> 1 ~ 255 <b>Default value:</b> 20 <b>Type:</b> Mandatory

#### 5.4.66 priority-queue atm queue2-weight

**Description** Set weight value of ATM Priority Queue 2  
**Syntax** priority-queue atm queue2-weight <number>  
**Parameter**

Name	Description
<number>	Weight value of ATM Priority Queue 2 <b>Valid values:</b> 1 ~ 255 <b>Default value:</b> 30 <b>Type:</b> Mandatory

#### 5.4.67 priority-queue atm queue3-weight

**Description** Set weight value of ATM Priority Queue 3  
**Syntax** priority-queue atm queue3-weight <number>  
**Parameter**

Name	Description
<number>	Weight value of ATM Priority Queue 3 <b>Valid values:</b> 1 ~ 255 <b>Default value:</b> 40 <b>Type:</b> Mandatory

#### 5.4.68 priority-queue atm scheduling

**Description** Set priority queue scheduling only support SPQ mode or support SQP and WFQ modes  
**Syntax** priority-queue atm scheduling {sqp | spq-wfq}  
**Parameter** None

#### 5.4.69 priority-queue gigabit priority

**Description** Set gigabit interface priority queue mapping  
**Syntax** priority-queue atm priority <prio ID> queue <number>  
**Parameter**

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory
<number>	Priority queue value. <b>Valid values:</b> 0 ~ 3 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.70 profile alarm

**Description** Enter this command to go to alarm profile configuration mode.

**Syntax** profile alarm

**Parameter** None

#### 5.4.71 profile igmp-acl

**Description** Enter this command to go to IGMP ACL profile configuration mode

**Syntax** profile igmp-acl <profile index>

**Parameter**

Name	Description
<profile index>	Profile index <b>Valid values:</b> 1~15 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.72 profile service adsl

**Description** Enter this command to go to service profile configuration mode or delete a service profile

**Syntax** profile service adsl <profile index> [disable]

**Parameter**

Name	Description
<profile index>	Profile index <b>Valid values:</b> 2 ~ 120 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.73 profile spectrum

**Description** Enter this command to go to spectrum profile configuration mode or delete a spectrum profile

**Syntax** profile spectrum {adsl2 | adsl2plus | readsl2} <profile index> [disable]

**Parameter**

Name	Description
profile index	Profile index <b>Valid values:</b> 2 ~ 120 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.74 profile tca xdsl

**Description** Enter this command to go to TCA profile configuration mode or delete the specified TCA profile

**Syntax** profile tca xdsl <index> [disable]

**Parameter**

Name	Description
<index>	TCA profile index. <b>Valid values:</b> 2~64 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.75 profile rate-limit

**Description** Enter this command to go to rate-limit profile configuration mode

**Syntax** profile tca xdsl <index> [disable]

**Parameter** None

#### 5.4.76 remotecfg login

**Description** Login FTP server to get remote configuration and load it to running configuration or write remote configuration to memory

**Syntax** remotecfg login <ipv4 address> get <filename> {load | write partition <number>}

**Parameter**

Name	Description
<ipv4 address>	IP address of TFTP server. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory
<filename>	Remote path and file name (max 31 character) <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Partition number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.77 restore-factory

**Description** Restore factory setting (Except out-band IP address and user account, all other configuration will be restored to factory default. User needs to restart the system after restore-factory to make the setting take effect.)

**Syntax** restore-factory

**Parameter** None

#### 5.4.78 rmon alarm <index> alarm\_interval

**Description** Set RMON alarm interval

**Syntax** rmon alarm <index> alarm\_interval <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Alarm interval. <b>Valid values:</b> 0~2147483647 (0: disable) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.79 rmon alarm <index> delete

**Description** Delete RMON alarm entry

**Syntax** rmon alarm <index> delete <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.80 rmon alarm <index> falling\_eventindex

**Description** Set RMON alarm falling event index

**Syntax** rmon alarm <index> falling\_eventindex <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	RMON alarm falling event index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.81 rmon alarm <index> falling\_threshold

**Description** Set RMON alarm falling threshold

**Syntax** rmon alarm <index> falling\_threshold <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	RMON alarm falling threshold <b>Valid values:</b> 0~4294967295 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.82 rmon alarm <index> owner

**Description** RMON alarm owner

**Syntax** rmon alarm <index> owner <string>

**Parameter**

Name	Description
<string>	Owner name. <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.83 rmon alarm <index> rising\_eventindex

**Description** Set RMON alarm rising event index

**Syntax** rmon alarm <index> rising\_eventindex <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	RMON alarm rising event index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.84 rmon alarm <index> rising\_threshold

**Description** Set RMON alarm rising threshold

**Syntax** rmon alarm <index> rising\_threshold <number>

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	RMON alarm rising threshold <b>Valid values:</b> 0~4294967295 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.85 rmon alarm <index> sample\_type

**Description** RMON alarm sample type (Compared directly with the thresholds or Difference compared with the thresholds)

**Syntax** rmon alarm <index> sample\_type {absolute | delta}

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory



#### 5.4.86 rmon alarm <index> startup\_alarm

**Description** RMON startup alarm (Rising threshold alarm, Falling threshold alarm or Both rising and falling threshold alarm)

**Syntax** rmon alarm <index> startup\_alarm {rising | falling | both}

**Parameter**

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.4.87 rmon alarm <index> variable

**Description** Source sample in statistic table

Variable	Description
rx_broadcast	Monitoring rx broadcast packets
rx_bytes	Monitoring rx bytes packets
rx_dropped	Monitoring rx dropped packets
rx_err_aligment	Monitoring rx error aligment packets
rx_fragments	Monitoring rx fragments packets
rx_jabber	Monitoring rx jabber packets
rx_multicast	Monitoring rx multicast packets
rx_oversize	Monitoring rx oversize packets
rx_packets	Monitoring rx packets
rx_undersize	Monitoring rx undersize packets
tx_single_collision	Monitoring tx single collision packets
txrx_frames_64	Monitoring tx 64 octets
txrx_frames_127	Monitoring tx 65 to 127 octets
txrx_frames_255	Monitoring tx 128 to 255 octets
txrx_frames_511	Monitoring tx 256 to 511 octets
txrx_frames_1023	Monitoring tx 512 to 1023 octets
txrx_frames_1518	Monitoring tx 1024 to 1518 octets

**Syntax** rmon alarm <index> variable {rx\_broadcast | rx\_bytes | rx\_dropped | rx\_err\_aligment | rx\_fragments | rx\_jabber | rx\_multicast | rx\_oversize | rx\_packets | rx\_undersize} index <number>

rmon alarm <index> variable {tx\_single\_collision | txrx\_frames\_64 | txrx\_frames\_127 | txrx\_frames\_255 | txrx\_frames\_511 | txrx\_frames\_1023 | txrx\_frames\_1518} index <number>

#### Parameter

Name	Description
<index>	RMON alarm entry index <b>Valid values:</b> 1~64 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Source index in statistic table <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.88 rmon event <index> community

**Description** Set RMON event community

**Syntax** rmon event <index> community <string>

**Parameter**

Name	Description
<index>	RMON event entry index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	RMON event community <b>Valid values:</b> string type value. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.89 rmon event <index> delete

**Description** Delete RMON event entry

**Syntax** rmon event <index> delete

**Parameter**

Name	Description
<index>	RMON event entry index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.90 rmon event <index> description

**Description** Description for the RMON event

**Syntax** rmon event <index> description <string>

**Parameter**

Name	Description
<index>	RMON event entry index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	Event description <b>Valid values:</b> string type value. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.91 rmon event <index> owner

**Description** Set RMON event owner

**Syntax** rmon event <index> owner <string>

**Parameter**

Name	Description
<index>	RMON event entry index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	Owner name <b>Valid values:</b> string type value. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.92 rmon event <index> type

**Description** Set RMON event type (no alarm, only syslog, only SNMP trap, or both syslog and SNMP trap)

**Syntax** rmon event <index> type {none | log | trap | both}

**Parameter**

Name	Description
<index>	RMON event entry index <b>Valid values:</b> 1~128 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.93 rmon history <index> buckets\_requested

**Description** Set RMON history buckets requested

**Syntax** rmon history <index> buckets\_requested <number>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Buckets requested value <b>Valid values:</b> 1~65535 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.94 rmon history <index> delete

**Description** Delete RMON history entry

**Syntax** rmon history <index> delete

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.95 rmon history <index> ifc

**Description** Set Physical interface

**Syntax** rmon history <index> ifc <number>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Physical interface index <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.96 rmon history <index> interval

**Description** Set RMON history interval

**Syntax** rmon history <index> interval <number>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	History interval <b>Valid values:</b> 1~3600 (sec) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.97 rmon history <index> owner

**Description** Set RMON history owner

**Syntax** rmon history <index> owner <string>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	Owner name <b>Valid values:</b> string type value. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.98 rmon statistic <index> delete

**Description** Delete RMON statistic entry

**Syntax** rmon statistic <index> delete

**Parameter**

Name	Description
<index>	RMON statistic entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.99 rmon statistic <index> ifc

**Description** Set Physical interface

**Syntax** rmon statistic <index> ifc <number>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Physical interface index <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.100 rmon statistic <index> owner

**Description** Set RMON statistic owner

**Syntax** rmon statistic <index> owner <string>

**Parameter**

Name	Description
<index>	RMON history control entry index <b>Valid values:</b> 1~10 <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	Owner name <b>Valid values:</b> string type value. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.101 route

**Description** Add routing to route table

**Syntax** route <ipv4 address > netmask <ipv4 address > gateway <ipv4 address >

**Parameter**

Name	Description
<ipv4 address>	IP address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.102 route default

**Description** Set default route

**Syntax** route default <ipv4 address>

**Parameter**

Name	Description
<ipv4 address>	Default route IP address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.103 route delete

**Description** Delete routing from route table

**Syntax** route delete <ipv4 address> netmask <ipv4 address>

**Parameter**

Name	Description
<ipv4 address>	IP address. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.104 runningcfg active partition

**Description** There are two memory partitions for storing the configuration data. This command allows you to select the flash boot point (partition) for next power-on.

**Syntax** runningcfg active partition <number>

**Parameter**

Name	Description
<number>	Partition number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.105 runningcfg load partition

**Description** Load running configuration from memory

**Syntax** runningcfg load partition <number>

**Parameter**

Name	Description
<number>	Partition number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory



#### 5.4.106 runningcfg login

**Description** Login FTP server

**Syntax** runningcfg login <ipv4 address> put <filename>

**Parameter**

Name	Description
<ipv4 address>	IP address of TFTP server. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory
<filename>	Path and File name (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.107 runningcfg write partition

**Description** Write running configuration to memory

**Syntax** runningcfg write partition <number>

**Parameter**

Name	Description
<number>	Partition number <b>Valid values:</b> 1~2 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.108 snmp <index> community

**Description** Set SNMP read only or read/write community string

**Syntax** snmp <index> community {ro | rw} <community>

**Parameter**

Name	Description
<index>	SNMP community index <b>Valid values:</b> 1~32 <b>Default value:</b> - <b>Type:</b> Mandatory
<community>	Community string. (max 63 character; note that community names beginning with a digital number are not allowed) <b>Default value:</b> public <b>Type:</b> Mandatory

#### 5.4.109 snmp notify

**Description** Set SNMP notify information / Delete SNMP notify tag

**Syntax** snmp notify <name> {tag <tag> | delete}

**Parameter**

Name	Description
<name>	Notify name string. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<tag>	Notify Tag string. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.110 snmp target <name> address

**Description** Set SNMP target address

**Syntax** snmp target <name> address <ipv4 address> port <port>

**Parameter**

Name	Description
<name>	SNMP target name <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Target IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	SNMP target port <b>Valid values:</b> 1~65535 <b>Default value:</b> 162 <b>Type:</b> Mandatory

#### 5.4.111 snmp target <name> delete

**Description** Delete SNMP target tag list

**Syntax** snmp target <name> delete

**Parameter**

Name	Description
<name>	SNMP target name <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.112 snmp target <name> tag-list

**Description** Set SNMP target tag list

**Syntax** snmp target <name> tag-list <string>

**Parameter**

Name	Description
<name>	SNMP target name <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<string>	SNMP target tag list <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.113 snmp target <name> version

**Description** Set SNMP target trap version to V1 or V2C

**Syntax** snmp target <name> version {v1 | v2c}

**Parameter**

Name	Description
<name>	SNMP target name <b>Valid values:</b> (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.114 snmp polling interval

**Description** Set SNMP polling interval

**Syntax** snmp polling interval <number>

**Parameter**

Name	Description
number	Polling interval (in seconds) <b>Valid values:</b> 60~65535 <b>Default value:</b> 600 <b>Type:</b> Mandatory

#### 5.4.115 snmp server address

**Description** Set SNMP server ip address

**Syntax** snmp server address <ipv4 address>

**Parameter**

Name	Description
<ipv4 address>	IP address of SNMP server. <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory

#### 5.4.116 stp

**Description** STP set default

**Syntax** stp [default]

**Parameter** None

#### 5.4.117 stp enable

**Description** Enable Spanning Tree Protocol (STP)

**Syntax** stp enable

**Parameter** None

#### 5.4.118 stp disable

**Description** Disable Spanning Tree Protocol (STP)

**Syntax** stp disable

**Parameter** None

#### 5.4.119 stp forward delay

**Description** Set STP forward delay

**Syntax** stp forward delay <number>

**Parameter**

Name	Description
number	STP forward delay value <b>Valid values:</b> 4-30 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.120 stp hello time

**Description** Set STP hello time

**Syntax** stp hello time <number>

**Parameter**

Name	Description
number	STP hello time value <b>Valid values:</b> 1-10 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.121 stp max-age

**Description** Set STP maximum age

**Syntax** stp max-age <number>

**Parameter**

Name	Description
number	STP maximum age value <b>Valid values:</b> 6-40 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.122 stp priority

**Description** Set STP priority value

**Syntax** stp priority <number>

**Parameter**

Name	Description
number	STP priority value <b>Valid values:</b> 0-65535 <b>Default value:</b> 32768 <b>Type:</b> Mandatory

#### 5.4.123 stp version

**Description** Set version to STP or RSTP

**Syntax** stp version {STP | RSTP}

**Parameter** None

#### 5.4.124 syslog server

**Description** Set system log server

**Syntax** syslog server <ipv4 address>

**Parameter**

Name	Description
<ipv4 address>	Syslog server IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory

#### 5.4.125 tcm color-aware

**Description** Set Color Aware or Color Blind TCM Policer

**Syntax** tcm color-aware {aware | blind}

**Parameter** None

#### 5.4.126 tcm color-field

**Description** Set TCM color field to be VLAN priority or DSCP.

**Syntax** tcm color-field {vprio | dscp}

**Parameter** None

#### 5.4.127 tcm green

**Description** Set TCM green color value

**Syntax** tcm green <number>

**Parameter**

Name	Description
<number>	TCM green color value <b>Valid values:</b> 0 ~ 7 for VLAN priority color field; 0 ~ 63 for DSCP color field <b>Default value:</b> 1 <b>Type:</b> Mandatory

#### 5.4.128 tcm non-conform-pkt

**Description** Set the action for non-conforming packets: discard or tag. If "Tag" is selected, then all the packets will be marked as green, yellow, or red in the Color field.

**Syntax** tcm non-conform-pkt {discard | tag}

**Parameter** None

#### 5.4.129 tcm red

**Description** Set TCM red color value

**Syntax** tcm red <number>

**Parameter**

Name	Description
<number>	TCM red color value <b>Valid values:</b> 0 ~ 7 for VLAN priority color field; 0 ~ 63 for DSCP color field <b>Default value:</b> 7 <b>Type:</b> Mandatory

#### 5.4.130 tcm yellow

**Description** Set TCM yellow color value

**Syntax** tcm yellow <number>

**Parameter**

Name	Description
<number>	TCM yellow color value <b>Valid values:</b> 0 ~ 7 for VLAN priority color field; 0 ~ 63 for DSCP color field <b>Default value:</b> 3 <b>Type:</b> Mandatory

#### 5.4.131 temperature threshold

**Description** Shelf temperature threshold

**Syntax** temperature threshold {up | down | fan} <number>

**Parameter**

Name	Description
<number>	Temperature threshold value. <b>Valid values:</b> up: -55~85 Down: -55~85 fan: -40~15 <b>Default value:</b> up: 65 down: 65 fan: -40 <b>Type:</b> Mandatory

#### 5.4.132 temperature shelf time

**Description** Shelf time

**Syntax** temperature shelf time {up | down} <number>

**Parameter**

Name	Description
<number>	Shelf time value. <b>Valid values:</b> 1~255 <b>Default value:</b> 10 <b>Type:</b> Mandatory

#### 5.4.133 time set date

**Description** Set date of the system (default is current system date)

**Syntax** time set date {MM-DD-YY | MM-DD-CCYY}

**Parameter**

Name	Description
MM	Month. <b>Valid values:</b> 01-12 <b>Type:</b> Mandatory
DD	Day of month. <b>Valid values:</b> 01-31 <b>Type:</b> Mandatory
CC	Century. <b>Valid values:</b> 0 <b>Type:</b> Optional
YY	Short year start from 2000. <b>Valid values:</b> 00-99 <b>Type:</b> Mandatory



#### 5.4.134 time set time

**Description** Set time of the system (default is current system time)

**Syntax** time set time {hh:mm | hh:mm:ss}

**Parameter**

Name	Description
hh	Hour in 24 hour format <b>Valid values:</b> 00-23 <b>Type:</b> Mandatory
mm	Minute. <b>Valid values:</b> 00-59 <b>Type:</b> Mandatory
ss	Second <b>Valid values:</b> 00-59 <b>Type:</b> Optional

#### 5.4.135 time set timezone

**Description** Set timezone

**Syntax** time set timezone <timezone>

**Parameter**

Name	Description
timezone	Timezone <b>Type:</b> Mandatory <b>Valid values:</b> Given below. idl (GMT-12:00) International Date Line idlw (GMT-12:00) International Date Line West nt (GMT-11:00) Nome Time ahst (GMT-10:00) Alaska GMT Hawaii Standard Time hst (GMT-10:00) Hawaiian Standard Time bdt (GMT-10:00) BDT cat (GMT-10:00) Central Alaska Time yst (GMT-09:00) Yukon Standard Time hdt (GMT-09:00) HDT pst (GMT-08:00) Pacific Standard Time ydt (GMT-08:00) YDT mst (GMT-07:00) Mountain Standard Time pdt (GMT-07:00) Pacific Daylight Time cst (GMT-06:00) Central Standard Time mdt (GMT-06:00) Mountain Daylight Time est (GMT-05:00) Eastan Standard Time

cdt	(GMT-05:00) Central Daylight Time
ast	(GMT-04:00) Atlantic Standard Time
edt	(GMT-04:00) Eastan Daylight Time
nst Time	(GMT-03:30) Newfoundland Standard
adt	(GMT-03:00) Altantic Daylight Time
bst	(GMT-03:00) Brazil Standard Time
gst	(GMT-03:00) Greenland Standard Time
at	(GMT-02:00) Azores Time
wat	(GMT-01:00) West Africa Time
gmt	(GMT) Greenwich Mean Time
wet	(GMT+00:00) Western European Time
ut	(GMT+00:00) Universal Time
utc	(GMT+00:00) Universal Time
cet	(GMT+01:00) Central European Time
met	(GMT+01:00) Middle European Time
mewt Time	(GMT+01:00) Middle Eruopean Winter
swt	(GMT+01:00) Swedish Winter Time
fwt	(GMT+01:00) French Winter Time
eet	(GMT+02:00) Eastean European Time
mest Summer Time	(GMT+02:00) Middle European
fst	(GMT+02:00) French Summer Time
es	(GMT+02:00) Egypt Standard Time
ed	(GMT+03:00) Egypt Daylight Time
bt	(GMT+03:00) Baghdad Time
it	(GMT+03:30) Iran Time
zp4	(GMT+04:00) GMT Plus 4 Hours
zp5	(GMT+05:00) GMT Plus 5 Hours
ist	(GMT+05:30) Indian Standard Time
zp6	(GMT+06:00) GMT Plus 6 Hours
sst	(GMT+07:00) South Smatra Time
wast Standard Time	(GMT+07:00) West Australian
jt	(GMT+07:30) Java Time
cct	(GMT+08:00) China Coast Time
hst Time	(GMT+08:00) HongKong Standard
wadt Time	(GMT+08:00) West Australian Daylight
wst	(GMT+08:00) WST
jst	(GMT+09:00) Japan Standard Time
kst	(GMT+09:00) Korean Standard Time
cast	(GMT+09:30) Central Australian

	Standard Time	
sast	Standard Time	(GMT+09:30) South Australian
jdt		(GMT+10:00) JDT
gst		(GMT+10:00) Guam Standard Time
east	Standard Time	(GMT+10:00) East Australian
cadt	Daylight Time	(GMT+10:30) Central Austrlian
sadt	Daylight Time	(GMT+10:30) South Australian
eadt	Time	(GMT+11:00) East Australian Daylight
nzt		(GMT+12:00) New Zealand Time
nzst	Time	(GMT+12:00) New Zealand Standard
idle	East	(GMT+12:00) International Date Line
nzdt	Time	(GMT+13:00) New Zealand Daylight

#### 5.4.136 trunk-mode

- Description** Set Trunk mode to Non Link Aggregation or Link Aggregation with LACP
- Syntax** trunk-mode {general | lacp}
- Parameter** None

#### 5.4.137 vlan ether type s-tag

- Description** Set VLAN S-Tag Ether Type value
- Syntax** vlan ether type s-tag <number>
- Parameter**

Name	Description
<number>	S-Tag Ether type value <b>Valid values:</b> 0x0001 ~ 0xffff <b>Default value:</b> 0x8100 <b>Type:</b> Mandatory

### 5.4.138 vlan protocol-base

**Description** Set Protocol Based VLAN table / Delete the specified entry from Protocol Based VLAN table

**Syntax** vlan protocol-base <index> {ethertype <number> vlan <VLAN ID> | disable}

**Parameter**

Name	Description
<index>	Protocol Based VLAN table index. <b>Valid values:</b> 1 ~ 32 <b>Default value:</b> - <b>Type:</b> Mandatory
<number>	Ether type value <b>Valid values:</b> 0x0001 ~ 0xffff <b>Default value:</b> - <b>Type:</b> Mandatory
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.4.139 vlan-translation <port>/<pvc> <VLAN ID> gigabit <port> one-to-one

**Description** Set one-to-one VLAN translation

**Syntax** **1. C-tag reserved**

vlan-translation <port>/<pvc> <user port VLAN ID> gigabit <port> one-to-one reserved {priority-reserved | priority-replaced <PRIO ID>}

**2. C-tag replaced**

vlan-trans vlan-translation <port>/<pvc> <user port VLAN ID> gigabit <port> one-to-one replaced <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

**3. Stacking and C-tag reserved**

vlan-trans vlan-translation <port>/<pvc> <user port VLAN ID> gigabit <port> one-to-one stacking <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

**4. Stacking and C-tag replaced**

vlan-translation <port>/<pvc> <user port VLAN ID> gigabit <port> one-to-one stacking <uplink VLAN ID> ctag-replaced <c-tag VLAN ID> <c-tag PRIO ID> {priority-reserved | priority-replaced <PRIO ID>}

**Parameter**

Name	Description
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<user port VLAN ID>	ADSL port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<uplink VLAN ID>	Gigabit uplink port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<PRIO ID>	Replaced the priority level of packets out through the uplink port with the specified value. <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.140 vlan-translation <port>/<pvc> <VLAN ID> gigabit <port> many-to-one

**Description** Set many-to-one VLAN translation

**Syntax** vlan-translation <port>/<pvc> <user port VLAN ID> gigabit <port> many-to-one replaced <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

#### Parameter

Name	Description
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<user port VLAN ID>	ADSL port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<uplink VLAN ID>	Gigabit uplink port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<PRIO ID>	Replaced the priority level of packets out through the uplink port with the specified value. <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.141 vlan-translation <port>/<pvc> <VLAN ID> gigabit la one-to-one

**Description** Set one-to-one VLAN translation for link aggregation gigabit interface

**Syntax** **1. C-tag reserved**

vlan-translation <port>/<pvc> <user port VLAN ID> gigabit la one-to-one reserved {priority-reserved | priority-replaced <PRIO ID>}

**2. C-tag replaced**

vlan-trans vlan-translation <port>/<pvc> <user port VLAN ID> gigabit la one-to-one replaced <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

**3. Stacking and C-tag reserved**

vlan-trans vlan-translation <port>/<pvc> <user port VLAN ID> gigabit la one-to-one stacking <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

**4. Stacking and C-tag replaced**

vlan-translation <port>/<pvc> <user port VLAN ID> gigabit la one-to-one stacking <uplink VLAN ID> ctag-replaced <c-tag VLAN ID> <c-tag PRIO ID> {priority-reserved | priority-replaced <PRIO ID>}

**Parameter**

Name	Description
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<user port VLAN ID>	ADSL port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<uplink VLAN ID>	Gigabit uplink port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<PRIO ID>	Replaced the priority level of packets out through the uplink port with the specified value. <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.4.142 vlan-translation <port>/<pvc> <VLAN ID> gigabit la many-to-one

**Description** Set many-to-one VLAN translation for link aggregation gigabit interface

**Syntax** vlan-translation <port>/<pvc> <user port VLAN ID> gigabit la many- to-one replaced <uplink VLAN ID> {priority-reserved | priority-replaced <PRIO ID>}

#### Parameter

Name	Description
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<user port VLAN ID>	ADSL port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<uplink VLAN ID>	Gigabit uplink port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<PRIO ID>	Replaced the priority level of packets out through the uplink port with the specified value. <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory



#### 5.4.143 vlan-translation <port>/<pvc> <VLAN ID> disable

**Description** Delete the specified entry from the VLAN translation table.

**Syntax** vlan-translation <port>/<pvc> <VLAN ID> disable

**Parameter**

Name	Description
<port>	ADSL Port number. <b>Valid values:</b> 1~48 <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<VLAN ID>	ADSL port VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.5 Ethernet Interface Mode Commands

The commands in this section can be executed only in the Ethernet Interface execution mode.

### 5.5.1 bridge

<b>Description</b>	Enter bridge configuration mode / Set bridge port to default status
<b>Syntax</b>	bridge [default]
<b>Parameter</b>	None

### 5.5.2 gbe admin

<b>Description</b>	Set Gigabit Ethernet administrative status (ON/OFF)
<b>Syntax</b>	gbe admin {on   off}
<b>Parameter</b>	None

### 5.5.3 gbe speed

<b>Description</b>	Set Gigabit ethernet speed to auto-negotiate, 100Mbps half duplexing, or 100Mbps full duplexing / Set Copper or SFP as the first priority of GBE physical interface
<b>Syntax</b>	gbe speed {auto   half_100mbps   full_100mbps   physical {copper   sfp}}
<b>Parameter</b>	None

## 5.6 Interface Mode Commands

The commands in this section can be executed only in the Interface execution mode.

### 5.6.1 bridge

**Description** Enter ATM-bridge configuration mode / Disable bridge port

**Syntax** bridge <bridge id> [disable]

**Parameter**

Name	Description
bridge id	Bridge number. <b>Valid values:</b> 1-8 <b>Default value:</b> 1 <b>Type:</b> Mandatory

### 5.6.2 adsl-config

**Description** Enter adsl configuration mode

**Syntax** adsl-config

**Parameter** None

### 5.6.3 ipoa

**Description** Enter IPoA (RFC 2684) routed mode

**Syntax** ipoa

**Parameter** None

## 5.7 ATM Bridge Mode Commands

The commands in this section can be executed only in the ATM Bridge execution mode.

### 5.7.1 accfrm

<b>Description</b>	Set acceptable frame type (untagged only, tagged only, or all)
<b>Syntax</b>	accfrm {all   tag   untag}
<b>Parameter</b>	None

### 5.7.2 default vlan

<b>Description</b>	Set default VLAN ID for a bridge port
<b>Syntax</b>	default vlan <VLAN ID>
<b>Parameter</b>	

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> 1 <b>Type:</b> Mandatory

### 5.7.3 default prio

<b>Description</b>	Set default priority value for a bridge port
<b>Syntax</b>	default prio <prio ID>
<b>Parameter</b>	

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

#### 5.7.4 dhcp-relay

**Description** Enable/disable DHCP relay, or Set circuit ID/remote ID for identifying the subscriber

**Syntax** dhcp-relay {trusted | untrusted | circuit <circuit ID> | remote <remote ID>}

**Parameter**

Name	Description
<circuit ID>	Circuit ID <b>Valid values:</b> string type (max length 48) <b>Default value:</b> - <b>Type:</b> Mandatory
<remote ID>	Remote ID <b>Valid values:</b> string type (max length 48) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.7.5 egress

**Description** Default PVID egress tagged/untagged setting

**Syntax** egress {tag | untag}

**Parameter** None

#### 5.7.6 force priority

**Description** Force priority setting (**disabled:** reserve the original priority of all packets. **egress:** force the priority value of all packets sent out from this bridge port's default VLAN to be the default VLAN priority, so this rule only works on default VLAN of this bridge port. **ingress:** force applying the default VLAN priority value to all the packets received on this bridge port (so this rule will work on all the member-set of this bridge port). **both:** combine the rules of Ingress and Egress.

**Syntax** force priority {disable | egress | ingress | both}

**Parameter** None

#### 5.7.7 igmp-acl bind

**Description** IGMP ACL (Access Control List) binding profile configuration

**Syntax** igmp-acl bind {<number> [on] | on | off | reset}

**Parameter**

Name	Description
<number>	IGMP ACL profile index. <b>Valid values:</b> 1 ~ 15 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.7.8 igmp-acl max-group

**Description** Per port limit IGMP join group number

**Syntax** igmp-acl max-group <number>

**Parameter**

Name	Description
<number>	IGMP ACL profile index. <b>Valid values:</b> 1 ~ 128 <b>Default value:</b> 8 <b>Type:</b> Mandatory

### 5.7.9 ingress

**Description** Enable/disable ingress filter mode

**Syntax** ingress {enable | disable}

**Parameter** None

### 5.7.10 ip-allowed

**Description** Enable/disable IP allowed function (user can specify allowed source IP address per bridge port)

**Syntax** ip-allowed {enable | disable}

**Parameter** None

### 5.7.11 isolation

**Description** Enable/Disable default PVID isolation setting

**Syntax** isolation [disable]

**Parameter** None

### 5.7.12 mac-learning

**Description** Enable/disable MAC learning ability of a bridge port

**Syntax** mac-learning {enable | disable}

**Parameter** None

### 5.7.13 max-mac

**Description** Set the maximum users allowed to access Internet based on user MAC address counter on per ATM PVC basis

**Syntax** max-mac <number>

**Parameter**

Name	Description
<number>	Maximum number of the MAC addresses <b>Valid values:</b> 1 ~ 128 <b>Default value:</b> 0 <b>Type:</b> Mandatory

#### 5.7.14 priority-regen

**Description** VLAN priority value regeneration or Delete VLAN priority tag filter

**Syntax** priority-regen incoming <incoming prio> {outgoing <outgoing prio> | disable}

**Parameter**

Name	Description
<incoming prio>	Incoming VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory
<outgoing prio>	Outgoing VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.7.15 protocol-base

**Description** Enable/disable protocol-based VLAN

**Syntax** protocol-base {enable | disable}

**Parameter** None

#### 5.7.16 pvc

**Description** Set VPI and VCI

**Syntax** pvc <VPI>/<VCI>

**Parameter**

Name	Description
<VPI>	Virtual Path Identifier. <b>Valid values:</b> 0 ~ 255 <b>Default value:</b> 0 <b>Type:</b> Mandatory
<VCI>	Virtual Channel Identifier. <b>Valid values:</b> 21, 32~65535 <b>Default value:</b> 35 <b>Type:</b> Mandatory

#### 5.7.17 pvc atmdesc

**Description** List ATM traffic descriptor

**Syntax** pvc atmdesc

**Parameter** None

### 5.7.18 pvc atmdesc plc

**Description** Set ATM police (Rx) descriptor

**Syntax** pvc atmdesc plc <number>

**Parameter**

Name	Description
<number>	ATM descriptor number. <b>Valid values:</b> Enter 'pvc atmdesc' command to see the descriptor list. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.7.19 pvc atmdesc shp

**Description** Set ATM shaped (Tx) descriptor

**Syntax** pvc atmdesc shp <number>

**Parameter**

Name	Description
<number>	ATM descriptor number. <b>Valid values:</b> Enter 'pvc atmdesc' command to see the descriptor list. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.7.20 pvc encapsulation

**Description** Set Encapsulation type

**Syntax** pvc encapsulation {llc | vcmux | auto}

**Parameter** None

*Note:* The IDL-4802 supports auto-detection of the ATM AAL5 encapsulation method, LLC or VC-Mux. Meanwhile, the IDL-4802 is also able to automatically sense the following protocol encapsulations: PPPoE over ATM (per RFC 2684), IPoE over ATM bridge mode, and PPP over ATM. IPoA works on individual PVC.

However, there are limitations on auto-detection of encapsulations:

3. LLC/VC-Mux automatically detection is only applicable to PVC#1 ~ PVC#4 of each ADSL port. PVC#5 ~ PVC#8 must be assigned the ATM AAL5 encapsulation method manually.
4. PPPoA works only for PVC#1 ~ PVC#4.

Refer to IPoA configuration commands.



### 5.7.21 stack

**Description** Enable/disable VLAN stacking

**Syntax** stack {enable | disable}

**Parameter** None

### 5.7.22 stack tls port enable

**Description** Enable VLAN stack TLS (transparent LAN service) port

**Syntax** stack tls port {enable | disable}

**Parameter** None

### 5.7.23 tcm-policer

**Description** Bind/Unbind Three Color Marking (TCM) Policer profile

**Syntax** tcm-policer <number> {bind | unbind}

**Parameter**

Name	Description
<number>	TCM policer profile index. <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.7.24 vlan <VLAN ID> disable

**Description** Delete a VLAN from memberset table

**Syntax** vlan <VLAN ID> disable

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.7.25 vlan <VLAN ID> list

**Description** Show memberset setting by VLAN

**Syntax** vlan <VLAN ID> list

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.7.26 vlan <VLAN ID> priority

**Description** Set VLAN memberset priority (specify priority level or reserved the originalpriority, tag or untag, enable or disable port isolation)

**Syntax** vlan <VLAN ID> priority {<prio ID> | reserved} {tag | untag} isolation [disable]

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.7.27 vlan list

**Description** Show memberset setting by VLAN

**Syntax** vlan list

**Parameter** None

## 5.8 GBE Bridge Mode Commands

The commands in this section can be executed only in the GBE Bridge execution mode.

### 5.8.1 accfrm

**Description** Set acceptable frame type (untagged only, tagged only, or all)

**Syntax** accfrm {all | tag | untag}

**Parameter** None

### 5.8.2 default vlan

**Description** Set default VLAN ID for a bridge port

**Syntax** default vlan <VLAN ID>

**Parameter**

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> 1 <b>Type:</b> Mandatory

### 5.8.3 default prio

**Description** Set default priority value for a bridge port

**Syntax** default prio <prio ID>

**Parameter**

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.8.4 egress

**Description** Default PVID egress tagged/untagged setting

**Syntax** egress {tag | untag}

**Parameter** None

### 5.8.5 ingress

**Description** Enable/disable ingress filter mode

**Syntax** ingress {enable | disable}

**Parameter** None

### 5.8.6 isolation

**Description** Enable/Disable default PVID isolation setting  
**Syntax** isolation [disable]  
**Parameter** None

### 5.8.7 link mode

**Description** Set link mode (uplink mode or user mode)  
**Syntax** link mode {uplink | user}  
**Parameter** None

### 5.8.8 max-mac

**Description** Set the maximum users allowed to access Internet based on user MAC address counter on per ATM PVC basis  
**Syntax** max-mac <number>  
**Parameter**

Name	Description
<number>	Maximum number of the MAC addresses <b>Valid values:</b> 1 ~ 4096 for GBE interface, 1 ~ 128 for ADSL interface. <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.8.9 priority-regen

**Description** VLAN priority value regeneration or Delete VLAN priority tag filter  
**Syntax** priority-regen incoming <incoming prio> {outgoing <outgoing prio> | disable}  
**Parameter**

Name	Description
<incoming prio>	Incoming VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory
<outgoing prio>	Outgoing VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.8.10 stack

**Description** Enable/disable VLAN stacking  
**Syntax** stack {enable | disable}  
**Parameter** None

### 5.8.11 stpport edge

**Description** Set edge status  
**Syntax** stpport edg {enable | disable}  
**Parameter** None

### 5.8.12 stpport enable/disable

**Description** Enable/Disable STP port  
**Syntax** stpport {enable | disable}  
**Parameter** None

### 5.8.13 stpport pathcost

**Description** Set STP port pathcost  
**Syntax** stpport pathcost <number>  
**Parameter**

Name	Description
<number>	Path cost value. <b>Valid values:</b> 1~65535 <b>Default value:</b> 9 <b>Type:</b> Mandatory

### 5.8.14 stpport priority

**Description** Set STP port priority  
**Syntax** stpport priority <number>  
**Parameter**

Name	Description
<number>	Priority value. <b>Valid values:</b> 0~240,step 16 <b>Default value:</b> 255 <b>Type:</b> Mandatory

### 5.8.15 tcm-policer

**Description** Bind/Unbind Three Color Marking (TCM) Policer profile  
**Syntax** tcm-policer <number> {bind | unbind}  
**Parameter**

Name	Description
<number>	TCM policer profile index. <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.8.16 vlan <VLAN ID> disable

**Description** Delete a VLAN from memberset table

**Syntax** vlan <VLAN ID> disable

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.8.17 vlan <VLAN ID> list

**Description** Show memberset setting by VLAN

**Syntax** vlan <VLAN ID> list

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.8.18 vlan <VLAN ID> priority

**Description** Set VLAN memberset priority (specify priority level or reserved the original priority, tag or untag, enable or disable port isolation)

**Syntax** vlan <VLAN ID> priority {<prio ID> | reserved} {tag | untag} isolation [disable]

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.8.19 vlan list

<b>Description</b>	Show memberset setting by VLAN
<b>Syntax</b>	vlan list
<b>Parameter</b>	None

## 5.9 GBE-LA Bridge Mode Commands

### 5.9.1 accfrm

**Description** Set acceptable frame type (untagged only, tagged only, or all)

**Syntax** accfrm {all | tag | untag}

**Parameter** None

### 5.9.2 default vlan

**Description** Set default VLAN ID for a bridge port

**Syntax** default vlan <VLAN ID>

**Parameter**

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> 1 <b>Type:</b> Mandatory

### 5.9.3 default prio

**Description** Set default priority value for a bridge port

**Syntax** default prio <prio ID>

**Parameter**

Name	Description
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.9.4 egress

**Description** Default PVID egress tagged/untagged setting

**Syntax** egress {tag | untag}

**Parameter** None

### 5.9.5 ingress

**Description** Enable/disable ingress filter mode

**Syntax** ingress {enable | disable}

**Parameter** None



### 5.9.6 isolation

**Description** Enable/Disable default PVID isolation setting

**Syntax** isolation [disable]

**Parameter** None

### 5.9.7 lacp actor priority system

**Description** Set actor's system priority (Link aggregation only).

**Syntax** lacp actor priority system <number>

**Parameter**

Name	Description
number	Set system priority value. <b>Valid values:</b> 0-65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.9.8 link mode

**Description** Set link mode (uplink mode or user mode)

**Syntax** link mode {uplink | user}

**Parameter** None

### 5.9.9 max-mac

**Description** Set the maximum users allowed to access Internet based on user MAC address counter on per ATM PVC basis

**Syntax** max-mac <number>

**Parameter**

Name	Description
<number>	Maximum number of the MAC addresses <b>Valid values:</b> 1 ~ 4096 <b>Default value:</b> 0 <b>Type:</b> Mandatory

### 5.9.10 priority-regen

**Description** VLAN priority value regeneration or Delete VLAN priority tag filter

**Syntax** priority-regen incoming <incoming prio> {outgoing <outgoing prio> | disable}

**Parameter**

Name	Description
<incoming prio>	Incoming VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory
<outgoing prio>	Outgoing VLAN priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.9.11 stack

**Description** Enable/disable VLAN stacking

**Syntax** stack {enable | disable}

**Parameter** None

### 5.9.12 tcm-policer

**Description** Bind/Unbind Three Color Marking (TCM) Policer profile

**Syntax** tcm-policer <number> {bind | unbind}

**Parameter**

Name	Description
<number>	TCM policer profile index. <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.9.13 vlan <VLAN ID> disable

**Description** Delete a VLAN from memberset table

**Syntax** vlan <VLAN ID> disable

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.9.14 vlan <VLAN ID> list

**Description** Show memberset setting by VLAN

**Syntax** vlan <VLAN ID> list

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.9.15 vlan <VLAN ID> priority

**Description** Set VLAN memberset priority (specify priority level or reserved the original priority, tag or untag, enable or disable port isolation)

**Syntax** vlan <VLAN ID> priority {<prio ID> | reserved} {tag | untag} isolation [disable]

**Parameter**

Name	Description
VLAN ID	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority ID <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> 0 <b>Type:</b> Mandatory

#### 5.9.16 vlan list

**Description** Show memberset setting by VLAN

**Syntax** vlan list

**Parameter** None

## 5.10 ADSL Configure Mode Commands

The commands in this section can be executed only in the ADSL Config mode.

### 5.10.1 line mode carrier

<b>Description</b>	Set/Clear xDSL line carrier
<b>Syntax</b>	line mode carrier {on   off   oninit}
<b>Parameter</b>	None

### 5.10.2 line mode diagnostic

<b>Description</b>	Set/Clear xDSL line diagnostics
<b>Syntax</b>	line mode diagnostic {init   off}
<b>Parameter</b>	None

### 5.10.3 line mode force-l3

<b>Description</b>	Set force to power management L3 mode or not
<b>Syntax</b>	line mode force-l3 {on   off}
<b>Parameter</b>	None

### 5.10.4 line mode mask

<b>Description</b>	Set/Clear xDSL line Operational mode mask
<b>Syntax</b>	line mode mask {set   clear } <opmode ID>
<b>Parameter</b>	

Name	Description
<opmode id>	The ID of allowed ADSL modes of operation. <b>Valid values:</b> Use 'list opmode' command to see all the operation modes. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.10.5 line port

**Description** Set xDSL line port information  
**Syntax** line port {id <id> | description <desc> | phone <phone number>}  
**Parameter**

Name	Description
<id>	Line ID name (max 32 characters) <b>Default value:</b> - <b>Type:</b> Mandatory
<desc>	Line port description (max 48 character) <b>Default value:</b> - <b>Type:</b> Mandatory
<phone number>	Phone number. (max 32 characters) <b>Valid values:</b> no limit format <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.10.6 line profile

**Description** Create xDSL line profile  
**Syntax** line profile {service | spectrum | tca} <number>  
**Parameter**

Name	Description
<number>	Profile index. <b>Valid values:</b> 1~120 (1~64 for tca profile) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.10.7 line status service

**Description** Set xDSL line service status (service ON/OFF/RESET)  
**Syntax** line status service {on | off | reset}  
**Parameter** None

## 5.11 IPoA Configure Mode Commands

The commands in this section can be executed only in the IPoA configure mode.

### 5.11.1 brasmac

**Description** Display Broadband RAS MAC address by index

**Syntax** brasmac <number>

**Parameter**

Name	Description
<number>	Broadband RAS MAC Table Index <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.2 brasmac list

**Description** Show Broadband RAS MAC address table

**Syntax** brasmac list

**Parameter** None

### 5.11.3 cpriority

**Description** Customer VLAN Priority setting

**Syntax** cpriority <prio ID>

**Parameter**

Name	Description
<prio ID>	Customer VLAN Priority value <b>Valid values:</b> 0 ~ 7 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.4 cvlan

**Description** Customer VLAN setting

**Syntax** cvlan <VLAN ID>

**Parameter**

Name	Description
<prio ID>	Customer VLAN ID number <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.5 ipoa-status

**Description** IPoA Status setting (enable/disable IPoA)

**Syntax** ipoa-status {enable | disable}

**Parameter** None

### 5.11.6 max-mac

**Description** Port based allowed maximum number of MAC addresses

**Syntax** max-mac <number>

**Parameter**

Name	Description
<number>	Number of MAC addresses <b>Valid values:</b> 1 ~ 128 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.7 pvc

**Description** Set VPI and VCI

**Syntax** pvc <VPI>/<VCI>

**Parameter**

Name	Description
<VPI>	Virtual Path Identifier. <b>Valid values:</b> 0 ~ 255 <b>Default value:</b> 0 <b>Type:</b> Mandatory
<VCI>	Virtual Channel Identifier. <b>Valid values:</b> 21, 32~65535 <b>Default value:</b> 35 <b>Type:</b> Mandatory

### 5.11.8 pvc atmdesc

**Description** List ATM traffic descriptor

**Syntax** pvc atmdesc

**Parameter** None

### 5.11.9 pvc atmdesc plc

**Description** Set ATM police (Rx) descriptor

**Syntax** pvc atmdesc plc <number>

**Parameter**

Name	Description
<number>	ATM descriptor number. <b>Valid values:</b> Enter 'pvc atmdesc' command to see the descriptor list. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.10 pvc atmdesc shp

**Description** Set ATM shaped (Tx) descriptor

**Syntax** pvc atmdesc shp <number>

**Parameter**

Name	Description
<number>	ATM descriptor number. <b>Valid values:</b> Enter 'pvc atmdesc' command to see the descriptor list. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.11.11 pvc encapsulation

**Description** Set Encapsulation type

**Syntax** pvc encapsulation {llc | vcmux}

**Parameter** None

### 5.11.12 uplink gigabit

**Description** Set GBE uplink mode (general or LACP)

**Syntax** uplink {<port> | la}

**Parameter**

Name	Description
<port>	Gigabit Ethernet port number. <b>Valid values:</b> 1 ~ 2 <b>Default value:</b> - <b>Type:</b> Mandatory



## 5.12 Access List Mode Commands

The commands in this section can be executed only in the ACL execution mode.

### 5.12.1 bcrate cir

**Description** Broadcast rate limiting CIR and LBS setting

**Syntax** bcrate cir <cir> lbs <lbs>

**Parameter**

Name	Description
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> 80000 <b>Type:</b> Mandatory
<lbs>	Leakage Bucket Size (millisecond) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> 80 <b>Type:</b> Mandatory

### 5.12.2 bcrate list

**Description** Show broadcast rate limiting list

**Syntax** bcrate list

**Parameter** None

### 5.12.3 dstmac

**Description** Specify destination MAC address of packets to filter / Show specified destination MAC deny access list entry / Delete specified destination MAC deny access list entry

**Syntax** dstmac <number> deny {xDSL <port>/<pvc> | gigabit {<port> | la}} mac <mac address>

dstmac <number> list

dstmac <number> disable

#### Parameter

Name	Description
<number>	Destination MAC deny access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<mac address>	Destination MAC address <b>Valid values:</b> xx:xx:xx:xx:xx:xx (xx:00~ff) <b>Default value:</b> 00:00:00:00:00:00 <b>Type:</b> Mandatory

### 5.12.4 dstmac list

**Description** Display destination MAC deny access list

**Syntax** dstmac list

**Parameter** None

### 5.12.5 dstip

**Description** Specify destination IP address of packets to filter / Show specified destination IP deny access list entry / Delete specified destination IP deny access list entry

**Syntax** dstip <number> deny {xDSL <port>/<pvc> | gigabit {<port> | la}} ip <ipv4 address> <netmask>

dstip <number> list

dstip <number> disable

#### Parameter

Name	Description
<number>	Destination IP deny access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Destination IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<netmask>	Subnet mask <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

### 5.12.6 dstip list

**Description** Display destination IP deny access list

**Syntax** dstip list

**Parameter** None

## 5.12.7 ethertype

**Description** Specify Ether Type of packets to filter / Show specified Ether Type deny access list entry / Delete specified Ether Type deny access list entry

**Syntax** ethertype <number> deny {xdsl <port>/<pvc> | gigabit {<port> | la}} type <ethertype>

ethertype <number> list

ethertype <number> disable

### Parameter

Name	Description
<number>	Ether Type deny access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<ethertype>	Ether Type value <b>Valid values:</b> 0x0001 ~ 0xffff <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.12.8 ethertype list

**Description** Display Ether Type deny access list

**Syntax** ethertype list

**Parameter** None

## 5.12.9 ip-allowed

**Description** Specify allowed source IP addresss of packets to filter / Show allowed IP access list entry / Delete specified allowed IP from access list

**Syntax** ip-allowed <number> allow xdsl <port>/<pvc> srcip <ipv4 address> vlan <VLAN ID>

ip-allowed <number> list

ip-allwowed <number> disable

### Parameter

Name	Description
<number>	Static IP allow access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Allowed source IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<VLAN ID>	IP Allowed entry VLAN ID number <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Optional

## 5.12.10 ip-allowed list

**Description** Display static IP allow access list

**Syntax** ip-allowed list

**Parameter** None

## 5.12.11 ipprotocol

**Description** Specify IP Protocol of packets to reject / Show specify IP protocol access list entry / Delete specify IP protocol deny access list entry

**Syntax** ipprotocol <number> deny {xdsl <port>/<pvc> | gigabit {<port> | la}}  
protocol <protocol>

ipprotocol <number> list

ipprotocol <number> disable

### Parameter

Name	Description
<number>	IP Protocol deny access list number <b>Valid values:</b> 1-256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
protocol	Input protocol name. <b>Valid values:</b> icmp (ICMP) Internet Control Message <1> igmp (IGMP) Internet Group Management <2> ipinip IP in IP (encapsulation) <4> tcp (TCP) Transmission Control <6> grp (GRP) Globin Reduction Protocol <7> igp (IGP) Any private interior gateway <9> udp (UDP) User Datagram <17> gre (GRE) General Routing Encapsulation <47> eigrp EIGRP <88> ospf OSPF <89> <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.12.12 ipprotocol list

**Description** Display IP protocol deny access list  
**Syntax** ipprotocol list  
**Parameter** None

### 5.12.13 l4dstport

**Description** Specify L4 dest port of packets to reject / Show specify L4 dest port access list entry / Delete specify L4 dest port deny access list entry

**Syntax** l4dstport <number> {xdsl <port>/<pvc> | gigabit {<port> | la}} port <port number>

l4dstport <number> list

l4dstport <number> disable

#### Parameter

Name	Description
<number>	L4 dest port deny access list number <b>Valid values:</b> 1-256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<port number>	L4 destination port number <b>Valid values:</b> 1-65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.12.14 l4dstport list

**Description** Display L4 dest port deny access list  
**Syntax** l4dstport list  
**Parameter** None

### 5.12.15 mcfldrate list

**Description** Display flooding rate limiting list

**Syntax** mcfldrate list

**Parameter** None

### 5.12.16 mcfldrate vlan

**Description** Display flooding rate limiting list

**Syntax** mcfldrate vlan <VLAN ID> {list | disable | cir <cir> lbs <lbs>}

**Parameter**

Name	Description
<VLAN ID>	VLAN ID <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> 80000 <b>Type:</b> Mandatory
<lbs>	Leakage Bucket Size (millisecond) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> 80 <b>Type:</b> Mandatory



### 5.12.17 srcip

**Description** Specify source IP address of packets to filter / Show specify source IP deny access list entry / Delete specify source IP deny access list entry

**Syntax** srcip <number> deny {xdsl <port>/<pvc> | gigabit {<port> | la}} ip <ipv4 address> <net mask>

srcip <number> list

srcip <number> disable

#### Parameter

Name	Description
<number>	Source IP deny access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Destination IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<netmask>	Subnet mask <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

### 5.12.18 srcip list

**Description** Display source IP deny access list

**Syntax** srcip list

**Parameter** None

## 5.12.19 srcmac

**Description** Specify source MAC of packets to reject / Show specify source MAC deny access list entry / Delete specify source MAC deny access list entry

**Syntax** srcmac <number> {xdsl <port>/<pvc> | gigabit {<port> | la}} mac <mac address>

srcmac <number> list

srcmac <number> disable

### Parameter

Name	Description
<number>	Source MAC deny access list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<mac address>	MAC address <b>Valid values:</b> xx:xx:xx:xx:xx:xx (xx:00~ff) <b>Default value:</b> 00:00:00:00:00:00 <b>Type:</b> Mandatory

## 5.12.20 srcmac list

**Description** Display source MAC deny access list

**Syntax** srcmac list

**Parameter** None

## 5.13 ATM Description Mode Commands

### 5.13.1 cbr

**Description** CBR traffic setting  
**Syntax** cbr <index> pcr <pcr> cdvt <cdvt>  
**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.2 no atmdesc

**Description** Delete ATM Description  
**Syntax** no atmdesc <number>  
**Parameter**

Name	Description
<number>	ATM Description number <b>Valid values:</b> 1~251 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.3 ubr1

**Description** UBR type 1 traffic setting (atmNoClpNoScrCdvt)

**Syntax** ubr1 <index> pcr <pcr> cdvt <cdvt>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.4 ubr2

**Description** UBR type 2 traffic setting (atmNoClpTaggingNoScr)

**Syntax** ubr2 <index> pcr <pcr> cdvt <cdvt>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.5 unshp

**Description** unshaped traffic setting (atmNoTrafficDescriptor)

**Syntax** unshp <index>

Parameter

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.6 vbr1

**Description** VBR type 1 traffic setting (atmNoClpScrCdvT)

**Syntax** vbr1 <index> pcr <pcr> cdvt <cdvt> scr <scr> mbs <mbs>

Parameter

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<scr>	Sustained Cell Rate <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<mbs>	Maximum Burst Size <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.7 vbr2

**Description** VBR type 2 traffic setting (atmClpNoTaggingScrCdvt)

**Syntax** vbr2 <index> pcr <pcr> cdvt <cdvt> scr <scr> mbs <mbs>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<scr>	Sustained Cell Rate <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<mbs>	Maximum Burst Size <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.8 vbr3

**Description** VBR type 3 traffic setting (atmClpTaggingScrCdvT)

**Syntax** vbr3 <index> pcr <pcr> cdvt <cdvt> scr <scr> mbs <mbs>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<scr>	Sustained Cell Rate <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<mbs>	Maximum Burst Size <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.9 ubr-shp

**Description** UBR shaped traffic setting (atmNoClpNoScr)

**Syntax** ubr-shp <index> pcr <pcr>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.10 cbr-shp

**Description** CBR shaped traffic setting (atmClpTransparentNoScr)

**Syntax** cbr-shp <index> pcr <pcr> cdvt <cdvt>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory



### 5.13.11 vbr-shp

**Description** VBR shaped traffic setting (atmClpTransparentScr)

**Syntax** vbr-shp <index> pcr <pcr> cdvt <cdvt> scr <scr> mbs <mbs>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<scr>	Sustained Cell Rate <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<mbs>	Maximum Burst Size <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.13.12 vbrnrt

**Description** VBR-nrt shaped traffic setting (atmClpNoTaggingScrCdvT)

**Syntax** vbr-shp <index> pcr <pcr> cdvt <cdvt> scr <scr> mbs <mbs>

**Parameter**

Name	Description
<index>	ATM Descriptor index <b>Valid values:</b> 1 ~ 251 <b>Default value:</b> - <b>Type:</b> Mandatory
<pcr>	Peak cell rate number <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<cdvt>	Cell Delay Variation Tolerance <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<scr>	Sustained Cell Rate <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory
<mbs>	Maximum Burst Size <b>Valid values:</b> 0 ~ 65535 <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.14 Priority List Mode Commands

The commands in this section can be executed only in the Priority List execution mode.

### 5.14.1 ds

**Description** Set Differentiated Service of packets to remark VLAN priority / Show Differentiated Service priority list entry / Disable Differentiated Service priority list entry

**Syntax** ds <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}} dscp <dscp>

ds <number> list

ds <number> disable

#### Parameter

Name	Description												
<number>	Differentiated Service priority list number. <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory												
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory												
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory												
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory												
<dscp>	Diffserv Code Points, which is a 6-bit number. The standardized combinations are listed below: <table border="0"> <tr> <td>default</td> <td>Default value (bits:000000)</td> </tr> <tr> <td>af11</td> <td>Assured Forwarding Class 1:Low Drop (bits:001010)</td> </tr> <tr> <td>af12</td> <td>Assured Forwarding Class 1:Medium Drop (bits:001100)</td> </tr> <tr> <td>af13</td> <td>Assured Forwarding Class 1:High Drop (bits:001110)</td> </tr> <tr> <td>af21</td> <td>Assured Forwarding Class 2:Low Drop (bits:010010)</td> </tr> <tr> <td>af22</td> <td>Assured Forwarding Class 2:Medium Drop (bits:010100)</td> </tr> </table>	default	Default value (bits:000000)	af11	Assured Forwarding Class 1:Low Drop (bits:001010)	af12	Assured Forwarding Class 1:Medium Drop (bits:001100)	af13	Assured Forwarding Class 1:High Drop (bits:001110)	af21	Assured Forwarding Class 2:Low Drop (bits:010010)	af22	Assured Forwarding Class 2:Medium Drop (bits:010100)
default	Default value (bits:000000)												
af11	Assured Forwarding Class 1:Low Drop (bits:001010)												
af12	Assured Forwarding Class 1:Medium Drop (bits:001100)												
af13	Assured Forwarding Class 1:High Drop (bits:001110)												
af21	Assured Forwarding Class 2:Low Drop (bits:010010)												
af22	Assured Forwarding Class 2:Medium Drop (bits:010100)												

af23	Assured Forwarding Class 2:High Drop (bits:010110)
af31	Assured Forwarding Class 3:Low Drop (bits:011010)
af32	Assured Forwarding Class 3:Medium Drop (bits:011100)
af33	Assured Forwarding Class 3:High Drop (bits:011110)
af41	Assured Forwarding Class 4:Low Drop (bits:100010)
af42	Assured Forwarding Class 4:Medium Drop (bits:100100)
af43	Assured Forwarding Class 4:High Drop (bits:100110)
ef	Expedited Forwarding (bits:101110)

### 5.14.2 ds list

<b>Description</b>	Show Differentiated Service priority list
<b>Syntax</b>	ds list
<b>Parameter</b>	None

### 5.14.3 dstip

**Description** Specify dest IP address of packets to remark vlan priority / Show dest IP address priority list entry / Disable dest IP address priority list entry

**Syntax** dstip <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}} ip <ipv4 address> <netmask>  
dstip <number> list  
dstip <number> disable

#### Parameter

Name	Description
<number>	Destination IP address priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8

	<b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Destination IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<netmask>	Subnet mask <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

#### 5.14.4 dstip list

<b>Description</b>	Show destination IP address priority list
<b>Syntax</b>	dstip list
<b>Parameter</b>	None

#### 5.14.5 dstmac

<b>Description</b>	Specify dest MAC of packets to remark vlan priority / Show dest MAC priority list entry / Disable dest MAC priority list entry
<b>Syntax</b>	dstmac <number> prio <prio ID> {xdsl <port>/<pvc>   gigabit {<port>   la}} mac <mac address>  dstmac <number> list dstmac <number> disable

#### Parameter

Name	Description
<number>	Destination MAC priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory

<code>&lt;mac address&gt;</code>	MAC address <b>Valid values:</b> xx:xx:xx:xx:xx:xx (xx:0~ff) <b>Default value:</b> 00:00:00:00:00:00 <b>Type:</b> Mandatory
----------------------------------	--

#### 5.14.6 dstmac list

**Description** Show destination MAC priority list

**Syntax** dstmac list

**Parameter** None

#### 5.14.7 ethertype

**Description** Specify Ether Type of packets to remark vlan priority / Show Ether Type priority list entry / Disable Ether Type priority list entry

**Syntax** ethertype <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}}  
type <ethertype>

ethertype <number> list

ethertype <number> disable

**Parameter**

Name	Description
<code>&lt;number&gt;</code>	ToS (IP Precedence) priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<code>&lt;prio ID&gt;</code>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<code>&lt;port&gt;</code>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<code>&lt;pvc&gt;</code>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<code>&lt;ethertype&gt;</code>	Ether Type value <b>Valid values:</b> 0x0001 ~ 0xffff <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.14.8 ethertype list

**Description** Show Ether Type priority list  
**Syntax** ethertype list  
**Parameter** None

### 5.14.9 ipprotocol

**Description** Specify IP protocol of packets to remark vlan priority / Show IP protocol priority list entry / Disable IP protocol priority list entry  
**Syntax** ipprotocol <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la} } protocol <protocol>  
ipprotocol <number> list  
ipprotocol <number> disable

#### Parameter

Name	Description
<number>	ToS (IP Precedence) priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
protocol	Input protocol name. <b>Valid values:</b> icmp (ICMP) Internet Control Message <1> igmp (IGMP) Internet Group Management <2> ipinip IP in IP (encapsulation) <4> tcp (TCP) Transmission Control <6> grp (GRP) Globin Reduction Protocol <7> igp (IGP) Any private interior gateway <9>

udp	(UDP) User Datagram <17>
gre	(GRE) General Routing Encapsulation <47>
eigrp	EIGRP <88>
ospf	OSPF <89>
<b>Default value:</b> -	
<b>Type:</b> Mandatory	

#### 5.14.10 ipprotocol list

**Description** Show IP protocol priority list

**Syntax** ipprotocol list

**Parameter** None

#### 5.14.11 srcip

**Description** Specify source IP address of packets to remark vlan priority

**Syntax** srcip <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}} ip <ipv4 address> <netmask>

srcip <number> list

scrip <number> disable

**Parameter**

Name	Description
<number>	Source IP address priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	Destination IP address <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> 0.0.0.0



	<b>Type:</b> Mandatory
<netmask>	Subnet mask <b>Valid values:</b> xxx.xxx.xxx.xxx (xxx:0~255) <b>Default value:</b> - <b>Type:</b> Optional

#### 5.14.12 srcip list

**Description** Show source IP address priority list

**Syntax** srcip list

**Parameter** None

#### 5.14.13 srcmac

**Description** Specify source MAC of packets to remark vlan priority

**Syntax** srcmac <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}}  
mac <mac address>

srcmac <number> list

srcmac <number> disable

**Parameter**

Name	Description
<number>	Source mac priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<mac address>	MAC address <b>Valid values:</b> xx:xx:xx:xx:xx:xx (xx:0~ff) <b>Default value:</b> 00:00:00:00:00:00 <b>Type:</b> Mandatory

#### 5.14.14 srcmac list

**Description** Show source MAC priority list

**Syntax** srcmac list

**Parameter** None

#### 5.14.15 tos

**Description** Specify ToS (IP Precedence) of packets to remark vlan priority / Show ToS (IP Precedence) priority list entry / Disable ToS (IP Precedence) priority list entry

**Syntax** tos <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}} precedence <tos>

tos <number> list

tos <number> disable

**Parameter**

Name	Description
<number>	ToS (IP Precedence) priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<tos>	Incoming Type of Service. <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.14.16 tos list

<b>Description</b>	Show ToS (IP Precedence) priority list
<b>Syntax</b>	tos list
<b>Parameter</b>	None

#### 5.14.17 vlanid

**Description** Specify VLAN ID of packets to remark VLAN priority / Show VLAN id priority list entry / Disable VLAN id priority list entry

**Syntax** vlanid <number> prio <prio ID> {xdsl <port>/<pvc> | gigabit {<port> | la}}  
vlan <VLAN ID>

vlanid <number> list

vlanid <number> disable

#### Parameter

Name	Description
<number>	Vlan id priority list number <b>Valid values:</b> 1~256 <b>Default value:</b> - <b>Type:</b> Mandatory
<prio ID>	Priority value <b>Valid values:</b> 0~7 <b>Default value:</b> - <b>Type:</b> Mandatory
<port>	Port number. <b>Valid values:</b> 1~48 for xDSL, 1~2 for GBE <b>Default value:</b> - <b>Type:</b> Mandatory
<pvc>	PVC number <b>Valid values:</b> 1 ~ 8 <b>Default value:</b> - <b>Type:</b> Mandatory
<VLAN ID>	VLAN ID number <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.14.18 vlanid list

<b>Description</b>	Show VLAN id priority list
<b>Syntax</b>	vlanid list
<b>Parameter</b>	None

## 5.15 Alarm Profile Mode Commands

The commands in this section can be executed only in the Alarm Profile execution mode.

### 5.15.1 alarm mask

**Description** Mask the alarm

**Syntax** alarm mask <name>

**Parameter**

Name	Description
<name>	Name of alarm. <b>Valid values:</b> Refer to Appendix B Alarm Table. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.15.2 alarm unmask

**Description** Unmask the alarm

**Syntax** alarm unmask <name>

**Parameter**

Name	Description
<name>	Name of alarm. <b>Valid values:</b> Refer to Appendix B Alarm Table. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.15.3 alarm major

**Description** Set the level of the alarm to Major

**Syntax** alarm major <name>

**Parameter**

Name	Description
<name>	Name of alarm. <b>Valid values:</b> Refer to Appendix B Alarm Table. <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.15.4 alarm minor

**Description** Set the level of the alarm to Minor

**Syntax** alarm minor <name>

**Parameter**

Name	Description
<name>	Name of alarm. <b>Valid values:</b> Refer to Appendix B Alarm Table. <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.16 IGMP-ACL Profile Mode Commands

The commands in this section can be executed only in the IGMP-ACL Profile execution mode.

### 5.16.1 igmp-acl

**Description** IGMP group ACL Setting (IP and VLAN) / Delete channel setting

**Syntax** igmp-acl <number> {<ipv4 address> vlan <VLAN ID> | delete}

**Parameter**

Name	Description
<number>	IGMP ACL channel index. <b>Valid values:</b> 1 ~ 256 <b>Default value:</b> - <b>Type:</b> Mandatory
<ipv4 address>	IGMP group address <b>Valid values:</b> 224.0.0.0 ~ 239.255.255.255 The range of addresses from 224.0.0.0 to 224.0.0.255 is reserved for the use of routing protocols and other low-level topology discovery or maintenance protocols. <b>Default value:</b> 0.0.0.0 <b>Type:</b> Mandatory
<VLAN ID>	VLAN ID. <b>Valid values:</b> 1 ~ 4094 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.16.2 igmp-acl rebind

**Description** IGMP ACL Profile rebind

**Syntax** igmp-acl rebind

**Parameter** None

## 5.17 Rate Limit Profile Mode Commands

The commands in this section can be executed only in the Rate Limit Profile execution mode.

### 5.17.1 share-slb

**Description** Set share SLB (Single Leaky Bucket) / Delete the share SLB profile

**Syntax** share-slb <number> {cir <cir> lbs <lbs> | disable}

**Parameter**

Name	Description
number	Share SLB profile index <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.17.2 share-dlb

**Description** Set share DLB (Dual Leaky Bucket) / Delete the share DLB profile

**Syntax** share-dlb <number> {cir <cir> lbs <lbs> eir <eir> lbs <lbs> | disable}

**Parameter**

Name	Description
number	Share DLB profile index <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	First Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> - <b>Type:</b> Mandatory
<eir>	Excess Info Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000

	<b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	Second Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.17.3 non-share-slb

**Description** Set non-share SLB (Single Leaky Bucket) / Delete the non-share SLB profile

**Syntax** non-share-slb <number> {cir <cir> lbs <lbs> | disable}

**Parameter**

Name	Description
number	Share SLB profile index <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.17.4 non-share-dlb

**Description** Set non-share DLB (Dual Leaky Bucket) / Delete the non-share DLB profile

**Syntax** non-share-dlb <number> {cir <cir> lbs <lbs> eir <eir> lbs <lbs> | disable}

**Parameter**

Name	Description
number	Share DLB profile index <b>Valid values:</b> 1 ~ 48 <b>Default value:</b> - <b>Type:</b> Mandatory
<cir>	Committed Information Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	First Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> -



	<b>Type:</b> Mandatory
<eir>	Excess Info Rate (bps) <b>Valid values:</b> 1536 ~ 1000000000 <b>Default value:</b> - <b>Type:</b> Mandatory
<lbs>	Second Leakage Bucket Size (bits) <b>Valid values:</b> 1 ~ 1024 <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.18 Service Profile Configure Mode Commands

The commands in this section can be executed only in the Service Profile execution mode.

### 5.18.1 bitrate

**Description** Set downstream/upstream Minimum/Maximum/Planned/L2 minimum bit rate

**Syntax** bitrate {ds | us} {min | max | planned | l2} <number>

**Parameter**

Name	Description
number	Bit rate (kb/s). <b>Valid values:</b> 0-65535 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.18.2 delay

**Description** Set downstream/upstream delay introduced by the interleaving

**Syntax** delay {ds | us} <number>

**Parameter**

Name	Description
number	Delay time (ms). <b>Valid values:</b> 1-63 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.18.3 l2-packet

**Description** Set L2 Packet cell

**Syntax** l2-packet <number>

**Parameter**

Name	Description
number	Set L2 Packet cell. <b>Valid values:</b> 0 ~ 28 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.18.4 mode

**Description** Set downstream/upstream rate adaptive mode to **init** (rate automatically selected at start up only and does not change after that), **dynamic** (rate automatically selected at initialization and is continuously adapted during show time), or **manual** (rate changed manually)

**Syntax** mode {ds | us} {init | dynamic | manual}

**Parameter** None

### 5.18.5 noise

**Description** Set downstream/upstream minimum impulse noise protection.

**Syntax** noise {ds | us} <number>

**Parameter**

Name	Description
number	Noise (tenth symbols). <b>Valid values:</b> 0~8 step 0.1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.18.6 noisemargin

**Description** Set Downshift/Upshift Noise Margin in downstream/upstream direction

**Syntax** noisemargin {ds | us} {downshift | upshift} <number>

**Parameter**

Name	Description
number	Downshift/Upshift Noise Margin (tenth symbols). <b>Valid values:</b> 0~31 step 0.1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.18.7 ra-interval

**Description** Set Downshift/Upshift Interval in downstream/upstream direction

**Syntax** ra-interval {ds | us} {downshift | upshift} <number>

**Parameter**

Name	Description
number	Downshift/Upshift interval (seconds). <b>Valid values:</b> 0 ~ 16383 <b>Default value:</b> 10 <b>Type:</b> Mandatory

### 5.18.8 service name

**Description** Set service profile name

**Syntax** service name <string>

**Parameter**

Name	Description
<string>	Profile name. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

## 5.19 Spectrum Profile Configure Mode Commands

The commands in this section can be executed only in the Spectrum Profile execution mode.

### 5.19.1 aggregate

**Description** Set downstream/upstream aggregate power level

**Syntax** aggregate {ds | us} max powerlevel <number>

**Parameter**

Name	Description
<number>	Power level (tenth dBm). <b>Valid values:</b> 0~25.5 step 0.1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.2 bands <index> {start | stop}

**Description** Set RF bands

**Syntax** bands <index> {start | stop} <value>

**Parameter**

Name	Description
index	Bands array index. <b>Valid values:</b> 0-7 <b>Default value:</b> - <b>Type:</b> Mandatory
value	Set start / stop frequency (kHz). <b>Valid values:</b> 0-12000 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.3 bands <index> mask

**Description** Set bands mask

**Syntax** bands <index> mask <value>

**Parameter**

Name	Description
index	Bands array index. <b>Valid values:</b> 0-7 <b>Default value:</b> - <b>Type:</b> Mandatory
value	<b>Valid values:</b> see the following: egress_no_control    egress no control egress_notched      egress notched ingress_low          ingress low

	ingress_weak	ingress weak
	ingress_strong	ingress strong
	rf_signal_am	RF Signal AM Type
	rf_signal_hamband Type	RF Signal HAMBAND Type
	<b>Default value:</b> egress_no_control	
	<b>Type:</b> Mandatory	

#### 5.19.4 carriermask

**Description** Set carrier mask

**Syntax** carriermask {ds | us} <index> <value>

**Parameter**

Name	Description
index	Carrier mask array index. <b>Valid values:</b> 0-63 <b>Default value:</b> - <b>Type:</b> Mandatory
<value>	Carrier mask array value. <b>Valid values:</b> 0x00~0xff (Hex) <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.19.5 message-based

**Description** Set minimum DS/US message-based data rate that is needed by ATU

**Syntax** message-based {ds | us} min <number>

**Parameter**

Name	Description
<number>	Min downstream/upstream message-based data rate. <b>Valid values:</b> 4 ~ 28 kbps <b>Default value:</b> - <b>Type:</b> Mandatory

#### 5.19.6 modem features

**Description** Set modem features enable/disable

**Syntax** modem features {enable | disable}

**Parameter** None

### 5.19.7 noisemargin

**Description** Set downstream/upstream maximum / minimum / target noise margin

**Syntax** noisemargin {ds | us} {max | min | target} <number>

**Parameter**

Name	Description
<number>	Noise margin value. <b>Valid values:</b> 0~31 (or 51.1 means no max noise margin is used) step 0.1. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.8 opmode

**Description** Set Operational mode

**Syntax** opmode {set | clear} <opmode id>

**Parameter**

Name	Description
opmode id	The ID of allowed ADSL modes of operation. <b>Valid values:</b> Use 'list opmode' command to see all the operation modes. <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.9 pbomode

**Description** Set power backoff operation mode ON/OFF

**Syntax** pbomode us {on | off}

**Parameter** None

### 5.19.10 power-mgt disable

**Description** Disable power management function for ADSL

**Syntax** power-mgt disable

**Parameter** None

### 5.19.11 power-mgt l2 enable

**Description** Allow autonomous L2 state entry/exit

**Syntax** power-mgt l2 enable

**Parameter** None

### 5.19.12 power-mgt l2\_l3 enable

**Description** Allow autonomous L2 and L3 state entry/exit

**Syntax** power-mgt l2\_l3 enable

**Parameter** None

### 5.19.13 power-mgt l0-time

**Description** Set the minimum time (in seconds) between Exit from L2 low power state and the next Entry into the L2 low power state

**Syntax** power-mgt l0-time <number>

**Parameter**

Name	Description
<number>	L0 Time value. <b>Valid values:</b> 0 ~ 255 (sec) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.14 power-mgt l2-time

**Description** Set minimum time (in seconds) between an Entry into L2 low power state and the first L2 low power trim request, and between two consecutive L2 power trim requests

**Syntax** power-mgt l2-time <number>

**Parameter**

Name	Description
<number>	L2 Time value. <b>Valid values:</b> 0 ~ 255 (sec) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.15 power-mgt l2-atpr

**Description** Set maximum aggregate transmit power reduction (in dB) that is allowed at transition of L0 to L2 state or an L2 low power trim request

**Syntax** power-mgt l2-atpr <number>

**Parameter**

Name	Description
<number>	L2 power reduction range value. <b>Valid values:</b> 0 ~ 31 (dB) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.16 power-mgt l2-atprt

**Description** Set total maximum aggregate transmit power reduction (in dB) that is allowed in the L2 state; the total reduction is the sum of all reductions of L2 Request (i.e., at transition of L0 to L2 state) and L2 power trims

**Syntax** power-mgt l2-atprt <number>

**Parameter**

Name	Description
<number>	L2 total power reduction value. <b>Valid values:</b> 0 ~ 31 (dB) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.17 psdlevel

**Description** Set PSD level

**Syntax** psdlevel {ds | us} max <number>

**Parameter**

Name	Description
<number>	Maximum PSD level (tenth dBm/Hz). <b>Valid values:</b> -60 ~ -40 downstream step 0.1 -60 ~ -38 upstream. step 0.1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.18 psdshape

**Description** Set PSD shape

**Syntax** psdshape ds {cut-off <number> | standard}

**Parameter**

Name	Description
number	Cut-off frequencies at carrier. <b>Valid values:</b> 100-280 step 10 <b>Default value:</b> - <b>Type:</b> Mandatory



### 5.19.19 rxaggregate us max powerlevel

**Description** Set maximum aggregate receive power level

**Syntax** rxaggregate us max powerlevel <number>

**Parameter**

Name	Description
<number>	Maximum aggregate receive power level (-255~255 tenth dBm). <b>Valid values:</b> -25.5~25.5 step 0.1 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.20 spectrum name

**Description** Set spectrum profile name

**Syntax** spectrum name <string>

**Parameter**

Name	Description
<string>	Name of the spectrum profile. (max 31 characters) <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.19.21 status modify complete

**Description** Set the status of modification

**Syntax** status modify complete

**Parameter** None

## 5.20 TCA Profile Mode Commands

The commands in this section can be executed only in the TCA Profile execution mode.

### 5.20.1 adsl-tca day

**Description** Set threshold value for near-end/far-end day PM

**Syntax** adsl-tca day {ne | fe} {es | ses | uas} <number>

**Parameter**

Name	Description
number	Threshold value. <b>Valid values:</b> 0-86400 <b>Default value:</b> - <b>Type:</b> Mandatory

### 5.20.2 adsl-tca disable

**Description** Disable TCA

**Syntax** adsl-tca disable

**Parameter** None

### 5.20.3 adsl-tca enable

**Description** Enable TCA

**Syntax** adsl-tca enable

**Parameter** None

### 5.20.4 adsl-tca interval

**Description** Set threshold value for near-end/far-end interval PM

**Syntax** adsl-tca interval {ne | fe} {es | ses | uas | lof | lol | los | errframe} <number>

**Parameter**

Name	Description
number	Threshold value. <b>Valid values:</b> 0-900 <b>Default value:</b> - <b>Type:</b> Mandatory

# Appendix A ADSL Operational Mask Table

**Table A-1 ADSL Operational Mask**

Bit	Description	Bit	Description
0	ANSI_T1.413	32	992_4_I_AllDigital_NonOverlapped
1	ETSI_DTS_TM06006	33	992_4_I_AllDigital_Overlapped
2	992_1_A_Pots_NonOverlapped	34	992_3_L_Pots_NonOverlapped_Mode1
3	992_1_A_Pots_Overlapped	35	992_3_L_Pots_NonOverlapped_Mode2
4	992_1_B_Isdn_NonOverlapped	36	992_3_L_Pots_Overlapped_Mode3
5	992_1_B_Isdn_Overlapped	37	992_3_L_Pots_Overlapped_Mode4
6	992_1_C_TcmIsdn_NonOverlapped	38	992_3_M_Pots_Extend_US_Overlapped
7	992_1_C_TcmIsdn_Overlapped	39	992_3_M_Pots_Extend_US_NonOverlapped
8	992_2_A_Pots_NonOverlapped	40	992_5_A_Pots_NonOverlapped
9	992_2_B_Pots_Overlapped	41	992_5_A_Pots_Overlapped
10	992_2_C_TcmIsdn_NonOverlapped	42	992_5_B_Isdn_NonOverlapped
11	992_2_C_TcmIsdn_Overlapped	43	992_5_B_Isdn_Overlapped
18	992_3_A_Pots_NonOverlapped	46	992_5_I_AllDigital_NonOverlapped
19	992_3_A_Pots_Overlapped	47	992_5_I_AllDigital_Overlapped
20	992_3_B_Isdn_NonOverlapped	48	ANSI_T1.424
21	992_3_B_Isdn_Overlapped	49	ETSI_TS_101_270
24	992_4_A_Pots_NonOverlapped	50	993_1
25	992_4_A_Pots_Overlapped	51	IEEE_8023ah
28	992_3_I_AllDigital_NonOverlapped	56	992_5_J_AllDigital_NonOverlapped
29	992_3_I_AllDigital_Overlapped	57	992_5_J_AllDigital_Overlapped
30	992_3_J_AllDigital_NonOverlapped	58	992_5_M_Pots_Extend_US_NonOverlapped
31	992_3_J_AllDigital_Overlapped	59	992_5_M_Pots_Extend_US_Overlapped

# Appendix B Alarm Table

**Table B-1 Alarm Table**

Alarm ID	Name	Description
104	alm_fan_fail	System Fan Fail
105	alm_self_test_fail	System Self Test Fail
106	alm_above_temper	System Above Temperature
107	alm_below_temper	System Below Temperature
118	alm_dsl_dsp	System DSP Fail
601	alm_adsl_los	Near-end Loss of Signal
602	alm_adsl_lof	Near-end Loss of Frame
603	alm_adsl_lom	Near-end Loss of Margin
610	alm_adsl_lcd	Near-end Loss Cell Delineation
612	alm_adsl_ncd	Near-end No Cell Delineation
613	alm_adsl_los_fe	Far-end Loss of Signal
614	alm_adsl_lof_fe	Far-end Loss of Frame
615	alm_adsl_lom_fe	Far-end Loss of Margin
616	alm_adsl_lopwr_fe	Far-end Loss of Power
619	alm_adsl_commf_fe	Far-end Communication Failure
620	alm_adsl_nopeer_fe	Far-end No Peer Present
622	alm_adsl_lcd_fe	Far-end Loss Cell Delineation
624	alm_adsl_ncd_fe	Far-end No Cell Delineation

# Appendix C Maintenance Requirement

## Tools and Equipment Requirements

Below tablelists required tools and test equipment for the IDL-4802 system maintenance.

### Required Installation Tools and Materials

Item Required	Purpose
Anti-static wrist strap	Protect the system from electrostatic discharge damage
Hand tool	Screwdrivers for equipment removal and replacement
Wire cutter/stripper	Prepare wires for electrical connections
Wire-wrap gun and bit	Removing and replacing the system interconnection wires
Wires	System interconnections to external facilities
VF transmission and signaling test sets	Testing faulty POTS
Fuse and alarm panel	For protection and simplifying troubleshooting

## System Spares

Always keep spares for the DSLAM at each central office for replacement purposes. During the system trouble-shooting procedures, certain cards at the central office and/or remote site will be required to be replaced.

## Dispatching Maintenance Personnel

Some procedures in this manual involve end-to-end system testing, for which technicians are needed at each remote site. The remote IDL-4802 system sites are normally unattended, however, technicians should be dispatched when needed. The IDL-4802 system maintenance efforts and monitor the system for alarms during those on-site operations.

## Electrostatic Discharge Protection

The IDL-4802 system contains static-sensitive components. Be sure to wear a properly grounded antistatic wrist strap when handling them. Also, when removing and replacing a card, hold it either by its front ejector handle or by its edges.

Do not touch its rear connector contacts, which must remain free of contaminants.

## Routine Maintenance

Always monitor the IDL-4802 system performance at the central office/ remote sites using the snmp. It allows user to view the current system status, alarm information and to take the necessary corrective action if a problem is reported.

Also keep each IDL-4802 system site free of dust and other pollutant that could affect system performance. In addition, be sure to maintain the environment conditions at the central office and at each remote system site. The ideal operating temperature is about 20°C. The following is the acceptable operating condition range:

- -10°C to 65°C and 0% to 95% humidity at 35°C

## Powering the IDL-4802 Up or Down

This section describes how to power up the DSLAM and how to power down the DSLAM.

### Procedures of Powering Up the DSLAM

Step	Action
1	Put on the antistatic wrist strap and connect it to a grounding point.
2	Ensure that the DSLAM is securely installed.
3	Ensure that the DSLAM ground strap is connected to a suitable ground point.
4	Ensure that -48 Vdc power is being supplied to the DSLAM.
5	Ensure that the fan card is installed.
6	Ensure that the POTS lines, subscriber lines, and alarm equipment are connected.
7	Slide the power switch on the faceplate to ON.
8	Wait for a minute, and then check the LEDs on the DSLAM. If the LEDs show some problem, refer to section 3.2 for information on how to resolve problems indicated through LEDs.


### Procedures of Powering Down the DSLAM

Step	Action
	<b>Caution:</b> Powering down the DSLAM stops DSL service to subscribers. POTS service is not affected.
1	Put on the antistatic wrist strap and connect it to a grounding point.
2	Slide the power switch on the faceplate to Off.

## Replacing Units

This section provides procedures on how to:

- replace the fan card (replace as required)
- replace the air filter (replace every three months)



### Procedure 1 Replace the Fan Card

---

**Danger** — When removing the fan card, wait for a moment for the fan blades to come to a complete stop before fully extracting the fan card.

- 1 Put on the antistatic wrist strap and connect it to a grounding point.
  - 2 Slide the power switch of the DSLAM to the OFF position.
  - 3 Remove the fan card to be replaced by doing the following steps:
    - a Turn the two screws on the faceplate of the fan card counterclockwise until they loosen the connection of the fan card to the DSLAM.
    - b Pull the fan card out about 2 inches and wait for a moment for the fan blades to stop completely.
    - c Pull the fan card completely out of the DSLAM, and set it aside.
  - 4 Install the replacement fan card into the DSLAM by doing the following steps:
    - a Slide the replacement fan card into the fan card slot of the DSLAM.
    - b Turn the two screws on the faceplate of the fan card clockwise until they secure the fan card in place.
-

## **Procedure 2 Replace the Air Filter**

---

**Note** — You must loosen the connection of the fan card to the DSLAM and pull out the FAN card (refer to Procedure 1) before replacing the air filter. While you want to install the replacement filter, remember that you have to insert the air filter into the chassis slot before inserting the FAN card. Because you will not be able to insert the air filter after the FAN card is secured in place.

- 1 Put on the antistatic wrist strap and connect it to a grounding point.
  - 2 Slide the power switch of the DSLAM to the OFF position.
  - 3 Remove the fan card (refer to Procedure 1).
  - 4 Pull the air filter out of the DSLAM.
  - 5 Slide the replacement air filter into the air filter slot of the DSLAM.
  - 6 Install the FAN card back in the chassis.
-



## Appendix D Introduction for Troubleshooting

This chapter describes instructions for the IDL-4802 system problems. These procedures may require the presence of technicians at remote IDL-4802 system sites and plus an operator at PC to monitor system alarms by console or EMS during maintenance.

### Resolving Problems Indicated Through LEDs

This section describes what to do to solve problems indicated by LEDs on the system front panel.

#### Problems Indicated by LEDs

LED	Activity	Problem	Action
SYS	Not lit even though DSLAM is powered up	There is a power up problem with the system.	Troubleshoot the DSLAM for power up problems; see section 3.4.
	Red	Self-test failed. There is a functional problem with the system.	Replace the IDL-4802.
ALM	Red	Major alarm set	See next section.
	Red-Flash	Major and Minor alarm set	See next section.
	Yellow	Minor alarm set	See next section.
GBE1/GBE2 (If SFP interface is activated)	Not lit even though DSLAM is powered up	No link	Troubleshoot the DSLAM for fiber optics problems.

### Resolving Problems Indicated Through Alarms

Alarms of the system are viewed through CLI, Web GUI.

If an alarm indicates a problem, refer to section troubleshooting procedures.

### Troubleshooting Procedures for the IDL-4802

When you follow a troubleshooting procedure, start from the first step of the procedure. If the first step does not solve the problem, proceed to the next step; keep going through the steps until the problem is solved. Use the following table to find out the appropriate procedure for troubleshooting the listed problems.

## List of Troubleshooting Procedures

Type of problem	Procedure Number
IDL-4802 power up problems	1
Fan card power up problems	2
Fiber optics problems	3
ADSLx service problems (POTS service is ok)	4
POTS service problems (ADSLx service is ok)	5
Subscriber service problems (no POTS and ADSLx service)	6

### Procedure 1 Troubleshoot IDL-4802 Power Up Problems

---

Problem indication:

- the SYS LED on the front panel is not lit even though the DSLAM is powered up
  - alarm that indicates a system power up problem
  - subscribers connected to the DSLAM do not have DSL service; POTS service is ok
- 1 Check that the power switch on the front panel is set to the ON position.
  - 2 Check that the power feeds are connected to the DSLAM, and that power is present on the two power feeds with correct polarity.
  - 3 Replace the IDL-4802.
  - 4 Contact your provider.
- 

### Procedure 2 Troubleshoot Fan Card Power Up Problems

---

Problem indication:

- alarm that indicates a fan problem
- 1 Check that the fan card is completely inserted in its slot.
  - 2 Replace the fan card.
  - 3 Contact your provider.
- 

### Procedure 3 Troubleshoot Fiber Optics Problems

---

Problem indication:

- the GBE1/GBE2 LED on the system front panel is not lit (maybe the signal power detected by the fiber optical receiver being below the minimum power threshold) but the SFP interface has been activated
  - alarm that indicates loss of signal
  - subscribers connected to the DSLAM do not have DSL service; POTS service is ok
- 1 Check the connection of the fiber optics link. Check that the connections are secure and that the transmit and receive connections are not reversed.
  - 2 Disconnect the fiber optics link from the dual fiber optics connector and do a physical loopback at the IDL-4802.
    - a If the GBE1/GBE2 LED turns green, the problem is with the fiber optics link.
    - b If the GBE1/GBE2 LED does not turn green, the problem is with the DSLAM. Follow **Procedure 1** to troubleshoot the DSLAM.
  - 3 If the problem is with the fiber optics cabling, clean or replace as appropriate.
  - 4 Contact your provider.
-

#### **Procedure 4 Troubleshoot ADSLx Service Problems**

---

Problem indication: No ADSLx service to the affected subscribers (POTS service is ok).

- 1 If all subscribers connected to the DSLAM are affected, and the SYS LED on the front panel is not lit, check the power switch on the front panel:
    - if the power switch is set to the OFF position, power up the DSLAM by sliding the power switch to the ON position
    - if the power switch is set to the ON position, follow **Procedure 1** to troubleshoot the DSLAM for power up problem
  - 2 If all subscribers are affected, check the SYS LED on the front panel; if it is red, replace the DSLAM.
  - 3 Check the GBE1/GBE2 LED (if SFP interface is activated); if it is not lit, follow **Procedure 3** to troubleshoot the DSLAM for fiber optics problems.
  - 4 If only some subscribers are affected, identify the ports that have problems. Check that the subscribers are connected to the line interfaces properly.
  - 5 Contact your provider.
- 

#### **Procedure 5 Troubleshoot POTS Service Problems**

---

Problem indication: No POTS service to the affected subscribers (ADSLx service is ok).

- 1 Check the connection of the POTS lines at the POTS connector for the DSLAM.
  - 2 Use a bridging connector to couple the POTS and subscriber lines. If this solves the problem, replace the DSLAM.
  - 3 Check the condition of the POTS lines and connectors.
- 

#### **Procedure 6 Subscriber Service Problems**

---

Problem indication: No POTS and ADSLx service to the affected subscribers.

- 1 Check the connection of the subscriber lines and POTS lines at the subscriber line connector for DSLAM for subscribers that do not have POTS and ADSLx service. If this step results in POTS service to the affected subscribers but there is still no ADSLx service to them, follow **Procedure 4** to troubleshoot ADSLx service problems. If this step results in ADSL service to the affected subscribers but there is still no POTS service to them, follow **Procedure 5** to troubleshoot POTS service problems.
  - 2 Use a bridging connector to couple the POTS and subscriber lines. If this results in POTS service to the affected subscribers, contact your provider.
  - 3 Check the condition of the subscriber lines and connectors.
-